

[Manuals.plus](#) /

› [BANZAI](#) /

› Banzai Aqua Sports Splash Pad Water Park Instruction Manual

BANZAI 90350

Banzai Aqua Sports Splash Pad Water Park Instruction Manual

Brand: BANZAI

Model: 90350

PRODUCT OVERVIEW

The Banzai Aqua Sports Splash Pad Water Park is an inflatable outdoor water play system designed for children aged 5-12. It features a large waterslide, a splash pool, a climbing wall, a basketball hoop, a volleyball net, and soccer goals, providing multiple activities for summer fun.



Image: The complete Banzai Aqua Sports Splash Pad Water Park, showcasing its vibrant colors and various play areas.



Image: An overhead view of the water park with key features labeled, including the curved waterslide, splash pool, climbing wall, built-in basketball ring, built-in volleyball net, and built-in soccer goal.

Safety Information

Always supervise children during use. Ensure the product is set up on a level, soft surface, free from sharp objects. The maximum combined user weight for this water park is 150 pounds. Ensure proper grounding for the blower motor.

The heavy-duty Dura-Tech vinyl construction is designed for durability, but regular inspection for wear and tear is recommended to ensure continued safe play.

Banzai

**INCLUDES
A BLOWER,
STORAGE BAG,
AND REPAIR KIT**



**FOR KIDS AGES
5-12 YEARS OLD;
SUPPORTS
UP TO 150 LBS.
COMBINED USER WEIGHT**

Image: This image highlights the included air blower, storage bag, and repair kit, along with text indicating the product is for ages 5-12 and supports up to 150 lbs combined user weight.

SETUP INSTRUCTIONS

Follow these steps for quick and easy setup:

1. **Unpack:** Carefully remove the water park and all components from the packaging.
2. **Placement:** Choose a flat, clear area in your backyard, away from any sharp objects, fences, or overhead obstructions.
3. **Unfold:** Unroll the inflatable water park completely.
4. **Connect Blower:** Attach the included air-blower motor to the inflation tube of the water park. Ensure the connection is secure to prevent air leakage.
5. **Inflate:** Plug in the air-blower motor (ensure it's connected to a GFCI outlet). The water park will inflate rapidly, typically within 2-3 minutes.
6. **Secure:** Use the provided ground stakes to secure the water park firmly in place.

7. **Water Connection:** Connect a standard garden hose to the water sprayer and shower attachments on the water park.
8. **Assemble Accessories:** Attach the volleyball net using the Velcro fasteners and set up the basketball hoop and soccer goals as desired.



Image: Children enjoying the fully inflated Aqua Sports Water Park, demonstrating its quick setup time of under 3 minutes.

OPERATING THE WATER PARK

Once fully inflated and secured, turn on the water supply to activate the slide's water flow and the overhead shower. Children can then enjoy the various features:

- **Waterslide:** Climb the wall and slide down into the splash pool.
- **Climbing Wall:** Use the hand and foot holds to ascend to the top of the slide.
- **Splash Pool:** A shallow pool area for splashing and cooling off.
- **Sports Activities:** Engage in basketball with the hoop, volleyball with the net, and soccer with the goals. Balls are

typically included for these activities.



Image: Children actively playing on the waterslide and in the splash pool, showcasing the main water features.



Image: Two children playing basketball in the water park's designated hoop area, highlighting one of the integrated sports activities.



Image: Children engaging in soccer and volleyball activities within the water park, demonstrating the versatility of the play area.

MAINTENANCE AND STORAGE

Proper care ensures the longevity of your water park:

- **Cleaning:** Regularly clean the water park with mild soap and water. Rinse thoroughly to remove any residue.
- **Drying:** Before deflating and storing, ensure the entire water park is completely dry to prevent mold and mildew. Using a leaf blower can assist in drying.
- **Repairs:** Small punctures or tears can be repaired using the included repair kit. Follow the instructions provided with the kit for effective patching.
- **Storage:** Deflate the water park completely, fold it neatly, and store it in a cool, dry place, preferably in the provided storage bag.



Image: The deflated water park rolled up for storage, alongside the air blower and other accessories, illustrating compact storage.

TROUBLESHOOTING

If you encounter any issues, refer to these common solutions:

- **Insufficient Inflation:** Ensure the blower tube is securely attached to the blower and the water park. Check for any large tears or openings that might be causing air loss.
- **Water Flow Issues:** Verify that the garden hose is properly connected and the water supply is turned on. Check for kinks in the hose or blockages in the water nozzles.
- **Minor Leaks:** Small air leaks are normal. For larger leaks or punctures, use the provided repair kit.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	BANZAI
Model Number	90350
Product Dimensions	180"L x 156"W x 96"H (15' L x 13' W x 8' H)
Material	Heavy-duty Dura-Tech Vinyl
Assembly Time	Approximately 2-3 minutes
Included Components	Inflatable water park, air-blower motor, water-spraying hose assembly, ground stakes, repair patches, carrying bag, sports balls (basketball, soccer ball, volleyball)
Item Weight	52.8 Pounds
Maximum Weight Recommendation	150 Pounds (combined user weight)
Recommended Age	5-12 years old

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question