Manuals+

Q & A | Deep Search | Upload

Step2 8521KR

Step2 Lifestyle Dream Kids Kitchen Playset Instruction Manual

Model: 8521KR | Brand: Step2

INTRODUCTION

The Step2 Lifestyle Dream Kids Kitchen Playset is designed to spark imagination and creativity in children aged 2 and above. This versatile indoor/outdoor pretend kitchen offers a realistic play experience with various interactive features and ample storage for accessories.

SAFETY INFORMATION

Choking Hazard. Small parts. Sharp points. Adult assembly required.

Warning: Adult supervision is recommended during play.

SETUP AND ASSEMBLY

The Step2 Lifestyle Dream Kids Kitchen Playset requires adult assembly. Follow these general steps:

- 1. Unpack all components and verify against the parts list (refer to the full installation manual for detailed instructions).
- 2. Assemble the main kitchen structure, ensuring all connections are secure.
- 3. Attach doors, drawers, and other interactive elements.
- 4. Install any required batteries (5 AAA batteries are needed for lights and sounds, not included).
- 5. Place accessories in designated storage areas.

For detailed assembly instructions, please refer to the official Installation Manual (PDF) linked in the Support section.



Figure 1: Product Dimensions Overview



Figure 2: Included Accessories

OPERATING INSTRUCTIONS

The Step2 Lifestyle Dream Kids Kitchen Playset offers various interactive features for an immersive play experience:

- **Electric Stove:** The electric stove turns on with realistic lights and sounds. Place pots or pans on the burner to activate.
- Microwave Keypad: The microwave features a working keypad for pretend cooking.
- **Sink Lights:** Lights over the sink provide illumination for play. Ensure batteries are installed for these features to function.
- Refrigerator and Oven Doors: Open and close the refrigerator and oven doors to store play food and accessories.
- **Storage:** Utilize the various drawers, cabinets, and storage bins for organizing the included 37-piece accessory set and other play items.

ACCESSORIES INCLUDED

Figure 3: Interactive Refrigerator Dispenser



Figure 4: Children Engaging with the Playset



Figure 5: Play Food and Cookware Interaction

MAINTENANCE AND CARE

To ensure the longevity and hygiene of your Step2 Lifestyle Dream Kids Kitchen Playset:

- **Cleaning:** Use disinfectant wipes or mild household cleaners to clean the surfaces. Ensure all cleaning agents are child-safe and wiped thoroughly.
- **Storage:** Store all accessories in the designated bins, drawers, and cabinets after playtime to keep the area tidy and prevent loss of pieces.
- **Durability:** The playset is constructed from durable double-walled plastic designed to resist chipping, fading, cracking, or peeling.
- Battery Replacement: Replace AAA batteries as needed for continued light and sound functionality.

TROUBLESHOOTING

If you encounter any issues with your playset, consider the following common solutions:

· Lights or Sounds Not Working:

- Check if 5 AAA batteries are installed correctly.
- Ensure batteries are fresh and not depleted.
- Verify that the battery compartment is securely closed.

· Oven Door Not Staying Shut:

- Inspect the latch mechanism for any obstructions or damage.
- Ensure the playset is on a level surface.

. Missing Parts:

- Refer to the parts list in the official Installation Manual to confirm all components were received.
- Contact Step2 customer support for assistance with missing parts.

• Chemical Smell on Accessories:

 Thoroughly wash all plastic accessories with mild soap and water before initial use. Rinse completely and allow to air dry.

SPECIFICATIONS

| Feature | Detail |
|--------------------|-----------------------------|
| Product Dimensions | 44.75 x 35.5 x 44.75 inches |
| Item Weight | 9.68 pounds |
| Model Number | 8521KR |
| Recommended Age | 24 months - 6 years |
| Batteries Required | 5 AAA batteries required. |
| Manufacturer | Step2 |
| Release Date | July 16, 2015 |

OFFICIAL PRODUCT VIDEOS

Watch these official videos for more insights into the Step2 Lifestyle Dream Kids Kitchen Playset:

No official seller videos are available for this product at this time.

WARRANTY AND SUPPORT

For detailed warranty information, product support, or to order replacement parts, please contact Step2 customer service directly.

An official Installation Manual (PDF) is available for download: Download Manual Visit the official Step2 Store for more products and information: Step2 Store

© 2024 Step2. All rights reserved.

Documents - Step2 – 8521KR



[pdf] Instructions

Lifestyle Dream Kitchen Download Instructions with Extra Play Food Set from Step2 8521KR assembly step2 media s ||

7363 8521 Lifestyle Dream KitchenTM For assistance or replacement parts please contact: The Step2 Company, LLC. 10010 Aurora-Hudson Rd. Streetsboro, OH 44241 USA 1-800-347-8372 USA Canada Only 330 656-0440 www.step2.com Step2 UK LTD Great Bank Road Wingates Industrial Estate BOLTON BL5 3XU Uk... lang:en score:35 filesize: 798.62 K page_count: 12 document date: 2023-01-11