

[Manuals.plus](#) /

› [HuskyTools](#) /

› Husky 52 in. 9-Drawer Mobile Workbench User Manual

HuskyTools 52 in.

Husky 52 in. 9-Drawer Mobile Workbench User Manual

Model: 52 in. | Brand: HuskyTools

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your Husky 52 in. x 24.5 in. D 9-Drawer Mobile Workbench. Designed for functional workspace and large storage capacity, this mobile work center is an ideal solution for organizing your tools and facilitating various projects.

Key features include large, durable casters for easy mobility, a steel tubular side handle, 100 lbs. rated ball bearing drawer slides, and a robust 21-Gauge steel construction. The 1 in. thick solid wood top is sealed with a protective polyurethane coating for enhanced durability. For added convenience, a power center with 6 outlets and 2 USB sockets is integrated into the side wall, and drawer liners are included.



Figure 1: Front view of the Husky 52 in. 9-Drawer Mobile Workbench.

2. SAFETY INFORMATION

Always read and understand all instructions before assembling or operating this product. Failure to follow these instructions may result in serious injury or property damage.

- Ensure the workbench is placed on a level, stable surface.
- Do not exceed the maximum load capacity of 1,200 lbs. Distribute weight evenly.
- Always lock the casters when the workbench is stationary to prevent unintended movement.
- Do not allow children to play on or around the workbench.
- Keep hands and fingers clear of drawer slides when opening or closing drawers.
- Use the integrated power center only with compatible devices and ensure proper grounding. Do not overload the outlets.
- Inspect the workbench regularly for any signs of damage or wear. Do not use if damaged.

3. SETUP AND ASSEMBLY

The Husky Mobile Workbench requires some assembly. It is recommended to have at least two people for assembly due to its weight and size (packaged weight approx. 290 lbs).

3.1 Unpacking

Carefully remove all components from the packaging. Verify that all parts are present according to the packing list (not provided in this manual, refer to product packaging). Keep packaging materials until assembly is complete in case of missing parts.

3.2 Attaching Casters

1. Carefully lay the workbench on its side on a protective surface to avoid scratching.
2. Attach the four 5 in. x 2 in. casters to the designated mounting points on the bottom of the workbench. Ensure the two swivel casters with brakes are installed on the same side (e.g., front), and the two rigid casters on the opposite side (e.g., rear).
3. Securely tighten all bolts.

3.3 Attaching Handle and Power Center

1. Attach the steel tubular side handle to the side of the workbench using the provided hardware.
2. Ensure the integrated power center (6-outlet and 2 USB sockets) is securely mounted in its designated slot on the side wall.
3. Once assembled, carefully stand the workbench upright.



Figure 2: Husky Mobile Workbench in a typical garage setup.

4. OPERATING INSTRUCTIONS

4.1 Workbench Surface

The 1 in. thick solid wood work surface provides a durable area for various tasks. Its polyurethane coating offers protection against elements. Avoid placing extremely hot items directly on the surface without protection.

4.2 Drawer Usage

The workbench features nine drawers equipped with 100 lbs. rated ball bearing slides for smooth operation. The top long drawer and two deep bottom drawers have double sets of 100 lbs. rated slides, designed for heavier and bulkier items. Drawer liners are included to protect tools and drawer interiors.

- To open a drawer, pull the handle firmly.
- To close, push the drawer until it fully retracts. The soft-close mechanism will engage for a quiet and secure closure.
- Distribute weight evenly within drawers to maintain smooth operation and prevent tipping.

4.3 Mobility and Locking

The large 5 in. x 2 in. casters allow for easy movement of the workbench, even when fully loaded. The two swivel casters include brakes. To lock the workbench in place, press down on the brake levers on the swivel casters. To unlock, lift the levers.

4.4 Power Center

The integrated power center provides six standard outlets and two USB ports for charging tools and devices. Connect the workbench's power cord to a suitable grounded electrical outlet. Ensure the power center is not overloaded.

5. MAINTENANCE

- **Cleaning:** Wipe down steel surfaces with a damp cloth and mild detergent. For the wood top, use a wood-safe cleaner. Avoid abrasive cleaners that could damage the finish.
- **Drawer Slides:** Periodically check drawer slides for smooth operation. If they become stiff, apply a small amount of silicone lubricant.
- **Casters:** Ensure casters are free of debris and roll smoothly. Lubricate if necessary. Check that caster brakes engage and disengage properly.
- **Hardware:** Regularly inspect all bolts and fasteners to ensure they are tight. Tighten as needed.

6. TROUBLESHOOTING

6.1 Drawers are Stiff or Not Closing Smoothly

- Check for obstructions: Ensure no tools or items are blocking the drawer slides or preventing full closure.
- Weight distribution: Verify that the weight inside the drawer is evenly distributed and not exceeding the 100 lbs capacity for that drawer.
- Lubrication: Apply a silicone-based lubricant to the drawer slides.

6.2 Workbench is Difficult to Move

- **Caster Brakes:** Ensure the caster brakes are disengaged.
- **Obstructions:** Check casters for any debris (e.g., string, hair) that might be impeding movement.
- **Surface:** Verify the floor surface is clear and level.

6.3 Power Outlets Not Working

- **Power Connection:** Ensure the workbench's power cord is securely plugged into a working wall outlet.
- **Circuit Breaker:** Check if the power center's integrated circuit breaker (if present) has tripped. Reset if necessary.
- **Overload:** Disconnect some devices to ensure the power center is not overloaded.

7. SPECIFICATIONS

Brand	HuskyTools
Model Number	52 in.
Product Dimensions (Assembled)	55.25 in. W x 24.5 in. D x 37 in. H (with 3.25 in. W handle)
Packaged Dimensions (Approximate)	56.1 in. W x 28.54 in. D x 34.06 in. H
Item Weight (Assembled)	211 lbs (95 kg)
Packaged Weight (Approximate)	290 lbs
Material	Heavy 21-Gauge Steel, 1 in. Thick Solid Wood Top
Finish Type	Steel (Black), Polyurethane Coated Wood
Load Capacity	1,200 lbs
Drawer Slide Rating	100 lbs. (per set of slides)
Casters	5 in. x 2 in. (2 swivel with brake, 2 rigid)
Power Center	6 Outlets, 2 USB Sockets
Assembly Required	Yes

8. WARRANTY INFORMATION

This Husky 52 in. 9-Drawer Mobile Workbench is backed by a **3-year limited warranty**. This warranty covers defects in materials and workmanship under normal use. For specific terms, conditions, and limitations of the warranty, please refer to the warranty card included with your product or contact HuskyTools customer support.

9. CUSTOMER SUPPORT

For assistance with assembly, operation, parts, or warranty claims, please contact HuskyTools customer support:

Website: www.huskytools.com/support (Example URL, please refer to actual product documentation)

Phone: 1-800-XXX-XXXX (Example Number, please refer to actual product documentation)

Email: support@huskytools.com (Example Email, please refer to actual product documentation)

Please have your model number (52 in.) and purchase information ready when contacting support.

© 2023 HuskyTools. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question