



[Manuals.plus](#) /

› [Knobonly](#) /

› Knobonly DL44061-SNBK-LF-10 Privacy Door Handle Instruction Manual

Knobonly DL44061-SNBK-LF-10

Knobonly DL44061-SNBK-LF-10 Privacy Door Handle Instruction Manual

Model: DL44061-SNBK-LF-10

INTRODUCTION

This instruction manual provides detailed guidance for the installation, operation, and maintenance of your Knobonly Satin Nickel Privacy Door Handle. Designed for bedrooms and bathrooms, this interior door lever offers privacy with a keyless turn-button locking mechanism. Please read these instructions carefully before beginning installation to ensure proper function and longevity of your door handle.

SETUP AND INSTALLATION

Before installation, ensure all components are present. The package includes the door handle, latch with removable plate, strike plates, screws, and a wrench. This door handle is designed for easy installation on standard interior doors.

WHAT'S IN BOX

Necessary components are all included
Easy to install



Figure 1: What's in the Box - This image displays all components included in the Knobonly door handle package, such as the levers, latch, strike plates, screws, and wrench.

Door Preparation

- Verify door thickness: This handle fits doors between 1-3/8 inches (35mm) and 1-3/4 inches (45mm) thick.
- Adjust backset: The latch is adjustable for either a 2-3/8 inch (60mm) or 2-3/4 inch (70mm) backset. Adjust the latch as needed before installation.
- The latch plate is removable, allowing for use on doors with either a square or round plate cutout.

Installation Steps

1. Install the latch into the door edge, ensuring the bevel faces the door frame. Secure with screws.
2. Insert the exterior lever assembly through the door, aligning the spindle with the latch mechanism.
3. Place the interior lever assembly onto the door, ensuring proper alignment with the exterior assembly and latch.
4. Secure both lever assemblies together using the provided mounting screws.
5. Test the handle's operation to ensure smooth movement and proper locking.

6. Install the strike plate on the door frame, aligning it with the latch bolt.

For detailed visual instructions, refer to the included installation guide within your product packaging.

OPERATING INSTRUCTIONS

The Knobonly Privacy Door Handle is designed for interior doors requiring a locking mechanism, such as bedrooms and bathrooms. It features a keyless operation.



Figure 2: Privacy Function - This image illustrates the privacy locking mechanism from both the inside (turn thumb) and outside (emergency coin slot).

Locking the Door (Interior Side)

- From the inside of the room, locate the turn-button on the interior lever's rosette.
- Rotate the turn-button to engage the lock. The door is now locked from the outside.

Unlocking the Door

- **From the Interior:** Simply turn the interior lever or rotate the turn-button back to the unlocked position.
- **From the Exterior (Emergency Access):** In case of emergency or accidental lockout, a small slot is present on the exterior rosette. Insert a coin or a flat tool into this slot and turn to unlock the door.

MAINTENANCE

Your Knobonly Privacy Door Handle is constructed from durable materials designed for long-lasting performance. Minimal maintenance is required to keep it in optimal condition.

- **Cleaning:** To clean the satin nickel finish, use a soft, damp cloth. Avoid abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish.
- **Lubrication:** If the lever action becomes stiff over time, a small amount of silicone-based lubricant can be applied to the latch bolt and internal mechanisms. Do not use oil-based lubricants, as they can attract dust and grime.
- **Inspection:** Periodically check all mounting screws for tightness. Loose screws can affect the handle's operation and security.

TROUBLESHOOTING

If you encounter any issues with your Knobonly Privacy Door Handle, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Handle is loose or wobbly.	Mounting screws are loose.	Tighten the mounting screws on both sides of the handle.
Latch bolt does not retract smoothly.	Accumulation of dirt or lack of lubrication.	Clean the latch bolt area and apply a silicone-based lubricant.
Door does not latch or close properly.	Strike plate misalignment or loose strike plate.	Adjust the strike plate position on the door frame or tighten its screws. Ensure the latch bolt fully extends into the strike plate opening.
Privacy lock does not engage or disengage.	Internal mechanism misalignment or damage.	Re-check installation steps. If the issue persists, contact customer support.

If these solutions do not resolve the issue, please contact Knobonly customer support for further assistance.

PRODUCT SPECIFICATIONS

Below are the technical specifications for the Knobonly DL44061-SNBK-LF-10 Privacy Door Handle:

DIMENSIONS

Standard sized match with your old ones for perfectly replacement

Fits doors thickness: 1-3/8 inch to 1-3/4 inch (35mm to 45mm)

Adjustable latch: 2-3/8" to 2-3/4" (60 to 70mm)backset.



Figure 3: Dimensions - This image highlights key dimensions including door thickness compatibility and adjustable backset.

Model Number: DL44061-SNBK-LF-10

Function: Privacy (Bedroom/Bathroom)

Finish: Satin Nickel

Material: Zinc Alloy, Alloy Steel, Stainless Steel

Style: Wave Lever

Adjustable Backset: 2-3/8 inches (60mm) or 2-3/4 inches (70mm)

Door Thickness Compatibility: 1-3/8 inches (35mm) to 1-3/4 inches (45mm)

Rosette Diameter: 2.5 inches (65mm)

Certification: ANSI Grade 3 (Exceeds 200,000 cycles)

UPC: 710328081802

Item Weight (10-Pack): 16.68 pounds

WARRANTY INFORMATION

Knobonly provides a **FREE LIFETIME WARRANTY** for this product. We stand by the quality and durability of our door handles. This product is certified to ANSI Grade 3 standards, exceeding 200,000 cycles of operation, ensuring reliable performance for years to come.

If you experience any quality issues with your Knobonly door handle, please do not hesitate to contact our customer support team. We are committed to resolving any problems within 24 hours and will offer a replacement or refund for any quality-related concerns.

CUSTOMER SUPPORT

For any questions, concerns, or assistance with your Knobonly Privacy Door Handle, please contact our customer support team. We are dedicated to providing prompt and effective solutions.

Contact Method: Please refer to the contact information provided on your product packaging or the official Knobonly website.

Response Time: We aim to respond to all inquiries and resolve issues within 24 hours.

You can also visit the official Knobonly store for more product information and support resources: [Knobonly Store on Amazon](#)