

[Manuals.plus](#) /

› [Pretty Love](#) /

› Pretty Love Zachary Vibrator User Manual - Model 6959532321951

Pretty Love 6959532321951

Pretty Love Zachary Vibrator User Manual

MODEL: 6959532321951

Introduction

Thank you for choosing the Pretty Love Zachary vibrator. This manual provides essential information for the safe and effective use, care, and maintenance of your device. Please read these instructions thoroughly before first use and retain them for future reference.

The Pretty Love Zachary is a classic rabbit-shaped vibrator designed for personal pleasure. It features 12 distinct vibration functions, a flexible shaft for targeted stimulation, and a memory function to recall your last setting. Constructed from body-safe silicone, it is conveniently USB rechargeable.

Package Contents

- Pretty Love Zachary Vibrator
- USB Charging Cable
- User Manual (this document)






Image: The Pretty Love Zachary vibrator displayed in its retail box, highlighting its fuchsia color and key features like 12 functions, memory, silicone material, and USB rechargeability.

Setup

1. **Initial Charge:** Before first use, fully charge the device. Connect the provided USB charging cable to the

charging port on the vibrator and plug the other end into a standard USB power source (e.g., computer USB port, USB wall adapter). The indicator light will typically show charging status (e.g., blinking while charging, solid when fully charged).

2. **Clean Before Use:** Wash the vibrator thoroughly with warm water and a mild, toy-safe soap before its initial use. Rinse completely and allow it to air dry or gently pat dry with a lint-free cloth.






Image: A side profile of the Pretty Love Zachary vibrator, illustrating its classic rabbit design and the smooth texture of its silicone material.

Operating Instructions

1. **Power On/Off:** Press and hold the power button (usually located at the base) for 2-3 seconds to turn the device on or off.
2. **Change Vibration Functions:** Once powered on, short press the power button to cycle through the 12 different vibration patterns and intensities.
3. **Memory Function:** The device will remember the last vibration setting used. When you power it on again, it will start with that setting.
4. **Flexible Shaft:** The main shaft of the vibrator is designed with a bendable spine. Gently flex the shaft to adjust its angle for personalized comfort and targeted stimulation.






Image: A front-side view of the Pretty Love Zachary vibrator, showing its dual stimulators and the location of the control button at the base.

Maintenance and Care

- **Cleaning:** Always clean the vibrator immediately after each use. Wash with warm water and a mild, toy-safe soap. Rinse thoroughly to remove all soap residue.
- **Drying:** Pat dry with a lint-free cloth or allow to air dry completely before storing.
- **Lubricant Compatibility:** Use only water-based lubricants with this silicone product. Oil-based or silicone-based lubricants can damage the silicone material.
- **Charging:** Recharge the device when the battery is low. Avoid overcharging by disconnecting the charger once the battery is full.
- **Storage:** Store the vibrator in a clean, dry, and dust-free place, away from direct sunlight and extreme

temperatures. Keep it separate from other silicone products to prevent material degradation.

Troubleshooting

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device fully using the provided USB cable.
Vibrations are weak or inconsistent.	Low battery.	Recharge the device.
Device does not charge.	Charging cable or port issue.	Ensure the USB cable is securely connected. Try a different USB power source or cable if available.
Material feels sticky or degraded.	Incompatible lubricant used.	Discontinue use if material is compromised. Always use water-based lubricants.

If you encounter issues not listed here, please refer to the support information below.

Specifications

- **Model:** 6959532321951
- **Brand:** Pretty Love
- **Material:** Silicone
- **Color:** Fuchsia
- **Functions:** 12 vibration patterns
- **Power Source:** USB Rechargeable
- **Overall Dimensions:** Approximately 7 inches (17.78 cm)
- **Insertable Length:** Approximately 4 inches (10.16 cm)
- **Diameter:** Approximately 1.3 inches (3.3 cm)
- **Product Dimensions (L x W x H):** 15.75 x 11.81 x 7.87 inches (packaging)
- **Weight:** 8.82 ounces (250 grams)
- **Features:** Bendable spine, Memory function

Warranty and Support

For warranty information or technical support, please contact the retailer or manufacturer directly. Keep your proof of purchase for any warranty claims.

Manufacturer: Liaoyang baile health care produ

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07NLFNXJM>

More documents and user manuals: <https://manuals.plus/>