

[Manuals.plus](#) /

> [Kokido](#) /

> Kokido Robot Manga X Pool Cleaner Instruction Manual

Kokido Manga X

Kokido Robot Manga X Pool Cleaner Instruction Manual

Model: Manga X | Brand: Kokido

1. INTRODUCTION

The Kokido Robot Manga X is an autonomous, cordless robotic pool cleaner designed for efficient cleaning of your pool's bottom. It utilizes advanced Lithium-ion battery technology for reliable performance and an extended lifespan. This manual provides essential information for the safe and effective use, setup, operation, and maintenance of your Manga X pool cleaner.



Figure 1: Kokido Robot Manga X Pool Cleaner. This image shows the overall design of the robotic pool cleaner, highlighting its compact and streamlined form.

2. SAFETY INFORMATION

Please read all safety instructions before operating the device. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Do not operate the cleaner if it or the charger is damaged.
- Ensure the charging port is dry before connecting the charger.
- Keep the cleaner out of reach of children and pets.
- Only use the provided charger for the device.
- Do not attempt to open or repair the battery pack.
- Always remove the cleaner from the pool before adding chemicals or performing maintenance.

3. PACKAGE CONTENTS

Verify that all components are present in the package:

- Kokido Robot Manga X Pool Cleaner Unit
- Battery Charger
- Instruction Manual
- Accessories (located inside the robot unit)



Figure 2: Exploded view of the Kokido Robot Manga X, illustrating its main components and internal accessory storage.

4. SETUP

1. **Initial Battery Charge:** Before first use, fully charge the Lithium-ion battery for approximately 5 to 6 hours. Connect the charger to the robot's charging port and then to a power outlet. The charging indicator will show the charging status.
2. **Accessory Retrieval:** Open the robot unit to retrieve any accessories stored inside. Refer to Figure 2 for component locations.
3. **Placement in Pool:** Once fully charged, carefully place the Manga X cleaner into the pool. Ensure it is fully submerged before operation. The "stop and go" system will activate automatically upon immersion.

5. OPERATION

The Manga X is designed for simple, autonomous operation:

- **Automatic Start/Stop:** The cleaner automatically begins operation once fully immersed in water and stops when removed from the water.
- **Cleaning Cycle:** A full charge provides approximately 80-90 minutes of cleaning time, sufficient for most pool bottoms.
- **Cleaning Pattern:** The robot navigates the pool bottom to collect debris. For optimal cleaning, ensure the pool pump is off during operation to avoid interference with the robot's movement.

No official seller videos demonstrating operation were found in the provided product data.

6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your Manga X pool cleaner.

1. **Filter Cleaning:** After each use, remove the cleaner from the pool and open the unit to access the filter compartment. Clean the filter thoroughly with a water jet to remove collected debris, such as leaves and sand.
2. **Unit Cleaning:** Rinse the exterior of the robot with fresh water to remove any pool chemicals or residue.
3. **Storage:** Store the cleaner in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the battery is charged before long-term storage.



Figure 3: Top view of the Kokido Robot Manga X, indicating the area for filter access and cleaning.

7. TROUBLESHOOTING

If you encounter issues with your Manga X cleaner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cleaner stops unexpectedly or frequently.	Low battery charge, debris clogging, pool pump interference.	Ensure battery is fully charged. Clean the filter compartment. Turn off the pool pump during operation.
Cleaner does not move or clean effectively.	Clogged filter, insufficient charge, unsuitable pool bottom (e.g., steep slopes).	Clean the filter. Recharge the battery. Note that this cleaner is most effective on flat pool bottoms.
Difficulty opening the unit for cleaning.	Mechanism might be stiff or unfamiliar.	Refer to the diagram (Figure 2) for proper opening points. Apply gentle, firm pressure.

8. SPECIFICATIONS

Feature	Detail
Brand	Kokido
Model Name	Manga X
Model Numbers	RC25DIS/CBX/EU, RC25CBX/EU
Product Dimensions (L x W x H)	50L x 20l x 30H centimeters
Item Weight	9.83 Pounds (approx. 4.46 kg)
Power Source	Battery Powered
Special Feature	Cordless
Assembly Required	No

Feature	Detail
Control Method	Touch
Battery Type	Lithium
Charge Time	5 hours
Debris Capacity	1.1 gallons
Load Capacity (Debris)	1.75 kilograms
Country of Manufacture	China

9. WARRANTY AND SUPPORT

The Kokido Robot Manga X comes with a manufacturer's limited warranty of 2 years. For warranty claims, technical support, or further assistance, please contact your retailer or visit the official Kokido website. Keep your proof of purchase for warranty validation.

© 2024 Kokido. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07NLYL964>

More documents and user manuals: <https://manuals.plus/>