



Manuals.plus /

- › Summer Infant /
- › Summer Infant 3Dlite+ Convenience Stroller User Manual

## Summer Infant 3Dlite+

# Summer Infant 3Dlite+ Convenience Stroller User Manual

Model: 3Dlite+

## IMPORTANT SAFETY INFORMATION

---

Please read and understand all instructions before assembling and using your Summer Infant 3Dlite+ Convenience Stroller. Failure to follow these instructions could result in serious injury or death to your child. Keep this manual for future reference.

- Never leave child unattended in the stroller.
- Always use the restraint system.
- Do not carry additional children or bags on the stroller, as this may cause it to become unstable.
- Ensure all locking devices are engaged before use.
- Do not use the stroller if any parts are damaged or missing.
- The maximum weight capacity for this stroller is 50 pounds (22.7 kg).
- The stroller is designed for children from 6 months up to 50 pounds.
- Avoid placing hot liquids in the cup holder.

## PRODUCT OVERVIEW

---

The Summer Infant 3Dlite+ Convenience Stroller is a lightweight and compact stroller designed for ease of use and portability. Key features include a durable aluminum frame, multi-position recline seat, oversized canopy, and convenient storage options.



Image: Front view of the Summer Infant 3Dlite+ Convenience Stroller, showcasing its overall design, canopy, seat, and wheels.

## Components:

- Aluminum Frame
- Multi-position Recline Seat with 5-point Harness
- Oversized Canopy with Flip-out Sun Visor and Peek-a-boo Window
- Parent Cup Holder
- Cell Phone Holder
- Zip-close Storage Pocket
- Child Sippy Cup Holder
- Extra-large Storage Basket
- Anti-shock Front Wheels
- Lockable Rear Wheels
- Padded Carry Strap

## SETUP

---

### 1. Unfolding the Stroller

1. Place the folded stroller on a flat surface.
2. Release the auto-lock mechanism, typically located on the side of the frame.

3. Lift the handle upwards until the frame fully extends and locks into place. You should hear an audible click.
4. Ensure all frame locks are securely engaged before placing a child in the stroller.

lightweight (14 lbs.)  
compact fold




Image: The stroller shown in both its compact folded state and fully unfolded, highlighting its lightweight design and portability.

## 2. Attaching the Canopy

1. Locate the canopy attachment points on the stroller frame, usually near the handles.
2. Slide the canopy clips onto the designated attachment points until they click securely.
3. Extend the canopy forward to provide shade.

## OPERATING THE STROLLER

### 1. Adjusting the Seat Recline

The 3Dlite+ features a one-hand, multi-position adjustable recline seat.

1. Locate the recline lever or strap mechanism on the back of the seat.
2. Squeeze the lever or adjust the strap to move the seat to the desired recline position.
3. Ensure the seat is securely locked in the chosen position before placing your child in it.



Image: A person demonstrating the one-hand recline feature of the stroller seat.

## 2. Securing the Child (5-Point Harness)

1. Place your child in the seat.
2. Bring the shoulder straps over your child's shoulders and the waist straps around their hips.
3. Insert the two buckle prongs into the center buckle until they click.
4. Adjust the straps to ensure a snug fit, leaving enough room for one finger between the strap and your child.

## 3. Using the Canopy

The oversized canopy provides ample shade and features a flip-out sun visor and a peek-a-boo window.

- To extend the canopy, pull it forward.
- For extra sun protection, pull out the integrated sun visor.
- To check on your child, lift the flap on the peek-a-boo window.



extra large canopy  
with pop out sun visor  
& peek-a-boo window



Image: Close-up view of the stroller's oversized canopy, showing the peek-a-boo window and sun visor.

#### 4. Engaging and Disengaging Brakes

The stroller is equipped with lockable rear wheels.

- To engage the brakes, press down firmly on the brake levers located on the rear wheels. Ensure both brakes are engaged.
- To disengage, lift the brake levers upwards.
- Always engage the brakes when the stroller is stationary.

#### 5. Folding the Stroller

The 3Dlite+ features a compact fold with an auto-lock and carry strap.

1. Ensure the seat is in the upright position and the canopy is retracted.
2. Locate the folding mechanism, typically a lever or button on the handle or frame.
3. Follow the specific folding steps for your model (refer to the labels on the stroller if present). This usually involves lifting a secondary lock and pushing the handles forward and down.
4. Once folded, the auto-lock should engage. Use the padded carry strap for easy transport.

#### 6. Using Accessories

The stroller includes a parent cup holder, cell phone holder, zip-close storage pocket, and a child sippy cup holder.

- **Parent Cup Holder & Cell Phone Holder:** Attach these to the designated slots on the stroller handle.

- **Zip-close Storage Pocket:** Located on the back of the canopy for small essentials.
- **Child Sippy Cup Holder:** Attach to the child's side of the stroller frame.
- **Extra-large Storage Basket:** Located under the seat for larger items. Do not exceed the weight limit for the basket.



Image: Close-up views of the stroller's storage pocket, parent cup holder, and cell phone holder.

## MAINTENANCE

---

### Cleaning Instructions:

- **Fabric:** Clean minor stains on fabric components with cold water and mild soap. Allow to air dry completely.
- **Plastic and Metal Surfaces:** Clean with a soft, damp cloth. Air dry.
- **Do Not Use:** Abrasive cleaners, solvents, or bleach on any part of the stroller.

### General Care:

- Regularly check all fasteners, rivets, and connections to ensure they are secure.
- Inspect wheels for wear and tear. Clean any debris from the wheel axles.
- Store the stroller in a dry place, away from direct sunlight and extreme temperatures.

## TROUBLESHOOTING

---

## Common Issues and Solutions:

- **Stroller does not unfold/fold easily:**

Ensure all locks are disengaged before unfolding. For folding, ensure the seat is upright and the canopy is retracted. Check for any obstructions in the folding mechanism. Lubricate moving parts if necessary.

- **Wheels are stiff or squeaky:**

Clean any dirt or debris from the wheel axles. Apply a silicone-based lubricant to the moving parts of the wheels.

- **Harness is difficult to buckle/unbuckle:**

Ensure the buckle prongs are aligned correctly. Clean any debris from the buckle mechanism. Do not force the buckle.

- **Stroller feels unstable:**

Verify that all frame locks are fully engaged. Ensure the maximum weight capacity of 50 lbs is not exceeded. Do not hang heavy bags on the handles.

## SPECIFICATIONS



Image: Diagram illustrating the key dimensions of the Summer Infant 3Dlite+ Stroller.

Feature	Detail
Brand	Summer Infant
Model Number	32743
Color	Matte Black
Material	Aluminum, Fabric (Polyester)
Age Range	Baby (6 months and up)
Maximum Weight Recommendation	50 Pounds (22.7 kg)
Item Weight	14 Pounds (6.35 kg)
Item Dimensions (L x W x H)	33"L x 19.5"W x 43"H (83.8cm L x 49.5cm W x 109.2cm H)
Folded Size	43"L x 12"W x 11"H (109.2cm L x 30.5cm W x 27.9cm H)
Harness Type	5-Point
Number of Cup Holders	2 (Parent & Child)
Safety Standard	ASTM

## WARRANTY AND SUPPORT

---

### Manufacturer's Warranty:

This Summer Infant 3Dlite+ Convenience Stroller is covered by a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, abuse, alteration, improper assembly, negligence, exposure to extreme weather, or normal wear and tear.

### Customer Support:

For warranty claims, replacement parts, or any questions regarding your stroller, please contact Summer Infant customer service. Refer to the contact information provided on the product packaging or the official Summer Infant website.

**Online Resources:** For additional support and product information, visit the Summer Infant Store on Amazon.