Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY RG15D/E-ELL, RG15D/E-ELL1

YING RAY Replacement Remote Control for Frigidaire Window Air Conditioners

Model: RG15D/E-ELL, RG15D/E-ELL1

Introduction

This manual provides instructions for the YING RAY replacement remote control, designed for use with various Frigidaire window air conditioner models. This remote control is a direct replacement and requires no programming. Simply install batteries to begin operation.

Product Overview

The YING RAY replacement remote control offers a user-friendly design with clearly labeled buttons for various air conditioner functions.



Figure 1: Front view of the YING RAY replacement remote control, showing all buttons and the YING RAY logo.



Figure 2: A visual comparison between the original Frigidaire remote control (labeled 'Replace') and the YING RAY replacement remote control (labeled 'We Sell').

Setup and Battery Installation

The YING RAY replacement remote control is designed for immediate use without any programming. Follow these steps to install batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two (2) AAA 1.5V normal batteries, ensuring the correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery compartment cover, ensuring it clicks securely into place.

Note: Batteries are not included with the remote control.



Figure 3: The open battery compartment of the remote control, indicating where to insert AAA 1.5V batteries.

Operation

Once batteries are installed, the remote control is ready to operate your compatible Frigidaire window air conditioner. Point the remote directly at the air conditioner's receiver.

Button Functions:

- **Power Button ( ):** Turns the air conditioner On or Off.
- **Fan Slower (◀):** Decreases the fan speed.
- **Fan Faster (▶):** Increases the fan speed.
- **Cool:** Activates the cooling mode.
- **Fan Only:** Activates the fan-only mode for air circulation without cooling.
- **Auto Fan:** Sets the fan speed to adjust automatically based on room temperature.
- **Temp/Timer (▲/▼):** Adjusts the temperature setting or sets the timer.

- **Energy Saver:** Activates the energy-saving mode.
- **Sleep:** Activates the sleep mode for quiet operation and gradual temperature adjustment.
- **Timer:** Sets or cancels the operational timer.

Compatible Models

This YING RAY replacement remote control is compatible with the following Frigidaire window air conditioner remote control models and part numbers:

- RG15D/E-ELL
- RG15D/E-ELL1
- Part Numbers: 5304476866, 5304487535, 5304501879

It also replaces remotes for various Frigidaire window AC unit models, including but not limited to:

- LRA127CT1
- FFRE08L3Q
- FFRE15L3Q1
- FFRE10L3Q16
- FGRC0644U100
- CRA057XT7 series (e.g., CRA057XT710, CRA057XT711)
- CRA074AT7 series (e.g., CRA074AT70, CRA074AT71)
- CRA087AT7 series (e.g., CRA087AT70, CRA087AT71)
- CRA107BU1 series (e.g., CRA107BU110, CRA107BU111)
- CRA107CT1 series (e.g., CRA107CT10, CRA107CT11)
- CRA127CT1 series (e.g., CRA127CT10, CRA127CT11)
- LRA057XT7 series (e.g., LRA057XT710, LRA057XT711)
- LRA074AT7 series (e.g., LRA074AT70, LRA074AT71)
- LRA087AT7 series (e.g., LRA087AT70, LRA087AT71)
- LRA107BU1 series (e.g., LRA107BU110, LRA107BU111)
- LRA107CT1 series (e.g., LRA107CT10, LRA107CT11)

Specifications

Feature	Detail
Brand	YING RAY
Special Feature	Ergonomic design
Max Number of Supported Devices	1
Compatible Devices	Air Conditioner
Connectivity Technology	Infrared
Controller Type	Button Control
Maximum Range	10 Meters

Battery Type	AAA (1.5V)

Product Video

Watch this video for a visual guide on the YING RAY replacement remote control, including battery installation and a demonstration of its functions.

Your browser does not support the video tag.

Video: Demonstration of the YING RAY replacement remote control, showing its features and how to install batteries.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07NN4QF32

More documents and user manuals: **https://manuals.plus/**