

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Anker](#) /

› [Anker Soundcore Wakey Bluetooth Speaker and Alarm Clock User Manual \(Model AK-A3300111\)](#)

Anker AK-A3300111

Anker Soundcore Wakey Bluetooth Speaker and Alarm Clock User Manual (Model AK-A3300111)

Model: AK-A3300111 | Brand: Anker

INTRODUCTION

The Anker Soundcore Wakey is a versatile bedside device combining a Bluetooth speaker, alarm clock, FM radio, white noise generator, and Qi wireless charger. This manual provides detailed instructions to help you set up and utilize all features of your Soundcore Wakey.



Image: Front view of the Anker Soundcore Wakey, displaying the time and controls.

PACKAGE CONTENTS

Ensure all items are present in the box:

- Soundcore Wakey Bluetooth Speaker
- Power Adapter
- FM Radio Antenna
- Welcome Guide
- 18-Month Warranty Card
- Customer Service Information

SETUP

1. Power Connection

Connect the provided power adapter to the DC 9V port on the back of the Soundcore Wakey, then plug the adapter into a wall outlet. The LED display will illuminate.

2. Time Setting

The Soundcore Wakey's time can be set manually or synchronized via the Soundcore app.

- **Using the Soundcore App:** Download the Soundcore app from your device's app store. Pair your Soundcore Wakey via Bluetooth (see Bluetooth Pairing section). The time on the display will automatically synchronize with your phone's time.
- **Manual Time Setting:** Use the "Time Set" buttons located on the back of the device to adjust the hour and minute.

OPERATING INSTRUCTIONS

1. Bluetooth Pairing

Press the **BT** button on the top panel to enter Bluetooth pairing mode. The display will show "bt". On your mobile device, enable Bluetooth and select "Soundcore Wakey" from the list of available devices to connect. Once connected, you can stream audio wirelessly.

2. FM Radio

Press the **FM** button on the top panel to switch to FM radio mode. Use the **<<** or **>>** buttons to search for stations. You can save up to 10 FM radio stations using the Soundcore app.

3. Alarm Clock

Set up to 15 individual alarms using the Soundcore app. You can choose from 10 unique alarm tones or select an FM radio station as your alarm sound. Use the "Alarm Set" buttons on the back for basic alarm management.

ALARM CLOCK

Set up to 15 alarms.



Image: Close-up of the Soundcore Wakey display showing the time and alarm icon.

4. White Noise Mode

Access the white noise mode via the Soundcore app. Select from 10 different ambient sounds or create a personalized soundscape by mixing your favorites. A timer can be set to help you fall asleep.

WHITE NOISE MODE

Personalize the soundscape
for better rest.



Image: Soundcore Wakey on a nightstand, illustrating its white noise function for sleep.

5. Qi Wireless Charging

Place your Qi-compatible smartphone on the center of the Soundcore Wakey's top panel for fast wireless charging. The charger delivers up to 10W for Samsung devices and 7.5W for iPhones. Ensure no metal objects or phone cases with metal are placed in the charging area.

WIRELESS FAST CHARGING

Charge Qi compatible devices
at up to 10W.



Image: Smartphone wirelessly charging on top of the Soundcore Wakey.

6. Intuitive Controls & Display

The touch bar on the top allows for quick access to Bluetooth connection, FM radio, volume adjustment, and alarm snooze. The LED display features a built-in sensor that automatically adjusts brightness based on ambient light conditions. Brightness can also be manually adjusted or turned off via the Soundcore app or the "Display Dimmer" on the back.

EASY-TO-USE APP



Image: A hand interacting with the Soundcore app on a smartphone, showing alarm settings.

MAINTENANCE

To ensure the longevity of your Soundcore Wakey, keep it clean and dry. Use a soft, dry cloth to wipe the surfaces. Avoid using abrasive cleaners or solvents.

TROUBLESHOOTING

- **No Power:** Ensure the power adapter is securely connected to both the device and a working power outlet.
- **Wireless Charging Not Working:** Verify your phone is Qi-compatible and placed centrally on the charging pad. Remove any metal objects or thick cases.
- **Bluetooth Pairing Issues:** Ensure the Soundcore Wakey is in pairing mode ("bt" flashing) and within range of your device. Forget previous pairings on your device and try again.
- **FM Radio Reception Poor:** Ensure the FM antenna is properly connected and extended. Try repositioning the device for better signal.
- **Alarm Not Sounding:** Check that the alarm is activated in the Soundcore app and the volume is set appropriately.

SPECIFICATIONS

Brand	Anker
Model Number	AK-A3300111
Color	Black
Display Type	Digital
Connectivity Technology	Bluetooth, Wireless
Power Source	Corded Electric
Product Dimensions	7.87"W x 3.23"H
Item Weight	1.19 pounds (540 Grams)
Special Feature	Portable

WARRANTY AND CUSTOMER SUPPORT



The Soundcore Wakey comes with an **18-month warranty**. For any issues or inquiries, please refer to the contact information provided in your welcome guide or visit the official Anker Soundcore support website.

Related Documents - AK-A3300111



[Anker Soundcore mini 2 Portable Bluetooth Speaker User Manual](#)

Comprehensive guide for the Anker Soundcore mini 2 (Model A3107) portable Bluetooth speaker, covering setup, features, safety, and specifications. Learn to connect via Bluetooth or AUX.

	<p>Anker 623 Magnetic Wireless Charger (MagGo) Quick Start Guide</p> <p>Quick start guide for the Anker 623 Magnetic Wireless Charger (MagGo), detailing setup, compatibility with various Apple and Android devices, and usage instructions.</p>
	<p>Anker Soundcore 2 Portable Bluetooth Speaker User Manual and Specifications</p> <p>This user manual provides comprehensive instructions for the Anker Soundcore 2 portable Bluetooth speaker, covering charging, pairing, TWS mode, AUX connection, controls, and detailed specifications. Learn how to use your Soundcore 2 for optimal performance and features.</p>
	<p>Anker Prime Wireless Car Charger User Manual - Fast Charging for iPhone</p> <p>Detailed user manual for the Anker Prime Wireless Car Charger, covering setup, usage, compatibility, troubleshooting, and specifications for iPhone 12 and later models with Qi2 fast charging.</p>
	<p>Anker 315 Wireless Charger (Pad) Safety and Specifications</p> <p>Safety instructions, compliance information, and technical specifications for the Anker 315 Wireless Charger (Pad) Model A2554, supporting up to 10W fast charging.</p>
	<p>Anker Soundcore A3201 Speaker Replacement Guide</p> <p>A comprehensive step-by-step guide from iFixit for disassembling, replacing, and reassembling the internal speakers of the Anker Soundcore A3201 Bluetooth speaker.</p>