



[Manuals.plus](#) /

› [Orium](#) /

› Orium 11276 Claritys Talking Alarm Clock User Manual

Orium 11276

Orium 11276 Claritys Talking Alarm Clock User Manual

Model: 11276

INTRODUCTION

The Orium 11276 Claritys Talking Alarm Clock is designed for ease of use and accessibility, particularly for individuals with visual or hearing impairments. This alarm clock features a clear, loud voice announcement for time and temperature, a large LCD display with high contrast, and adjustable volume. It offers both 12-hour and 24-hour time formats, a programmable alarm, and a snooze function. This manual provides detailed instructions to help you set up and operate your device effectively.



Figure 1: Front view of the Orium 11276 Claritys Talking Alarm Clock showing its large digital display.

SETUP

Powering the Device

The Orium 11276 Talking Alarm Clock can be powered by 2 AA LR06 batteries (not supplied) or via a power adapter (not supplied). For continuous operation, it is recommended to use a power adapter. Batteries provide backup power in case of an outage or for portable use.

Video: This video demonstrates how to power the alarm clock using either a power adapter or by inserting batteries, highlighting its versatility.

Battery Installation

1. Locate the battery compartment on the back of the alarm clock.
2. Open the battery compartment cover.
3. Insert 2 AA LR06 batteries, ensuring correct polarity (+ and -).
4. Close the battery compartment cover securely.



Figure 2: Rear view of the alarm clock, illustrating the battery compartment and control buttons.

Initial Time and Date Setting

To set the current time and date, refer to the control buttons, typically located on the side or back of the device. The specific buttons for setting hours, minutes, day, month, and year are usually marked with icons or labels.

Video: This video provides a visual guide on how to set the time and date on a talking clock, which is applicable to this model.

OPERATING INSTRUCTIONS

Announcing Time and Temperature

Press the designated button (often a large, prominent button) to hear the current time and temperature announced aloud. The clock will speak the time in French and the temperature in Celsius.

Video: A short demonstration of the talking function, announcing the time in French.

Adjusting Volume

The volume of the voice announcement can be adjusted using the ergonomic wheel or dedicated buttons, typically located on the side or back of the device. The volume range is from 68 dB to 85 dB.

Setting Alarm and Snooze Function

1. To set the alarm, locate the alarm setting buttons (often marked with a bell icon).
2. Follow the on-screen prompts or refer to the specific button functions to set your desired alarm time.
3. Activate the alarm using the alarm ON/OFF switch.
4. When the alarm sounds, press the large button on top to activate the snooze function, which will temporarily silence the alarm for a short period before it sounds again.

12-Hour / 24-Hour Format

The clock supports both 12-hour (AM/PM) and 24-hour time formats. Use the dedicated switch or button to toggle between these two display modes, usually found on the back or side of the unit.

Video: This video illustrates how to switch between 12-hour and 24-hour time formats on a talking clock.

Night Mode / Display Brightness

The LCD screen is backlit for optimal contrast. To avoid disturbance during the night, you can often adjust the display

brightness or turn off the backlight completely using a dedicated switch or button. The talking function will still operate normally even with the display off.




Figure 3: The alarm clock displayed in a low-light environment, demonstrating its night visibility.

MAINTENANCE

To ensure the longevity and proper functioning of your Orium 11276 Claritys Talking Alarm Clock, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the alarm clock. Avoid using abrasive cleaners or solvents, as they may damage the surface.
- **Battery Replacement:** Replace batteries promptly when the display dims or the voice announcement becomes unclear. Always use new batteries of the specified type (2 AA LR06).
- **Storage:** If storing the alarm clock for an extended period, remove the batteries to prevent leakage and potential damage to the device.

TROUBLESHOOTING

If you encounter any issues with your Orium 11276 Claritys Talking Alarm Clock, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound or low volume	Volume is set too low or batteries are weak.	Adjust the volume using the control wheel/buttons. Replace batteries if necessary. Ensure the environment is quiet for better audibility.
Incorrect time/date displayed	Time/date was not set correctly or batteries were removed/draind.	Re-set the time and date following the 'Initial Time and Date Setting' instructions.

Problem	Possible Cause	Solution
Display is dim or blank	Batteries are low, night mode is active, or power adapter is disconnected.	Replace batteries. Check night mode settings. Ensure power adapter is securely connected.
Alarm does not sound	Alarm is not activated or set incorrectly.	Ensure the alarm is switched ON and the alarm time is correctly set.

SPECIFICATIONS

Feature	Detail
Model Number	11276
Dimensions (L x W x H)	16 x 6.5 x 6 cm
Weight	180 grams
Brand	Orium
Color	Black
Display Type	Digital (LCD, backlit)
Special Features	Temperature display, Alarm, Large digits, Talking function
Power Source	Battery powered (2 x AA LR06, not included)
Volume Range	68 dB to 85 dB
Time Format	12H/24H selectable
Material	Acrylonitrile Butadiene Styrene

WARRANTY AND SUPPORT

This Orium product is covered by a standard manufacturer's warranty. For specific warranty details, please refer to the documentation included with your purchase or contact Orium customer support. If you require further assistance or have questions not covered in this manual, please reach out to the manufacturer's support channels.