

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Brabantia](#) /

› [Brabantia Bo Touch Top Kitchen Trash Can \(Model 221408\) Instruction Manual](#)

Brabantia 221408

Brabantia Bo Touch Top Kitchen Trash Can Instruction Manual

Model: 221408 | Brand: Brabantia

INTRODUCTION

Thank you for choosing the Brabantia Bo Touch Top Kitchen Trash Can. This manual provides essential information for the safe and efficient use of your new waste separation solution. This model features two 8-gallon inner buckets, a soft-touch opening system, and a space-saving design.

SAFETY INFORMATION

- Keep the product away from children and pets to prevent accidents.
- Do not overload the inner buckets beyond their capacity.
- Ensure the trash can is placed on a stable, flat surface.
- Avoid placing hot ashes or flammable materials directly into the bin.
- Do not stand or sit on the trash can.

PACKAGE CONTENTS

Your Brabantia Bo Touch Top Kitchen Trash Can package should include:

- 1 x Brabantia Bo Touch Top Trash Can (White)
- 2 x Removable Inner Buckets (8 Gallons each)
- 1 x Sample Pack of Brabantia PerfectFit Trash Bags (Code O)

SETUP

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future transport or returns if necessary.
2. **Placement:** Position the trash can in your desired location. Its flat back design allows it to fit closely against a wall or in a corner.

3. **Insert Inner Buckets:** Place the two removable inner buckets into the main body of the trash can. Ensure they are seated correctly.
4. **Insert Trash Bags:** Use the provided sample pack of Brabantia PerfectFit (Code O) trash bags. Open a bag and fit it around the rim of one inner bucket. Repeat for the second bucket.





Image: The Brabantia Bo Touch Top Trash Can with its lid open, revealing the two inner buckets ready for use.

OPERATING INSTRUCTIONS

1. **Opening the Lid:** The Bo Touch Top features a soft-touch opening system. Gently press the center of the lid to open it. The lid will stay open until you manually close it.
2. **Disposing of Waste:** Place your waste into the appropriate inner bucket. This model is designed for waste separation, allowing you to sort trash and recycling easily.
3. **Closing the Lid:** Gently push the lid down until it clicks into place. The soft-close mechanism ensures a smooth and quiet closure.
4. **Removing Inner Buckets:** To empty or clean, simply lift the inner buckets out using their integrated handles.



Image: A hand demonstrating the soft-touch opening mechanism of the trash can.



Image: An inner bucket being removed from the trash can for emptying or cleaning.

Official Product Video: Bo Touch Bin Overview

Your browser does not support the video tag.

Video: This video provides a comprehensive overview of the Brabantia Bo Touch Bin, showcasing its features like the soft-touch opening, waste separation options, and design.

MAINTENANCE & CLEANING

- **Exterior Cleaning:** Wipe the exterior of the trash can with a soft, damp cloth and a mild detergent. Avoid abrasive cleaners or scouring pads, which can damage the finish.
- **Inner Buckets:** The removable plastic inner buckets can be washed with warm soapy water. Rinse thoroughly and dry before placing them back into the trash can.
- **Lid Cleaning:** The entire lid can be removed for easier cleaning. Wipe it down with a damp cloth and mild detergent.
- **Regular Care:** For optimal hygiene, clean the trash can regularly, especially after emptying.

TROUBLESHOOTING

Problem	Solution
Lid not opening/closing smoothly.	Check for any obstructions around the lid mechanism. Ensure the lid is properly aligned. Clean any debris from the hinge area.
Inner buckets are difficult to remove or insert.	Ensure the buckets are correctly aligned with the grooves inside the main body. Do not force them.
Trash bags do not fit properly.	Use Brabantia PerfectFit trash bags (Code O) for this model. These are designed to fit perfectly without unsightly overhang.
Trash can is unstable.	Ensure the trash can is placed on a level surface. The non-skid base should provide stability.

SPECIFICATIONS

Feature	Detail
Brand	Brabantia
Model Number	221408
Capacity	16 Gallons (2 x 8 Gal inner buckets)
Color	White
Opening Mechanism	Press-Top (Soft-Touch)
Material	Plastic
Product Dimensions (LWH)	21.5"L x 12.3"W x 25.8"H
Item Weight	16.2 Pounds
Special Features	2 Removable Buckets, Ideal for waste separation, Light touch opening, Non-Scratch/Slip base, Soft-closing lid
Sustainability	Cradle-to-Cradle certified (Bronze level), made from 25% recycled material, 98% recyclable after use.



Image: Technical drawing illustrating the dimensions of the trash can (545mm L x 312mm W x 665mm H, 889mm with lid open).

WARRANTY & SUPPORT

The Brabantia Bo Touch Top Kitchen Trash Can comes with a **10-year guarantee**, reflecting its sustainable quality and durability.

For product support, spare parts, or warranty claims, please visit the official Brabantia website or contact their customer service directly. Ensure you have your model number (221408) and proof of purchase available.

Official Product Video: Brabantia Trash Cans - Designed for Living

Your browser does not support the video tag.

Video: This video highlights the design philosophy of Brabantia trash cans, emphasizing their integration into daily life and home aesthetics.