

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Polly Pocket](#) /

› [Polly Pocket Pollyville Pocket House Playset Instruction Manual](#)

Polly Pocket GFP42

Polly Pocket Pollyville Pocket House Playset Instruction Manual

Brand: Polly Pocket | Model: GFP42

1. INTRODUCTION

Welcome to Pollyville! The Polly Pocket Pollyville Pocket House Playset offers a miniature world of adventure and imaginative play. This playset is designed to provide a fun and interactive experience with multiple rooms, accessories, and transforming features.

This manual provides essential information for setting up, operating, and maintaining your playset. Please read it thoroughly before use.

2. SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small Parts. Not for children under 3 years.

- Always supervise young children during play.
- Keep small accessories away from infants and toddlers to prevent choking.
- Inspect the playset regularly for any damaged parts. Discontinue use if damage is found.

3. WHAT'S IN THE Box

Your Pollyville Pocket House Playset includes the following components:

- 1 x Pollyville Pocket House Playset
- 1 x Micro Polly doll
- 1 x Paxton Pocket doll
- 1 x Peaches the dog figure
- 1 x Trampoline
- 1 x Toy Bike with baby seat
- 1 x Rocking horse
- 1 x Paxton's high chair
- 1 x Table
- 2 x Chairs

- 1 x Couch
- 1 x Peaches' doghouse
- Additional furniture and accessories (11 total)
- 1 x Sticker sheet with Polly Stick technology



Figure 1: All included accessories for the Polly Pocket Pollyville Pocket House Playset.

4. SETUP INSTRUCTIONS

Follow these steps to set up your Pollyville Pocket House Playset:

1. **Unpack Components:** Carefully remove all items from the packaging. Ensure all listed accessories are present.
2. **Unfold the House:** The playset is designed to fold for storage. Gently unfold the house to reveal its full four stories and five rooms. The side kitchen area also extends outwards.
3. **Place Accessories:** Arrange the furniture and accessories within the house as desired. For example, place the rocking horse and crib in Paxton's room, the bed and laptop in Polly's bedroom, and the bathtub in the bathroom.
4. **Apply Stickers:** Use the included sticker sheet with Polly Stick technology to place stickers on various surfaces. These stickers allow Polly and friends to stick to the playset for enhanced play.

House extends up and sideways!




Figure 2: The Pollyville Pocket House Playset extends to reveal multiple play areas.

5. OPERATING INSTRUCTIONS

Explore the interactive features of your Pollyville Pocket House:

- **Dance Floor:** Place a micro doll on the dance floor in the living room and spin it for dancing action.
- **Trampoline:** Position a micro doll on the trampoline and gently press down to make it bounce.
- **Toy Bike:** Insert Polly doll's feet into the bicycle pedals. Push the bike forward to make the doll move as if riding. The bike includes a baby seat for Paxton.
- **Crib Feature:** The crib in Paxton's room can be flipped down for interactive play.
- **Kitchen Fridge:** The refrigerator door in the kitchen can be opened and closed.



POLLY™ spins on the dance floor!

Figure 3: Polly doll can spin on the dance floor.



Figure 4: Polly doll can ride the toy bike, which includes a baby seat.



Figure 5: The crib in Paxton's room features a flip-down function.

Official Product Video

Your browser does not support the video tag.

Video 1: Official demonstration of the Pollyville Pocket House playset, showcasing its various features and play possibilities.

Additional Product Video

Your browser does not support the video tag.

Video 2: A detailed review and demonstration of the Polly Pocket Micro Pollyville Pocket House, along with other Pollyville vehicles, highlighting its features and play value.

6. MAINTENANCE

To ensure the longevity of your playset:

- **Cleaning:** Wipe the playset and accessories with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, fold the playset back into its compact form. Store all micro dolls and accessories inside the house or in a designated container to prevent loss.



Figure 6: The playset folds into a compact house for easy storage.

7. TROUBLESHOOTING

If you encounter any issues with your playset, consider the following:

- **Missing Pieces:** Refer to the 'What's in the Box' section to confirm all components. Contact customer support if essential pieces are missing.
- **Stickers Not Sticking:** Ensure the playset surfaces are clean and dry before applying stickers. If dolls are not sticking, ensure their feet are clean and the sticker surface is intact.
- **Moving Parts Stiff:** Gently operate moving parts (e.g., folding sections, dance floor) to loosen them. Do not force any parts.

8. SPECIFICATIONS


Model Number	GFP42
Product Dimensions	7.09 x 4.72 x 4.33 inches
Item Weight	1.1 pounds
Manufacturer Recommended Age	4 years and up
Manufacturer	Mattel


9. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the manufacturer's official website or contact their customer service department directly. Keep your proof of purchase for any warranty claims.

© 2023 Polly Pocket. All rights reserved.

Related Documents - GFP42

	<p>XtremePower US 40cc Pocket Bike Owner's Manual & Safety Instructions Models 99701, 99703, 99706</p> <p>Comprehensive owner's manual and safety instructions for the XtremePower US 40cc Pocket Bike, covering operation, maintenance, parts, and safety warnings. Includes models 99701, 99703, 99706.</p>
	<p>FRP G0001 Off Road Pocket Bike User Manual: Safety, Operation, and Maintenance</p> <p>This user manual provides essential information for the FRP G0001 Off Road Pocket Bike, covering safe operation, pre-ride checks, starting procedures, controls, adjustments, maintenance schedules, troubleshooting, and warranty details.</p>
	<p>XtremepowerUS Mini Bike Assembly and Operation Guide</p> <p>Detailed assembly instructions and operation guide for the XtremepowerUS Mini Bike, covering unpacking, front fork and handlebar assembly, fender and wheel installation, oiling, and starting procedures.</p>
	<p>Pegasus Astro Pocket Powerbox Micro Quick Installation Guide</p> <p>This guide provides quick installation instructions for the Pegasus Astro Pocket Powerbox Micro, a device designed for astrophotographers offering 10Amps of power, multiple 12V outputs, dew heater channels, adjustable voltage, and an environmental sensor.</p>
	<p>Chicco Polly Magic Relax High Chair User Manual</p> <p>Comprehensive instructions for the Chicco Polly Magic Relax high chair, covering assembly, usage, safety, cleaning, and maintenance for both the high chair and recliner modes.</p>



[Chicco Polly Highchair Owner's Manual: Assembly, Use, and Care](#)

Comprehensive owner's manual for the Chicco Polly Highchair, providing detailed instructions on assembly, safe usage, adjustments, cleaning, and maintenance. Learn how to use the safety harness, adjust height and recline, and store the highchair.