Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DISNEY B07NR8V47H

Breakthrough DVD User Manual

Model: B07NR8V47H

Introduction

This manual provides essential information for the proper use and care of your Breakthrough DVD. Breakthrough is a compelling film based on the incredible true story of Joyce Smith's unwavering faith and the miraculous recovery of her adopted son, John, after a tragic accident. This DVD offers an enthralling viewing experience for audiences.




Image: Front cover of the Breakthrough DVD. The cover features a young man kissing a woman on the cheek, with a bright light shining down on a person in water below, symbolizing the film's theme of hope and recovery.

Getting Started

1. Connecting Your DVD Player

Ensure your DVD player is correctly connected to your television or display device. Typically, this involves using an HDMI cable for high-definition output, or RCA cables (red, white, and yellow) for standard definition. Refer to your DVD player's instruction manual for specific connection details.

2. Inserting the DVD

1. Gently open the DVD tray or slot on your DVD player.
2. Hold the Breakthrough DVD by its edges to avoid touching the playback surface.
3. Place the DVD into the tray or slot with the label side facing up.
4. Close the DVD tray or allow the player to draw the disc in.

Playback Instructions

1. Playing the Movie

Once the DVD is loaded, the player will typically display the main menu. Use your DVD player's remote control to navigate the menu. Select "Play Movie" or a similar option to begin watching Breakthrough.

2. Navigating Menus and Chapters

- Use the **arrow keys** on your remote to move between menu options.
- Press **Enter** or **OK** to select an option.
- To access specific scenes, select "Scene Selection" or "Chapters" from the main menu.
- Use the **"Menu"** button on your remote to return to the main menu at any time during playback.

3. Language and Subtitle Selection

The Breakthrough DVD supports multiple audio languages and subtitles. To change these settings:

- From the main menu, select "Audio" or "Languages" to choose your preferred audio track (e.g., English, French, Spanish).
- Select "Subtitles" or "Captions" to enable or disable subtitles and choose your preferred language.
- Some DVD players also allow you to change these settings during playback using dedicated buttons on the remote (e.g., "Audio," "Subtitle," or "CC").

Care and Maintenance

Proper care of your DVD will ensure its longevity and optimal playback quality.

1. Handling the Disc

- Always hold the DVD by its outer edges or by placing a finger through the center hole.
- Avoid touching the shiny playback surface to prevent fingerprints and scratches.

2. Cleaning the Disc

- If the disc becomes dirty, gently wipe it with a soft, lint-free cloth.
- Wipe from the center of the disc outwards in a straight line, not in a circular motion.
- For stubborn smudges, slightly dampen the cloth with water or a specialized disc cleaning solution. Do not use abrasive cleaners or solvents.

3. Storage

- Store the DVD in its original case when not in use to protect it from dust, scratches, and direct sunlight.
- Keep the DVD in a cool, dry place away from extreme temperatures and humidity.

Troubleshooting

If you encounter issues while playing your Breakthrough DVD, try the following solutions:

- **Disc Not Playing/Reading:**
  - Ensure the disc is inserted correctly with the label side facing up.
  - Check the disc for visible scratches, smudges, or dirt. Clean the disc as described in the "Care and Maintenance" section.
  - Try playing another DVD to determine if the issue is with the player or the disc.
  - Restart your DVD player by unplugging it from the power outlet for a few minutes, then plugging it back in.
- **No Audio or Video:**
  - Verify that all cables connecting your DVD player to your TV are securely attached.
  - Check your TV's input/source setting to ensure it is set to the correct input for your DVD player.
  - Adjust the volume on your TV and DVD player.
  - Ensure the correct audio track is selected from the DVD menu (see "Language and Subtitle Selection").
- **Skipping or Freezing:**
  - Clean the disc thoroughly, as dirt or fingerprints are common causes of skipping.
  - Inspect the disc for deep scratches. Severe scratches may prevent proper playback.
  - Ensure the DVD player is on a stable, level surface to prevent vibrations.

If problems persist, consult your DVD player's manual or contact the manufacturer of your DVD player for further assistance.

Specifications

Feature	Detail
Title	Breakthrough
Format	DVD, NTSC, Subtitled
ASIN	B07NR8V47H
Director	Roxann Dawson
Actors	Chrissy Metz, Topher Grace, Josh Lucas, Mike Colter, Rebecca Staab
Studio	DISNEY
Release Date	July 16, 2019
MPAA Rating	PG (Parental Guidance Suggested)
Aspect Ratio	2.39:1
Dubbed Languages	French, Spanish
Original Language	English

Number of Discs	1
Product Dimensions	0.7 x 7.5 x 5.4 inches; 2.08 ounces
Genre	Drama, Drama/Religion

Support

For questions regarding the content of the film or general inquiries about Disney products, please visit the official Disney website or contact their customer support. For technical issues related to DVD playback, please refer to your DVD player's manufacturer support resources.

You can find more information about the film here.

© 2025 DISNEY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07NR8V47H

More documents and user manuals: **https://manuals.plus/**