



Manuals.plus /

› Growsland /

› Growsland 1:18 Scale Remote Control Car Model RCY1114 Instruction Manual

## Growsland RCY1114

# Growsland 1:18 Scale Remote Control Car

MODEL: RCY1114

User Instruction Manual

<a href="#">Safety Information</a>	<a href="#">Package Contents</a>	<a href="#">Setup</a>	<a href="#">Operation</a>	<a href="#">Maintenance</a>	<a href="#">Troubleshooting</a>
<a href="#">Specifications</a>					

### INTRODUCTION

Thank you for choosing the Growsland 1:18 Scale Remote Control Car. This manual provides essential information for the safe and effective use of your new toy. Please read it thoroughly before operating the product and retain it for future reference.



*Image: The Growsland 1:18 Scale Remote Control Car in yellow, shown with its remote control and product packaging.*

## **SAFETY INFORMATION**

This product is designed for children aged 36 months to 12 years. Adult supervision is recommended during operation. Always ensure the play area is clear of obstacles and hazards. Do not operate near water or in wet conditions. Keep fingers, hair, and loose clothing away from moving parts. Do not attempt to modify the product or its components.

## **PACKAGE CONTENTS**

Please check the package to ensure all items are present:

- 1 x Remote Control Car (Model RCY1114)
- 1 x Remote Control
- 1 x Screwdriver

- 1 x Instruction Manual

## PACKAGE LIST



- 1\*Remote Control car**
- 1\*Remote Control**
- 1\*Screwdriver**
- 1\*Instruction manual**



*Image: The package contents laid out, showing the yellow remote control car, remote, screwdriver, and instruction manual.*

## SETUP

### 1. Battery Installation (Car):

Locate the battery compartment on the underside of the car. Use the provided screwdriver to open the battery cover. Insert 4 'AA' batteries (not included) into the compartment, ensuring correct polarity. Close the cover and secure it with the screw.



Image: The underside of the car showing the battery compartment and the remote control with its battery slot.

## 2. Battery Installation (Remote Control):

Locate the battery compartment on the back of the remote control. Use the provided screwdriver to open the battery cover. Insert 2 'AA' batteries (not included) into the compartment, ensuring correct polarity. Close the cover and secure it with the screw.

## 3. Power On:

Turn on the remote control using its power switch. Then, turn on the car using the ON/OFF switch located on its underside. The car and remote should automatically pair.

## 4. Steering Adjustment:

If the car does not drive straight, use the steering trim adjustment on the underside of the car (near the front wheels) to fine-tune its direction.

## OPERATING INSTRUCTIONS

The Growsland RC Car is designed for easy operation with its intuitive remote control.

### 1. Basic Controls:

Use the left joystick on the remote for Forward/Reverse movement. Use the right joystick for Left/Right steering.

### 2. Headlights:

The car features bright LED headlights that illuminate when driving forward, enhancing visibility and realism.

## **1** Bright Led Headlights

*Dazzling headlights glowing in the dark.*



## **2** Frosted Car Paint

*With intricate details, highlight its great texture.*

## **3** High-Quality Rubber Wheels

*Anti-slip and wear-resistant rubber tires can generate considerable grip on the ground to avoid slipping.*



*Image: Detailed view of the car's features, including LED headlights and rubber wheels.*

### **3. Driving on Various Terrains:**

The car is suitable for indoor use on smooth surfaces like floors and can also operate on low-pile carpets. Performance may vary on different surfaces.



*Image: The RC car demonstrating its ability to drive on various indoor terrains.*

#### 4. **Control Distance:**

The 40MHz controller provides a sufficient range for indoor play. Note that multiple cars operating on the same frequency in close proximity may experience interference.

### **Operation Videos**

Your browser does not support the video tag.

*Video: An official Growsland video demonstrating the remote control car's features and operation.*

Your browser does not support the video tag.

*Video: A short preview showing a child operating the remote control car outdoors, highlighting its speed and maneuverability.*

Your browser does not support the video tag.

*Video: A user-submitted preview demonstrating the car's indoor performance and ease of use, including its headlights.*

### **MAINTENANCE**

- **Cleaning:** Wipe the car and remote control with a soft, dry cloth. Do not use water or chemical

cleaners, as this may damage electronic components.

- **Battery Care:** Always remove batteries from both the car and the remote control when not in use for extended periods to prevent leakage and damage.
- **Storage:** Store the product in a cool, dry place away from direct sunlight and extreme temperatures.

## TROUBLESHOOTING

- **Car not responding:**  
Ensure both the car and remote control have fresh batteries and are switched ON. Check that the remote control's antenna is extended.
- **Car not driving straight:**  
Use the steering trim adjustment on the underside of the car to correct its alignment.
- **Interference with other RC cars:**  
The car operates on a 40MHz frequency. If multiple cars are used in close proximity, they may interfere with each other. Try operating them one at a time or in separate areas.
- **Poor performance on carpet:**  
While the car can operate on carpet, its speed and maneuverability may be reduced compared to smooth surfaces.

## SPECIFICATIONS

Feature	Detail
Model Number	RCY1114
Scale	1:18
Product Dimensions	10 x 4.3 x 2.2 inches
Item Weight	8.5 ounces
Recommended Age	36 months - 12 years
Car Batteries	4 x AA batteries (not included)
Remote Batteries	2 x AA batteries (not included)
Control Frequency	40MHz

## WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the contact details provided on the product packaging or visit the official Growsland website. Keep your purchase receipt as proof of purchase.