

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

- › [LEGO](#) /
- › LEGO Jurassic World T. rex vs Dino-Mech Battle 75938 Instruction Manual

LEGO 75938

LEGO Jurassic World T. rex vs Dino-Mech Battle 75938 Instruction Manual

Model: 75938 | Brand: LEGO

1. INTRODUCTION

Welcome to the instruction manual for your LEGO Jurassic World T. rex vs Dino-Mech Battle 75938 building set. This guide provides essential information for the assembly, operation, and care of your new LEGO model. Please read through these instructions carefully to ensure a complete and enjoyable building experience.



Image 1.1: The packaging for the LEGO Jurassic World T. rex vs Dino-Mech Battle 75938 set, showing the T. rex, Dino-Mech, volcanic rock, and boat.

2. PRODUCT OVERVIEW

The LEGO Jurassic World T. rex vs Dino-Mech Battle 75938 set allows for the construction of several detailed models and includes multiple minifigures and accessories. The set contains 716 pieces designed for building and imaginative play.

2.1 Main Components:

- **Buildable T. rex Figure:** A posable T. rex dinosaur with snapping jaws.
- **Buildable Dino-Mech:** A large, posable mechanical dinosaur with snapping jaws, designed for a minifigure pilot.
- **Buildable Volcanic Rock:** Features an opening function to reveal a hidden treasure chest.
- **Boat:** Equipped with two stud shooters and a tranquilizer gun.
- **Minifigures:** Includes Owen Grady, Claire Dearing, Vic Hoskins, and Danny Nedermeyer.
- **Baby Velociraptor Figures:** Four figures named Blue, Delta, Echo, and Charlie.



Image 2.1: The fully assembled LEGO set, showcasing the T. rex, Dino-Mech, volcanic rock, and boat with minifigures.

3. SETUP AND ASSEMBLY

Assembly of the LEGO Jurassic World T. rex vs Dino-Mech Battle 75938 set is a step-by-step process. The set includes detailed, illustrated building instructions that guide you through constructing each component.

3.1 Assembly Process:

1. **Unpack Components:** Carefully open the box and sort the LEGO bricks into their numbered bags.
2. **Follow Instructions:** Refer to the included instruction booklets. Each booklet typically corresponds to a specific numbered bag or section of the model.
3. **Connect Bricks:** Ensure bricks are firmly pressed together to create stable connections.
4. **Verify Steps:** Double-check each step against the illustrations to prevent errors.
5. **Complete Each Model:** Build the T. rex, Dino-Mech, volcanic rock, and boat sequentially as indicated in the instructions.

For optimal results, it is recommended to build on a clean, flat surface to prevent loss of small pieces.

4. OPERATING AND PLAY FEATURES

Once assembled, the LEGO Jurassic World T. rex vs Dino-Mech Battle set offers various interactive features for engaging play.

4.1 Interactive Elements:

- **Posable Figures:** Both the T. rex and Dino-Mech feature articulated joints, allowing for dynamic poses and battle scenes. Their jaws can be opened and closed.
- **Volcano Treasure Hunt:** The volcanic rock includes a mechanism to open and reveal a hidden treasure chest, adding an element of discovery to play.
- **Boat Action:** The boat is equipped with two stud shooters for projectile play and a tranquilizer gun for minifigure interaction.
- **Minifigure and Dinosaur Role-Play:** Utilize the included minifigures and baby velociraptors to recreate scenes or invent new adventures within the Jurassic World setting.



Image 4.1: An example of interactive play with the LEGO T. rex and Dino-Mech figures.



5. MAINTENANCE

Proper care ensures the longevity and cleanliness of your LEGO bricks.

5.1 Cleaning Instructions:

- **Gentle Cleaning:** Clean LEGO bricks using a mild soap solution and lukewarm water (not exceeding 40°C or 104°F).
- **Avoid Harsh Chemicals:** Do not use hot water, harsh detergents, or abrasive cleaners, as these can damage the plastic.
- **Air Dry:** Allow bricks to air dry completely at room temperature. Avoid direct sunlight or high heat.

5.2 Storage:

Store your LEGO set in a clean, dry place away from direct sunlight and extreme temperatures to prevent discoloration or warping of the plastic.

6. TROUBLESHOOTING

Should you encounter any issues with your LEGO set, please refer to the following common solutions.

6.1 Missing Pieces:

If you find that a piece is missing from your new set, please visit the official LEGO Customer Service website to request replacement parts. Ensure you have the set number (75938) available.

6.2 Difficulty Connecting Bricks:

Ensure you are using the correct bricks as indicated in the instruction manual. Apply firm, even pressure when connecting bricks. If a brick is consistently difficult to connect, verify it is not damaged or warped.

7. SPECIFICATIONS

Feature	Detail
Product Name	LEGO Jurassic World T. rex vs Dino-Mech Battle
Model Number	75938
Item Model Number (Internal)	6278191
Number of Pieces	716
Product Dimensions	21.26 x 11.1 x 3.09 inches
Item Weight	3.52 ounces
Manufacturer Recommended Age	8 years and up
Release Date	August 1, 2019
Manufacturer	LEGO

8. WARRANTY AND SUPPORT

LEGO products are manufactured to high-quality standards. For information regarding product warranty, missing parts, or any other support needs, please visit the official LEGO website or contact their customer service directly.

Official LEGO Website: www.lego.com

LEGO is committed to providing excellent customer service and ensuring satisfaction with their products.