

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Geberit](#) /

› [Geberit Sigma20 Dual Flush Actuator Plate \(Model 115.882.JQ.1\) Instruction Manual](#)

### Geberit 115.882.JQ.1

# Geberit Sigma20 Dual Flush Actuator Plate Instruction Manual

Model: 115.882.JQ.1



## 1. INTRODUCTION

This manual provides essential information for the installation, operation, and maintenance of your Geberit Sigma20 Dual Flush Actuator Plate. The Geberit Sigma20 actuator plate is designed for use with Geberit Sigma flush boxes, enabling a two-volume flushing system. It features front operation and sound-insulated push rods for quiet and efficient use.



Figure 1: Geberit Sigma20 Dual Flush Actuator Plate, showing the two circular buttons for dual flush functionality and a matt chrome finish with bright chrome-plated design strips.

## 2. PRODUCT FEATURES

---

- Designed for flush release with Geberit Sigma cisterns.
- Supports two-volume flushing for water conservation.
- Features sound-insulated push rods for quiet operation.
- Tool-free quick adjustment mechanism for simplified installation.
- Matt chrome-coated plate with easy-to-clean surface.
- Bright chrome-plated design strips for aesthetic appeal.

## 3. PACKAGE CONTENTS

---

Please verify that all components are present before beginning installation:

- Geberit Sigma20 Actuator Plate
- Mounting Frame
- 2 Spacer Bolts
- 2 Push Rods

## 4. SPECIFICATIONS

---

Attribute	Detail
Model Number	115.882.JQ.1
Brand	Geberit
Material	Plastic
Color	Matt Chrome-coated (Plate), Bright Chrome-plated (Strips)
Product Dimensions (W x H x D)	24.6 x 16.4 x 1.5 cm (9.69 x 6.46 x 0.59 inches)
Item Weight	392 Grams (13.8 ounces)
Actuation Force	< 20 N
Item Package Quantity	1
Global Trade Identification Number (GTIN)	04025416352440




Figure 2: Dimensional drawing of the Geberit Sigma20 Actuator Plate, indicating a width of 24.6 cm and a height of 16.4 cm.

## 5. SETUP AND INSTALLATION

The Geberit Sigma20 Actuator Plate is designed for straightforward installation with Geberit Sigma flush boxes. It operates from the front, allowing for easy access and adjustment.

### 5.1 General Installation Principles

1. Ensure the Geberit Sigma flush box is correctly installed and accessible.
2. Attach the provided mounting frame to the flush box according to the flush box's specific instructions.
3. Insert the spacer bolts into the designated positions on the mounting frame.
4. Connect the push rods to the flush mechanism within the cistern. The push rods are sound-insulated and feature tool-free quick adjustment.
5. Carefully align and attach the Sigma20 actuator plate to the mounting frame, ensuring the push rods engage correctly with the plate's buttons.
6. Secure the actuator plate in place.

**Important:** For detailed, step-by-step installation instructions, always refer to the specific installation guide provided with your Geberit Sigma flush box. If you are unsure about any part of the installation process, it is recommended to consult a qualified professional.



Figure 3: The Geberit Sigma20 Actuator Plate shown installed on a dark marble-patterned wall in a contemporary bathroom setting, demonstrating its integrated appearance.

## 6. OPERATING INSTRUCTIONS

The Geberit Sigma20 Actuator Plate features a dual flush mechanism, allowing you to choose between a full flush and a reduced flush volume for water efficiency.

## 6.1 Dual Flush Functionality

- **Full Flush:** Press the larger of the two circular buttons on the actuator plate. This activates the full flush volume from the cistern.
- **Reduced Flush:** Press the smaller of the two circular buttons on the actuator plate. This activates the reduced flush volume from the cistern, conserving water.

Ensure the buttons are pressed firmly and released to allow the flush mechanism to complete its cycle.

## 7. MAINTENANCE

The Geberit Sigma20 Actuator Plate is designed with an easy-to-clean coating to simplify maintenance.

### 7.1 Cleaning Instructions

- Use a soft, damp cloth and a mild, non-abrasive cleaning agent.
- Avoid using harsh chemicals, abrasive cleaners, scouring pads, or solvents, as these can damage the surface finish and coating.
- Wipe the surface gently to remove dirt and water spots.
- Dry the plate with a clean, soft cloth to prevent water marks.

Regular cleaning will help maintain the aesthetic appearance and longevity of your actuator plate.

## 8. TROUBLESHOOTING


If you encounter issues with your Geberit Sigma20 Actuator Plate, consider the following common points:

- **Flush Not Activating:** Ensure the push rods are correctly engaged with both the actuator plate buttons and the cistern's flush mechanism. Check for any obstructions preventing the buttons from being fully depressed.
- **Weak Flush:** This is typically related to the cistern's internal mechanism or water supply, not the actuator plate itself. Consult the manual for your Geberit Sigma flush box or contact a plumber.
- **Buttons Sticking:** Clean around the buttons to remove any debris. If the issue persists, the internal mechanism may require inspection.

For persistent problems or issues not covered here, it is advisable to contact Geberit customer support or a qualified plumbing professional.

## 9. WARRANTY AND SUPPORT

For information regarding the product warranty, please refer to the documentation provided at the time of purchase or visit the official Geberit website. For technical support, spare parts, or service inquiries, please contact Geberit customer service directly through their official channels.

 <p><b>INSTALLATION MANUAL</b> SIGMA 12 CM GEBERIT</p> <p><b>KNOW HOW</b></p>	<p><a href="#"><u>Geberit Sigma 12 CM Installation Manual</u></a></p> <p>Comprehensive installation manual for the Geberit Sigma 12 CM concealed cistern system, detailing step-by-step assembly, frame mounting, valve installation, and flush plate attachment for plumbing professionals.</p>
 <p><b>INSTALLATION MANUAL</b> SIGMA8 MECHANICAL CONCEALED CISTERN WITH FRAME GEBERIT</p> <p><b>KNOW HOW</b></p>	<p><a href="#"><u>Geberit Sigma8 Mechanical Concealed Cistern with Frame: Specifications and Installation Guide</u></a></p> <p>Detailed technical guide for the Geberit Sigma8 Mechanical Concealed Cistern with Frame. Includes product specifications, button options, water efficiency ratings, and comprehensive step-by-step installation instructions for various wall types. Essential for plumbers and installers.</p>
 <p><b>INSTALLATION MANUAL</b> KAPPA21 GEBERIT</p> <p><b>KNOW HOW</b></p>	<p><a href="#"><u>Geberit Kappa21 Dual Flush Plate Installation Guide</u></a></p> <p>Step-by-step installation instructions for the Geberit Kappa21 Dual Flush Plate, detailing the process for proper setup and mounting.</p>
 <p><b>INSTALLATION MANUAL</b> SIGMA01 GEBERIT</p> <p><b>KNOW HOW</b></p>	<p><a href="#"><u>Geberit Sigma01 Dual Flush Plate Installation Manual</u></a></p> <p>Step-by-step installation guide for the Geberit Sigma01 Dual Flush Plate, providing clear instructions and diagrams for proper mounting and assembly.</p>
 <p><b>INSTALLATION MANUAL</b> ROTARY ACTUATOR GEBERIT</p> <p><b>KNOW HOW</b></p>	<p><a href="#"><u>Geberit Rotary Actuator Installation Manual (Model 972.121.00.0)</u></a></p> <p>Detailed installation manual for Geberit rotary actuators with cable pull (e.g., model 245900201, 972.121.00.0), providing step-by-step instructions, diagrams, and part information for proper assembly and mounting. Available in English, German, French, and Italian.</p>
 <p><b>AP117</b> <b>INSTALLATION MANUAL</b> AP117 GEBERIT</p> <p><b>KNOW HOW</b></p>	<p><a href="#"><u>Geberit AP117 Toilet Cistern Installation Manual</u></a></p> <p>Comprehensive installation guide for the Geberit AP117 toilet cistern, featuring step-by-step instructions, dimensions, and technical details. Includes multilingual support.</p>