



Manuals.plus /

› Whirlpool /

› Whirlpool 7.5 Kg 5 Star Fully-Automatic Top Loading Washing Machine User Manual

## Whirlpool WHITEMAGIC ELITE 7.5GREY 10YMW

# Whirlpool 7.5 Kg Fully-Automatic Top Loading Washing Machine

Model: WHITEMAGIC ELITE 7.5GREY 10YMW

## 1. INTRODUCTION

Thank you for choosing the Whirlpool WHITEMAGIC ELITE 7.5 fully-automatic top loading washing machine. This appliance is designed to provide efficient and convenient laundry care with advanced features like the 1-2-3 Wash System, Spiro Wash Action, and Hard Water Wash Technology. This manual provides essential information for safe operation, installation, maintenance, and troubleshooting to ensure optimal performance and longevity of your washing machine.

Please read this manual thoroughly before operating the appliance and keep it for future reference.

## 2. SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Ensure the washing machine is connected to a properly grounded electrical outlet.
- Do not operate the machine with a damaged power cord or plug.
- Keep children and pets away from the appliance during operation.
- Do not wash items that have been soiled with flammable substances.
- Always unplug the machine before cleaning or performing any maintenance.
- Do not open the lid during the spin cycle.

## 3. SETUP AND INSTALLATION

### 3.1 Unpacking

Carefully remove all packaging materials. The package includes: 1 Washing Machine, Fill Hose, Drain Hose, Clamp, Scoop, User Manual and Quick Guide.

### 3.2 Placement

Place the washing machine on a firm, level surface to prevent vibration and noise during operation. Ensure there is

adequate ventilation around the appliance.



Figure 3.2.1: Washing machine dimensions for proper placement. Height: 96.5 cm (3 ft 1 in), Depth: 54 cm (1 ft 7 in), Width: 55 cm (1 ft 8 in).

### 3.3 Water and Drain Connections

Connect the fill hose to a cold water tap and the designated inlet on the machine. Securely attach the drain hose to a suitable drain pipe or sink, ensuring it is not kinked or blocked.

### 3.4 Power Connection

Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the machine's requirements (230 Volts).





Figure 3.4.1: Front view of the Whirlpool WHITEMAGIC ELITE 7.5 washing machine.

## 4. OPERATING INSTRUCTIONS

### 4.1 Control Panel Overview

The control panel features an LED Digital Display and intuitive buttons for program selection and settings.



Figure 4.1.1: Detailed view of the control panel, showing program options, display, and function buttons.

### 4.2 1-2-3 Wash System

This system simplifies operation to just three steps:

1. **Power:** Press the Power button to turn on the machine.
2. **Program:** Select your desired wash program.
3. **Start/Pause:** Press Start to begin the wash cycle.

### 4.3 Wash Programs

The machine offers 12 wash programs to suit various fabric types and soil levels:

- **Daily:** For everyday laundry.
- **Heavy:** For heavily soiled garments.
- **Delicates:** Gentle wash for delicate fabrics.
- **Whites:** Optimized for white clothes.
- **Hard Water Wash:** Specifically designed to handle hard water conditions.
- **Eco Wash:** Energy-efficient wash cycle.
- **Woollens:** Special care for wool garments.
- **Bed Sheet:** For washing bed linens.
- **Rinse + Spin:** Adds an extra rinse and spin cycle.
- **Spin:** Drains water and spins clothes to remove excess moisture.

- **Wash Only:** Performs only the wash cycle without rinse or spin.
- **Aqua Store:** Stores water for later use.

#### 4.4 Loading Laundry and Detergent

Open the lid and evenly distribute laundry inside the drum, ensuring not to overload beyond the 7.5 Kg capacity. Add appropriate detergent to the dispenser.



Figure 4.4.1: Top view of the washing machine with the lid open, showing the drum and agitator.

## 5. MAINTENANCE

## 5.1 Cleaning the Smart Lint Filter

Regularly clean the Smart Lint Filter to ensure efficient lint collection and prevent clogging. Refer to the quick guide for specific instructions on removing and cleaning the filter.

## 5.2 Auto Tub Clean

Utilize the 'Auto tub clean' feature periodically to clean the washing machine drum and prevent odor buildup. This helps maintain hygiene and performance.

## 5.3 Exterior Cleaning

Wipe the exterior of the machine with a soft, damp cloth. Avoid using abrasive cleaners or solvents that could damage the finish.

## 6. TROUBLESHOOTING

If you encounter issues with your washing machine, refer to the following common problems and solutions before contacting service.

Problem	Possible Cause	Solution
Machine does not start	Power cord unplugged; Lid not closed properly; No water supply.	Check power connection; Ensure lid is fully closed; Check water tap and hose.
Water not draining	Drain hose kinked or blocked; Pump filter clogged.	Straighten drain hose; Clean pump filter (refer to quick guide).
Excessive vibration/noise	Machine not level; Load unbalanced; Transit bolts not removed.	Adjust leveling feet; Redistribute laundry; Ensure all transit bolts are removed during installation.
Clothes not clean	Overloading; Insufficient detergent; Incorrect program.	Reduce load size; Use recommended detergent amount; Select appropriate wash program.

## 7. SPECIFICATIONS

Feature	Detail
Model	WHITEMAGIC ELITE 7.5GREY 10YMW
Capacity	7.5 Kilograms
Type	Fully-Automatic Top Loading
Dimensions (LxWxH)	54D x 55W x 96.5H Centimeters
Item Weight	31 kg
Number of Wash Programs	12
Maximum Rotational Speed	740 RPM
Noise Level (Washing)	63 dB
Noise Level (Spinning)	72 dB
Drum Material	Porcelain Enamel
Special Features	Auto tub clean, Back Control Panel, Child Lock, LED Display, Smart Lint Filter
Voltage	230 Volts
Country of Origin	India

## 8. WARRANTY AND SUPPORT

### 8.1 Warranty Information

This Whirlpool washing machine comes with a 10-year warranty on the motor, ensuring long-term reliability and peace of mind. Please refer to your warranty card for complete terms and conditions.

### 8.2 Customer Support

For any service requests, technical assistance, or inquiries, please contact Whirlpool customer support:

- **Email:** [helpdeskindia@whirlpool.com](mailto:helpdeskindia@whirlpool.com)
- **Toll Free:** 1800 208 1800
- **Manufacturer Address:** Whirlpool of India Ltd. Plot No. A-4, MIDC Ranjangaon, Taluka Shirur, Dist: Pune, Maharashtra 412220, India.