

allen + roth 94903

Allen + Roth Light Filtering Cordless Cellular Shade Instruction Manual

Brand: allen + roth | Model: 94903

INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your new allen + roth Light Filtering Cordless Cellular Shade. Designed for enhanced safety and convenience, this unique shade lifts and lowers without the use of a cord, making it an ideal choice for homes with children and pets. Its semi-opaque fabric gently filters natural light, reducing glare while maintaining a bright and inviting indoor environment.



Image: The Allen + Roth Gray Light Filtering Cordless Cellular Shade, shown fully extended within a white window frame, demonstrating its clean, cordless design and light-filtering capabilities.

KEY FEATURES

- **Cordless Operation:** Provides improved safety for homes with children and pets by eliminating hazardous cords.
- **Light Filtering Fabric:** Features a semi-opaque fabric that softly filters light, reducing harsh glare while allowing natural illumination.
- **Durable Construction:** Designed to withstand years of use, maintaining its appearance and functionality.
- **Easy Installation:** Simple installation process, typically completed in under 10 minutes.
- **Smooth Operation:** Lifts and lowers smoothly with minimal effort.
- **Child-Safe Certified:** This product is certified "Best for Kids," ensuring it meets stringent safety standards for homes with young children.



Image: The "Certified Best for Kids" logo, indicating the product's compliance with child safety standards for window coverings.

SETUP AND INSTALLATION

Your Allen + Roth Cordless Cellular Shade is designed for straightforward installation. While specific instructions and hardware will be included in your product packaging, the general steps for an inside mount are as follows:

- 1. Measure Your Window:** Ensure your window opening matches the shade's dimensions (29"W x 72"H).
- 2. Gather Tools:** You will typically need a drill, screwdriver, measuring tape, and pencil.
- 3. Mark Bracket Locations:** Hold the shade in place to determine optimal bracket positions within the window frame. Mark these spots with a pencil.
- 4. Install Brackets:** Securely attach the mounting brackets to the marked locations using the provided screws.
- 5. Attach the Shade:** Carefully snap or slide the shade's headrail into the installed brackets until it is securely in place.
- 6. Test Operation:** Gently raise and lower the shade to ensure smooth and proper functionality.

For detailed, step-by-step instructions and safety warnings, always refer to the specific installation guide included with your product.

OPERATING INSTRUCTIONS

The cordless design of your cellular shade allows for simple and safe operation. To adjust the shade:

- To Lower:** Gently grasp the bottom rail of the shade, typically using the small plastic handle provided, and pull it down to your desired position. The shade will hold its position once released.
- To Raise:** Gently grasp the bottom rail of the shade and push it upwards. The shade will smoothly retract and hold its position when released.

Ensure the shade moves freely and is not obstructed by the window frame or other objects.



Image: The cellular shade installed in a bedroom window, demonstrating how it blends seamlessly with interior decor while providing light control.

CARE AND MAINTENANCE

To keep your cellular shade looking its best and ensure its longevity, follow these simple care instructions:

- **Dusting:** Regularly dust the shade with a soft cloth or a feather duster to prevent dust buildup.
- **Spot Cleaning:** For minor stains, spot clean with a damp cloth and mild soap. Blot the area gently; do not rub. Allow the shade to air dry completely before raising it.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or strong detergents, as these can damage the fabric and

color.

- **Handle Gently:** Always operate the shade by grasping the bottom rail evenly to prevent uneven wear or damage.

TROUBLESHOOTING

If you encounter any issues with your cellular shade, consider the following common solutions:

- **Shade Not Staying Up/Down:** Ensure the shade is fully extended or retracted once to reset the internal mechanism. Check for any obstructions in the window frame.
- **Uneven Lifting/Lowering:** Gently guide the bottom rail to ensure it remains level during operation. If the issue persists, re-check the installation brackets for proper alignment.
- **Difficulty Moving Shade:** Ensure the bottom rail is grasped firmly and evenly. Check for any debris or obstructions in the mechanism.

If problems persist after attempting these steps, please contact customer support.

PRODUCT SPECIFICATIONS

Attribute	Detail
Brand	allen + roth
Model Number	94903
Product Dimensions (Actual)	29"W x 72"H (72"L x 29"W)
Color	Gray
Operation Mode	Manual (Cordless)
Special Feature	Light Filtering
Closure Type	Cordless
Mounting Type	Inside Mount
Product Care Instructions	Spot Clean
Item Weight	2.49 pounds
UPC	766686949032

WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to the documentation included with your purchase or visit the official allen + roth website. You may also contact their customer service directly for assistance with any product-related inquiries.

For further assistance, please visit: [allen + roth Official Website](#)

no relevant documents