

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Eureka](#) /

› [Eureka NES215A Blaze 3-in-1 Swivel Handheld & Stick Vacuum Cleaner Instruction Manual](#)

Eureka NES215A

Eureka NES215A Blaze 3-in-1 Swivel Handheld & Stick Vacuum Cleaner Instruction Manual

Model: NES215A | Brand: Eureka

INTRODUCTION

The Eureka NES215A Blaze 3-in-1 Swivel Handheld & Stick Vacuum Cleaner is a lightweight cleaning device designed for various floor types. It features strong suction, a large, easy-to-clean dust cup, and a washable filter. The capture nozzle is designed to pick up larger debris, and advanced swivel steering enhances maneuverability. An 18-foot power cord provides extended reach for cleaning larger areas. Multiple accessories are included for cleaning hard-to-reach spaces and furniture.

IMPORTANT SAFETY INFORMATION

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT USE OUTDOORS OR ON WET SURFACES.

SETUP & ASSEMBLY

The Eureka NES215A vacuum is designed for quick and easy assembly, allowing for versatile use as a stick vacuum, handheld vacuum, or with a crevice tool. Refer to the included components for assembly.





Image: The Eureka NES215A vacuum demonstrating its 3-in-1 versatility, configured as a full stick vacuum, a handheld unit, and a handheld unit with the floor nozzle attached.

1. **Stick Vacuum Assembly:** Connect the handle to the main vacuum body, and then attach the floor nozzle to the bottom of the main body. Ensure all connections click securely into place.
2. **Handheld Vacuum Configuration:** Detach the handle and floor nozzle from the main vacuum body. The main body functions as a standalone handheld vacuum.
3. **Accessory Attachment:** The included crevice tool can be directly attached to the handheld vacuum for targeted cleaning.

OPERATING INSTRUCTIONS

The Eureka NES215A offers flexible cleaning options for various surfaces.

1. Stick Vacuum Mode

Use the vacuum in its fully assembled stick configuration for cleaning hard floors, area rugs, and low pile carpets. The 18-foot power cord provides ample reach.



Image: A person operating the Eureka NES215A in its stick vacuum configuration on a kitchen floor.

- **Swivel Steering:** The advanced swivel steering allows for easy maneuverability around furniture and obstacles.
- **Capture Nozzle:** The unique capture nozzle design effectively picks up larger debris without pushing it around.

2. Handheld Vacuum Mode

Detach the main body for handheld use to clean above-floor surfaces, furniture, and tight spaces.



Image: A person using the Eureka NES215A in handheld mode to clean a bar stool.

- **Crevice Tool:** Attach the crevice tool for reaching narrow gaps, corners, and edges.

3. Stair Vacuum Mode

Combine the handheld unit with the floor nozzle or crevice tool for efficient stair cleaning.



Image: A person using the Eureka NES215A in handheld mode with the floor nozzle to clean stairs.

MAINTENANCE

Regular maintenance ensures optimal performance and extends the life of your Eureka NES215A vacuum cleaner.

1. Emptying the Dust Cup

The vacuum features a large, easy-to-clean dust cup. Empty the dust cup regularly to maintain suction power.



Image: Hands demonstrating the easy emptying of the vacuum's dust cup directly into a trash receptacle.

2. Cleaning the Washable Filter

The vacuum is equipped with a washable foam filter. Clean the filter periodically to ensure efficient filtration and prevent loss of suction.



Image: Hands rinsing the vacuum's washable filter under running water for easy maintenance.

3. Roller Brush and Belt Cleaning

We recommend cleaning the roller brush and the belt every 2 weeks. Long-term failure to clean may cause malfunction, or even risk of smoke and belt breakage.

TROUBLESHOOTING

- **Loss of Suction:** Check if the dust cup is full and empty it if necessary. Inspect the washable filter for clogs and clean it as per the maintenance instructions. Ensure there are no blockages in the nozzle or hose.
- **Unusual Noise/Smell:** This may indicate a clogged roller brush or belt. Refer to the maintenance section for cleaning the roller brush and belt. Discontinue use if the issue persists and contact customer service.
- **Power Issues:** Ensure the 18-foot power cord is securely plugged into a functional power outlet.

SPECIFICATIONS

Brand	Eureka
Model Number	NES215A
Special Feature	Lightweight, Swivel Steering, Washable Filter
Filter Type	Foam
Included Components	Crevice Tool, Filter, Floor Nozzle, Crevice Tool Holder
Is Cordless?	No

Capacity	0.55 Liters
Wattage	240 watts
Recommended Uses	Area Rugs, Low Pile Carpets, Hard Floor
Form Factor	Handheld
Color	Blaze Blue
Product Dimensions	45.87"L x 9.65"W x 5.63"H
Noise Level	84 Decibels
Item Weight	4 pounds

WARRANTY AND SUPPORT

The Eureka NES215A Blaze 3-in-1 Swivel Handheld & Stick Vacuum Cleaner comes with a one-year limited warranty from the date of purchase.

For any questions or support, please contact our customer service team at [1-800-282-2886](tel:1-800-282-2886).