Manuals+

Q & A | Deep Search | Upload

atomi smart AT1317

Atomi Smart WiFi 12-Cup Coffee Maker AT1317 User Manual

Model: AT1317 | Brand: Atomi Smart

INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your Atomi Smart WiFi 12-Cup Coffee Maker, Model AT1317. Please read this manual thoroughly before using the appliance and retain it for future reference. This smart coffee maker allows you to brew coffee remotely, set schedules, and control settings via the Atomi Smart app, Amazon Alexa, or Google Assistant.

WHAT'S IN THE BOX

- Atomi Smart WiFi 12-Cup Coffee Maker Unit
- 12-Cup Glass Carafe
- · Reusable Coffee Filter
- Instruction Manual (this document)

PRODUCT OVERVIEW

Familiarize yourself with the components of your Atomi Smart WiFi Coffee Maker.



Figure 1: Atomi Smart WiFi 12-Cup Coffee Maker with its digital display and control buttons, alongside a smartphone showing the brewing control interface of the Atomi Smart app.




Figure 2: A user comfortably operating the Atomi Smart Coffee Maker remotely from their bed using the Atomi Smart app on their mobile device.




Figure 3: The Atomi Smart Coffee Maker positioned on a kitchen counter, with a hand holding a smartphone displaying the Atomi Smart app, allowing selection between 'Regular' and 'Strong' brew modes.

Works with Amazon Alexa and Hey Google "Alexa, turn on coffee maker" ŝmart works with Hey Google alexa atomi Ŝmart°

Voice Control

Figure 4: The Atomi Smart Coffee Maker demonstrating its compatibility with voice control, shown alongside an Amazon Echo Dot, illustrating how users can initiate brewing with commands like "Alexa, turn on coffee maker."



Figure 5: A detailed view of the Atomi Smart Coffee Maker, emphasizing its removable and washable reusable filter, designed for easy cleaning and maintenance.

SETUP

- 1. **Unpack and Inspect:** Carefully remove all packaging materials. Inspect the coffee maker for any damage. Ensure all components listed in "What's in the Box" are present.
- 2. **Initial Cleaning:** Before first use, wash the glass carafe and reusable filter in warm, soapy water. Wipe the exterior of the coffee maker with a damp cloth.
- 3. **Placement:** Place the coffee maker on a flat, stable, heat-resistant surface, away from the edge of the counter. Ensure adequate ventilation around the unit.
- 4. Power Connection: Plug the power cord into a standard electrical outlet.
- 5. **Download Atomi Smart App:** Download the free Atomi Smart app from the App Store (iOS) or Google Play Store (Android) on your smartphone or tablet.
- 6. Pairing with App:

- Open the Atomi Smart app and create an account or log in.
- Follow the in-app instructions to add a new device. Select "Coffee Maker" from the device list.
- Ensure your coffee maker's Wi-Fi indicator is blinking, indicating it's in pairing mode. If not, press and hold the Wi-Fi button on the coffee maker until it blinks.
- Connect the app to your home 2.4GHz Wi-Fi network.
- Once connected, the Wi-Fi indicator on the coffee maker will become solid.

OPERATING INSTRUCTIONS

Manual Brewing

- 1. **Fill Water Reservoir:** Open the lid and fill the water reservoir with fresh, cold water up to the desired level indicated on the side of the coffee maker. Do not exceed the 12-cup maximum line.
- 2. **Add Coffee Grounds:** Place the reusable filter into the filter basket. Add your desired amount of ground coffee to the filter. For best results, use medium-ground coffee.
- 3. Place Carafe: Ensure the glass carafe is properly placed on the warming plate.
- 4. Start Brewing: Press the "POWER" button on the coffee maker. The brewing process will begin.
- Select Brew Strength (Optional): Press the "STRONG" button before or during brewing to select a stronger coffee flavor.

Using the Atomi Smart App

The Atomi Smart app provides enhanced control and scheduling features.

- Remote Brewing: Open the app, select your coffee maker, and tap the "Brew" button to start brewing from anywhere.
- Scheduling: Set daily or weekly schedules for automatic brewing. You can specify the time and brew strength.
- Brew Strength: Adjust the brew strength (Regular or Strong) directly from the app.
- Timer Function: Use the app to set a delayed brew timer.

Voice Control (Amazon Alexa / Google Assistant)

Once your Atomi Smart Coffee Maker is paired with the Atomi Smart app, you can link it to Amazon Alexa or Google Assistant for voice commands.

- 1. **Link Account:** In the Alexa or Google Home app, search for the "Atomi Smart" skill/service and link your Atomi Smart account.
- 2. Voice Commands:
 - "Alexa, turn on the coffee maker."
 - "Hey Google, start brewing coffee."
 - "Alexa, turn off the coffee maker."

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the life of your coffee maker.

Always Unplug: Before cleaning, always unplug the coffee maker from the power outlet and allow it to cool
completely.

- 2. **Carafe and Filter:** Wash the glass carafe and reusable filter after each use with warm, soapy water. Rinse thoroughly and dry. These parts are generally top-rack dishwasher safe, but hand washing is recommended for longevity.
- 3. **Exterior:** Wipe the exterior surfaces of the coffee maker with a soft, damp cloth. Do not use abrasive cleaners or scouring pads. Never immerse the coffee maker in water or other liquids.
- 4. **Descaling:** Mineral deposits from water can build up over time and affect performance. Descale your coffee maker every 2-3 months, or more frequently if you have hard water.
 - Fill the water reservoir with a mixture of white vinegar and water (1:2 ratio).
 - Place an empty carafe on the warming plate.
 - Run a brew cycle.
 - After the cycle, let the coffee maker cool for 15 minutes.
 - Repeat the process with fresh water 2-3 times to rinse thoroughly.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Coffee not brewing.	No power; water reservoir empty; carafe not in place; brew cycle not initiated.	Check power connection; fill water reservoir; ensure carafe is correctly positioned; press POWER button or use app/voice command.
Coffee tastes weak or too strong.	Incorrect coffee-to-water ratio; wrong grind size; brew strength setting.	Adjust coffee grounds amount; use medium-ground coffee; select desired brew strength (Regular/Strong) via button or app.
Wi-Fi connection issues.	Incorrect Wi-Fi password; router too far; 5GHz network selected; coffee maker not in pairing mode.	Verify Wi-Fi password; move coffee maker closer to router; ensure 2.4GHz network is used; reset Wi-Fi on coffee maker by holding the Wi-Fi button until it blinks.
App not responding.	App glitch; internet connectivity issue; coffee maker offline.	Close and reopen the app; check your phone's internet connection; verify coffee maker's Wi-Fi indicator is solid.

SPECIFICATIONS

Brand	Atomi Smart
Model Name	AT1317
Colour	Black/Stainless Steel
Capacity	12 Cups
Special Feature	Programmable, Smart WiFi, Voice Control (Alexa/Google Home)
Coffee Maker Type	Drip Coffee Machine
Human Interface Input	Buttons, Atomi Smart App, Voice Control

Item Weight	3 kg 180 g
Item Dimensions (LxWxH)	20.3 x 21.6 x 34.5 Centimeters
Included Components	Carafe, Reusable Filter
Manufacturer	Atomi, Inc.
UPC	841856113335

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Atomi Smart website or contact their customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims. For further assistance, visit: Atomi Smart Support

© 2023 Atomi Smart. All rights reserved.