

Origaudio Thumpah 30945

Origaudio Thumpah IPX5 Water-Resistant Bluetooth Speaker User Manual

Model: Thumpah 30945

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your Origaudio Thumpah IPX5 Water-Resistant Bluetooth Speaker. Please read these instructions carefully before using the product and retain them for future reference.

2. SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures (hot or cold) or direct sunlight for prolonged periods.
- While the speaker is IPX5 water-resistant, it is not designed for prolonged submersion. Do not immerse the speaker in water.
- Keep the speaker away from flammable materials.
- Do not attempt to disassemble, repair, or modify the speaker. This will void the warranty and may cause damage or injury.
- Use only the provided charging cable or a certified equivalent.
- Clean the speaker with a soft, dry cloth. Avoid using abrasive cleaners or solvents.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- Origaudio Thumpah Bluetooth Speaker
- USB Charging Cable
- User Manual (this document)



Image: The Origaudio Thumpah speaker shown with its included USB charging cable, illustrating typical package contents.

4. PRODUCT FEATURES

- **10-Watt Audio Output:** Delivers clear and powerful sound.
- **Integrated Subwoofer:** Enhances bass performance.
- **IPX5 Water Resistance:** Protected against low-pressure water jets from any direction.
- **Bluetooth Connectivity:** Wireless audio streaming up to 10 meters (33 feet).
- **Extended Playtime:** Over 4 hours of continuous audio playback on a single charge.
- **Built-in Microphone:** For hands-free calling.
- **Portable Design:** Compact and lightweight for easy transport.

5. CONTROLS AND INDICATORS



Image: Side view of the speaker highlighting the control panel and the integrated carrying strap.



Image: Detailed view of the speaker's control buttons, including volume, play/pause, and track skip.

- **Power Button ():** Press and hold to power on/off.
- **Play/Pause Button ():** Press to play or pause audio.
- **Volume Up (+) Button:** Press to increase volume. Press and hold to skip to the next track.
- **Volume Down (-) Button:** Press to decrease volume. Press and hold to skip to the previous track.
- **Bluetooth Pairing Button ():** Press to enter Bluetooth pairing mode.
- **LED Indicator:** Displays power status, charging status, and Bluetooth connection status.
- **Micro USB Charging Port:** For connecting the charging cable.



Image: Close-up of the speaker's power button, LED indicator, and Micro USB charging port.

6. SETUP

6.1 Charging the Speaker

1. Connect the small end of the USB charging cable to the Micro USB port on the speaker.
2. Connect the large end of the USB charging cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will illuminate during charging and change color or turn off when fully charged.

6.2 Powering On/Off

- **To Power On:** Press and hold the Power button () for approximately 3 seconds until the LED indicator lights up.
- **To Power Off:** Press and hold the Power button () for approximately 3 seconds until the LED indicator turns off.

6.3 Bluetooth Pairing

1. Ensure the speaker is powered on. The LED indicator will flash, indicating it is in pairing mode.
2. On your Bluetooth-enabled device (smartphone, tablet, laptop), go to the Bluetooth settings.
3. Search for available devices and select "Thumpah" from the list.
4. Once paired, the LED indicator on the speaker will stop flashing and remain solid.
5. The speaker is now ready to play audio from your device.

7. OPERATING THE SPEAKER

7.1 Playing Audio

- After successful Bluetooth pairing, start playing audio on your connected device.
- Use the Play/Pause button () on the speaker to control playback.
- Adjust volume using the Volume Up (+) and Volume Down (-) buttons.
- Press and hold the Volume Up (+) button for the next track.
- Press and hold the Volume Down (-) button for the previous track.

7.2 Making and Receiving Calls

When connected via Bluetooth, the speaker's built-in microphone allows for hands-free calling.

- **Answer Call:** Press the Play/Pause button () once to answer an incoming call.
- **End Call:** Press the Play/Pause button () once during a call to end it.
- **Reject Call:** Press and hold the Play/Pause button () for 2 seconds to reject an incoming call.

7.3 Water Resistance (IPX5)

The Origaudio Thumpah speaker is rated IPX5, meaning it is protected against low-pressure water jets from any direction. This makes it suitable for outdoor activities and environments where it may encounter splashes or light rain.

- Do not submerge the speaker in water.
- Ensure the charging port cover is securely closed before exposing the speaker to water.
- After exposure to water, wipe the speaker dry with a soft cloth before charging.



Image: The Origaudio Thumpah speaker positioned outdoors, demonstrating its suitability for various environments.

8. MAINTENANCE

8.1 Cleaning

- Always power off the speaker before cleaning.
- Use a soft, dry, lint-free cloth to wipe the exterior of the speaker.
- For stubborn dirt, slightly dampen the cloth with water. Do not use harsh chemicals, cleaning solvents, or strong detergents.
- Ensure the speaker is completely dry before powering it on or charging.

8.2 Storage

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the battery to approximately 50% every few months to maintain battery health.

9. TROUBLESHOOTING

Common Issues and Solutions

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Charge the speaker using the provided USB cable.
No sound from speaker.	Volume is too low or muted. Device not paired.	Increase speaker and device volume. Ensure speaker is paired correctly.
Cannot pair with Bluetooth device.	Speaker not in pairing mode. Device Bluetooth off. Interference.	Ensure speaker is on and LED is flashing. Turn device Bluetooth off/on. Move closer to speaker.
Poor audio quality or disconnections.	Device too far from speaker. Obstructions. Low battery.	Move device closer to speaker. Remove obstructions. Charge speaker.

10. SPECIFICATIONS

Origaudio Thumpah Speaker Specifications

Feature	Detail
Model Name	Thumpah
Item Model Number	30945
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Bluetooth Range	10 Meters (33 feet)
Speaker Maximum Output Power	10 Watts
Speaker Type	Subwoofer
Woofer Diameter	2.5 Inches
Audio Output Mode	Stereo
Surround Sound Channel Configuration	2.1
Control Method	Touch
Power Source	Battery Powered (1 Lithium Ion battery included)
Playtime	Over 4 hours
Water Resistance Rating	IPX5
Material	Plastic
Color	Black
Item Weight	1.55 pounds

Feature	Detail
Package Dimensions	8.2 x 5.1 x 2.15 inches
UPC	086547319461

11. WARRANTY AND SUPPORT

11.1 Warranty Information

The Origaudio Thumpah speaker comes with an extended warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty card included in your product packaging or visit the official Origaudio website.

11.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or general inquiries, please visit the official Origaudio website for support resources and contact information.