



[Manuals.plus](#) /

› [Sports Afield](#) /

› Sports Afield Home Defense Quick Access Single Gun Vault SA-HD2 Instruction Manual

Sports Afield SA-HD2

Sports Afield Home Defense Quick Access Single Gun Vault SA-HD2 Instruction Manual

Model: SA-HD2

INTRODUCTION

This manual provides essential instructions for the proper setup, operation, and maintenance of your Sports Afield Home Defense Quick Access Single Gun Vault, Model SA-HD2. Please read this manual thoroughly before using the vault to ensure safe and effective operation. Keep this manual for future reference.

The SA-HD2 vault is designed for quick access to a single handgun, featuring a durable construction, an electronic keypad, and a protective foam interior. It is equipped with red interior illumination for visibility in low-light conditions and a spring-loaded door for immediate access.

SAFETY INFORMATION

- Always store firearms unloaded and secured within the vault.
- Keep override keys in a secure location away from the vault and out of reach of unauthorized individuals.
- Do not store the override keys inside the vault.
- Ensure the vault is securely mounted to prevent unauthorized removal.
- This vault is not fireproof or waterproof.

PACKAGE CONTENTS

- Sports Afield SA-HD2 Quick Access Single Gun Vault
- Override Keys (2)
- Mounting Hardware
- Instruction Manual (this document)

SETUP

1. Unpacking and Initial Inspection

Carefully remove the vault from its packaging. Inspect the vault for any signs of damage. If damage is found, contact customer support immediately.

2. Battery Installation

The electronic lock requires batteries for operation. Locate the battery compartment, typically on the inside of the door or on the back of the keypad. Insert the required batteries (usually AA or AAA, not included) according to the polarity markings. Close the battery compartment securely.

3. Mounting the Vault

For optimal security, it is recommended to secure the vault to a fixed surface. The vault includes pre-drilled bolt-down holes and mounting hardware.

1. Choose a suitable location for the vault, ensuring it is level and stable.
2. Mark the drilling points through the bolt-down holes on the vault's base or back.
3. Drill pilot holes into the surface using an appropriate drill bit.
4. Position the vault over the holes and secure it using the provided mounting hardware. Tighten all fasteners firmly.



Image: The Sports Afield SA-HD2 vault, highlighting its key features such as the security cable attachment point, bolt-down holes for secure mounting, interior lighting for visibility, and a fully padded interior to protect contents.

4. Setting Your Personal Access Code

The electronic lock allows for a programmable access code between 3 and 8 digits.

1. With the vault door open, locate the programming button (often a small red button) on the inside of the door or near the battery compartment.
2. Press the programming button. The keypad will typically beep, and an indicator light will illuminate.
3. Enter your desired 3-8 digit code on the keypad.
4. Press the programming button again to confirm the new code. The keypad should beep to confirm successful programming.
5. Test the new code with the door open before closing it. If the code works, close the door and test it again.

1. Opening the Vault with Your Access Code

1. Enter your personal 3-8 digit access code on the backlit illuminated touch pad.
2. If the code is correct, the vault will unlock, and the spring-loaded door will open automatically, providing quick access.



Image: A detailed view of the SA-HD2's electronic keypad, showing the illuminated numerical buttons and lock status indicators, designed for easy use even in low light.



Image: The Sports Afield SA-HD2 vault with its spring-loaded door open, showcasing the protective foam interior designed to safeguard contents.

2. Opening the Vault with Override Keys

In case of battery failure or forgotten code, the vault can be opened using the provided override keys.

1. Locate the keyhole, typically concealed near the keypad or on the front panel.
2. Insert one of the override keys and turn it to unlock the vault.
3. The door will open, providing access.



FAIL SAFE™
KEYS



TAMPER
PROTECTION

Image: A graphic illustrating the 'FAIL SAFE KEYS' feature, emphasizing the importance of the override keys for emergency access, alongside 'TAMPER PROTECTION' for enhanced security.

3. Interior Illumination

The vault features red interior illumination for easy visibility in low-light conditions. This light activates automatically when the door is opened.



Image: The interior of the SA-HD2 vault, showing a handgun placed within the foam padding, illuminated by the red interior light for clear visibility during nighttime access.

4. Silent Entry Mode

The vault may feature a silent entry mode to disable keypad beeps. Refer to the specific instructions provided with your vault for activating or deactivating this feature, as it can vary by model revision.

MAINTENANCE

1. Battery Replacement

When the batteries are low, the keypad may emit a warning signal (e.g., multiple beeps or a specific light pattern) during operation. Replace batteries promptly to ensure continuous functionality. Use high-quality alkaline batteries.

2. Cleaning

Clean the exterior of the vault with a soft, damp cloth. Avoid using abrasive cleaners or solvents, as these can damage the finish. The interior foam can be gently wiped with a dry cloth.



Image: A close-up of the SA-HD2 vault's interior, highlighting the full foam lining designed to protect stored items from scratches and damage.

3. Key Storage

Always store the override keys in a secure, separate location from the vault. Do not store them inside the vault or in an easily accessible place where unauthorized persons might find them.

TROUBLESHOOTING

- **Keypad Not Responding:** Check battery installation and replace batteries if necessary. Ensure the keypad is clean and free of debris.
- **Door Not Opening:** If using the access code, re-enter the code carefully. If the issue persists, use the override keys. Check for any obstructions preventing the door from opening.
- **Low Battery Indicator:** If the keypad emits a warning signal, replace the batteries immediately.
- **Tamper Alarm:** The vault may feature a tamper indicator or alarm. If activated, it suggests an attempt at

unauthorized access. Check the vault for signs of forced entry.

SPECIFICATIONS

Feature	Detail
Model Number	SA-HD2
External Dimensions (H x W x D)	5" x 10" x 12"
Weight	18 lbs
Capacity	Single Handgun
Locking Mechanism	Electronic Keypad (3-8 digit code) with Override Keys
Interior Features	Full Foam Interior, Red Interior Illumination
Finish	Durable Black Matte



Product Weight: 12lbs

Interior Volume: 0.2 cu.ft.

Image: A visual representation of the SA-HD2 vault's external and internal dimensions, including its height, width, depth, and interior volume, along with the product weight.

WARRANTY INFORMATION

Your Sports Afield SA-HD2 Quick Access Single Gun Vault is protected by a Three Year Hassle-Free Warranty. This warranty covers product defects, including issues with locks, parts, and paint. In the event of a covered defect, free freight is provided for the shipment of a replacement unit within the continental United States.

CUSTOMER SUPPORT

For further assistance, technical support, or warranty claims, please contact Sports Afield customer service. Refer to the contact information provided on the Sports Afield official website or your product registration card.



© 2023 Sports Afield. All rights reserved.