

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [tectake](#) /

› [tectake Adjustable Height Tilting Desk for Children - Model 400926](#)

tectake 400926

tectake Adjustable Height Tilting Desk for Children - Model 400926

Instruction Manual

[Introduction](#) [Safety Information](#) [Product Components](#) [Assembly](#) [Operating Instructions](#) [Maintenance](#) [Specifications](#) [Troubleshooting](#) [Warranty & Support](#)

1. INTRODUCTION

Thank you for choosing the tectake Adjustable Height Tilting Desk. This desk is designed to provide a comfortable and versatile workspace for children, ideal for study and creative activities. Its adjustable features ensure it can adapt to various needs and grow with your child. Please read this manual carefully before assembly and use to ensure safe and proper operation.

Key Features:

- Tilting desktop for versatile use, ideal for precision work or reading.
- Legs adjustable to 7 different heights (from approx. 63 cm to approx. 94 cm) for superior comfort and ergonomic adaptation.
- Practical integrated drawer for organized storage of small items.
- Spacious work surface (approx. 109 x 55 cm) with two stopper strips to prevent materials from sliding.
- Robust construction with rounded table edges for enhanced safety.

2. SAFETY INFORMATION

Caution:

- Ensure the desk is placed on a stable and level surface to prevent tipping.
- Do not use the desk if the height adjustment mechanism is not correctly secured.
- Keep children away from moving parts when adjusting the desk's height or tilt.
- Do not place excessive weight on the desk, as this may cause instability or damage.
- Regularly check all screws and fasteners to ensure they are tight.

3. PRODUCT COMPONENTS

Before assembly, ensure all parts are present and undamaged. Refer to the included parts list in your package for detailed identification.



Figure 1: Fully assembled tectake Adjustable Height Tilting Desk.

Main Parts:

- Desktop (1 piece)
- Leg frames (2 pieces)
- Crossbars/Support beams (various pieces)
- Drawer unit (1 piece)
- Stopper strips (2 pieces)
- Adjustment knobs and fasteners (various)

4. ASSEMBLY

Assembly is straightforward. Follow these general steps. For detailed diagrams, please refer to the separate assembly instructions included in your product packaging.

1. **Attach Leg Frames:** Secure the horizontal crossbars to the vertical leg frames using the provided screws and tools. Ensure all connections are tight and stable.

2. **Assemble Base Structure:** Connect the two assembled leg frames with the main support beams to form the desk's base.
3. **Install Height Adjustment Mechanism:** Attach the height adjustment components to the leg frames. These typically involve pins or knobs that lock into pre-drilled holes.
4. **Mount Desktop Supports:** Secure the tilting mechanism and desktop support brackets to the top of the base structure.
5. **Attach Desktop:** Carefully place the desktop onto the support brackets and secure it using the designated fasteners.
6. **Install Drawer and Stopper Strips:** Slide the drawer into its designated slot. Attach the two stopper strips to the front edge of the desktop.

Once assembled, double-check all connections for tightness and stability before use.

5. OPERATING INSTRUCTIONS

5.1. Adjusting Desk Height

The desk height can be adjusted to 7 different positions, ranging from approximately 63 cm to 94 cm. To adjust the height:

1. Loosen the height adjustment knobs located on the side of each leg frame.
2. Carefully lift or lower the desktop to the desired height. Ensure both sides are adjusted evenly.
3. Align the holes in the leg frames and insert the adjustment pins or tighten the knobs securely into the chosen height setting.
4. Verify that the desk is stable at the new height before use.




Figure 2: Detail of the height adjustment mechanism.

5.2. Tilting the Desktop

The desktop can be tilted to various angles for comfortable drawing, writing, or reading. To tilt the desktop:

1. Ensure there are no items on the desktop that could slide off.
2. Locate the tilting mechanism on the underside of the desktop.
3. Adjust the locking mechanism (e.g., release levers or knobs) to allow the desktop to tilt.
4. Carefully raise the desktop to your preferred angle.
5. Secure the desktop in place by engaging the locking mechanism.
6. The two stopper strips at the bottom edge of the desktop will help prevent items from sliding when tilted.



Figure 3: Detail of the desktop tilting mechanism.

5.3. Using the Drawer

The integrated drawer provides convenient storage for pens, paper, and other small accessories. Simply pull the drawer out to access its contents and push it back in to close.

6. MAINTENANCE

To keep your tectake desk in optimal condition:

- Clean the desk surface and frame regularly with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the lacquered MDF wood.
- Periodically check all screws and fasteners to ensure they remain tight. Tighten if necessary.
- Avoid exposing the desk to direct sunlight or extreme temperature changes, which can cause warping or discoloration.
- Do not place hot items directly on the desktop without protection.

7. SPECIFICATIONS

Feature	Detail
Brand	tectake
Model Number	400926
Color	Blue
Material	Engineered wood (MDF, lacquered)
Work Surface Dimensions	Approx. 109 x 55 cm
Adjustable Height Range	Approx. 63 cm to 94 cm (7 positions)
Internal Drawer Dimensions (HxWxD)	Approx. 6 x 27 x 22 cm
Number of Drawers	1
Weight	Approx. 17 kg
Special Feature	Height adjustable, Tilting desktop

8. TROUBLESHOOTING

8.1. Desk is Unstable

- Ensure the desk is placed on a flat, level surface.
- Check all assembly screws and fasteners. Tighten any loose connections.
- Verify that the height adjustment pins are fully engaged and secured on both sides.

8.2. Desktop Does Not Tilt Smoothly

- Inspect the tilting mechanism for any obstructions or debris.
- Ensure the locking mechanism is fully disengaged before attempting to tilt.
- Check that all screws related to the tilting mechanism are properly tightened, but not overtightened to restrict movement.

9. WARRANTY & SUPPORT

For warranty information, product support, or to order replacement parts, please contact tectake customer service. Keep your purchase receipt as proof of purchase. Contact details can typically be found on the product packaging or the official tectake website.