

## Sealey CP1205KIT

# Sealey Cordless Polisher Kit Ø71mm 12V SV12 Series - CP1205KIT User Manual

Model: CP1205KIT | Brand: Sealey

## INTRODUCTION

This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your Sealey CP1205KIT Cordless Polisher Kit. Please read these instructions thoroughly before using the product and retain them for future reference. The Sealey CP1205KIT is a compact, lightweight cordless polisher designed for various polishing tasks, featuring a 12V lithium-ion battery system.

## SAFETY INSTRUCTIONS

Always observe basic safety precautions when using electrical tools to reduce the risk of fire, electric shock, and personal injury.

- **Work Area Safety:** Keep the work area clean and well-lit. Cluttered or dark areas invite accidents. Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- **Electrical Safety:** Avoid body contact with earthed or grounded surfaces such as pipes, radiators, ranges, and refrigerators. Do not expose power tools to rain or wet conditions.
- **Personal Safety:** Always wear eye protection. Use appropriate safety equipment such as dust masks, non-skid safety shoes, hard hats, or hearing protection when necessary. Dress properly; avoid loose clothing or jewelry.
- **Tool Use and Care:** Do not force the power tool. Use the correct power tool for your application. Disconnect the plug from the power source and/or the battery pack from the power tool before making any adjustments, changing accessories, or storing power tools.
- **Battery Pack Use and Care:** Recharge only with the charger specified by the manufacturer. Do not use battery packs or tools that are damaged or modified.
- **Service:** Have your power tool serviced by a qualified repair person using only identical replacement parts.

## PRODUCT OVERVIEW AND COMPONENTS

The Sealey CP1205KIT includes the cordless polisher unit, two lithium-ion batteries, a charger, and various

accessories to get you started with your polishing tasks.



Image 1: Complete Sealey CP1205KIT Cordless Polisher Kit, showing the polisher, two batteries, charger, side handle, and canvas storage bag.

### Included Components:

- CP1205 - SV12 Series 71mm Cordless Polisher 12V
- CP1200BP - SV12 Series Power Tool Battery 12V 1.5Ah (x2)
- CP1200MC - SV12 Series Fast Charge Battery Charger 12V
- CP1200CB - Canvas Tool Storage Bag
- Side Handle
- Two Foam Pads
- One Wool Polishing Pad

## SETUP

---

### 1. Charging the Battery

Before first use, fully charge the lithium-ion batteries. Insert the battery into the charger, ensuring it clicks into place. The charger's indicator light will show the charging status. A full charge typically takes 1 hour.



Image 2: The Sealey 12V Fast Charge Battery Charger (CP1200MC).



Image 3: Graphic indicating a 60-minute fast charge time for the battery.

## 2. Attaching the Side Handle

For improved control and comfort, attach the side handle to the polisher. Screw the handle into the threaded opening on the side of the polisher head until secure.



Image 4: The Sealey Cordless Polisher with the side handle securely attached for enhanced grip.

### 3. Attaching Polishing Pads

The polisher uses a hook-and-loop (Velcro-style) backing pad. Align the desired foam or wool polishing pad with the backing pad on the polisher and press firmly to secure it. Ensure the pad is centered before operation.



Image 5: Close-up view of the Sealey Cordless Polisher with a yellow foam polishing pad attached to the Ø71mm backing plate.

## OPERATION

---

### 1. Powering On/Off

To turn the polisher on, press and hold the trigger switch. Release the trigger to turn the polisher off. Always ensure a firm grip on the tool before starting.

### 2. Speed Control

The polisher features two-speed settings, selectable via a switch on the tool body. Additionally, the trigger switch provides variable speed control, allowing for precise adjustment of rotation speed based on pressure applied. Start at a lower speed for initial application of polish and increase as needed.

### 3. Battery Level Indicator

An integral LED battery level indicator is located on the tool body. Monitor this indicator to determine the remaining battery charge. Recharge the battery when the indicator shows a low charge to avoid interruptions.



during use.

## 4. Polishing Techniques

Apply a small amount of polishing compound directly to the pad or the surface to be polished. Work in small sections, using overlapping passes. Maintain consistent pressure and movement. For best results, consult specific polishing compound instructions.

## MAINTENANCE

- **Cleaning:** After each use, remove the polishing pad and clean it according to its specific instructions. Wipe down the polisher body with a clean, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the polisher, batteries, and charger in the provided canvas storage bag in a dry, cool place, away from direct sunlight and moisture. Ensure batteries are partially charged before long-term storage.
- **Battery Care:** Do not store batteries in a fully discharged state. Recharge them periodically if not used for extended periods to maintain battery health. Avoid exposing batteries to extreme temperatures.
- **Inspection:** Regularly inspect the polisher for any signs of damage, loose screws, or worn parts. If any damage is found, discontinue use and contact qualified service personnel.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Polisher does not start	Battery not charged; Battery not properly inserted; Faulty trigger switch.	Charge battery fully; Ensure battery is securely clicked into place; Contact service for repair.
Reduced power or short run time	Battery low on charge; Battery nearing end of life.	Recharge battery; Consider replacing battery if performance does not improve after charging.
Excessive vibration or noise	Polishing pad improperly attached; Damaged backing pad; Internal mechanical issue.	Re-attach pad correctly; Inspect and replace backing pad if damaged; Contact service for inspection.
Charger indicator light not working	Charger not plugged in; Faulty charger.	Check power connection; Test with another outlet; Replace charger if faulty.

## SPECIFICATIONS

Model Number	CP1205KIT
Brand	Sealey
Voltage	12V
Pad Diameter	Ø71mm
Speed Settings	2-Speed settings, Variable speed trigger

Max Speed	7500 RPM
Battery Type	Lithium-Ion
Battery Capacity	1.5Ah (x2 included)
Charger Type	Fast Charge (1 hour)
Item Weight	1.84 kg
Product Dimensions	1 x 1 x 1 cm (packaging/shipping dimensions)
Material	Plastic (housing)

## WARRANTY AND SUPPORT

The Sealey CP1205KIT Cordless Polisher Kit comes with a **1-year guarantee** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for any warranty claims. Terms and conditions apply.



Image 6: Sealey 1 Year Guarantee information.

For technical support, spare parts, or warranty service, please contact your authorized Sealey dealer or visit

the official Sealey website for contact information.

*Note: Unauthorized repairs or modifications will void the product warranty.*

## Related Documents - CP1205KIT

	<p><a href="#">Sealey 10.8V Ø75mm Cordless Polisher - Body Only (CP108VCPBO) User Manual</a></p> <p>User manual for the Sealey 10.8V Ø75mm Cordless Polisher (Model CP108VCPBO), providing essential safety instructions, specifications, operation guidelines, maintenance procedures, and disposal information.</p>
	<p><a href="#">Sealey CP1201 12V Cordless Combi Drill: Instructions and Specifications</a></p> <p>Comprehensive instructions and specifications for the Sealey CP1201 12V SV12 Series Cordless Combi Drill. Covers safety, operation, and technical details for optimal use and maintenance.</p>
	<p><a href="#">Sealey MS900PS Ø170mm Variable Speed Sander/Polisher 1300W - User Manual</a></p> <p>Comprehensive instructions for the Sealey MS900PS Ø170mm Variable Speed Sander/Polisher (1300W), covering safety precautions, specifications, assembly, operation, and maintenance. Includes guidance on electrical safety, general workshop practices, and hand-arm vibration.</p>
	<p><a href="#">Sealey CP4VSD 4V Cordless Screwdriver with 26pc Bit Set - User Manual</a></p> <p>Comprehensive instructions and safety guidelines for the Sealey CP4VSD 4V Cordless Screwdriver with 26pc Bit Set. Learn about operation, maintenance, specifications, and safety precautions.</p>
	<p><a href="#">Sealey 14pc 3.7V Lithium-Ion Quick Select Cordless Screwdriver CP36MS.V2 User Manual</a></p> <p>User manual for the Sealey CP36MS.V2 14-piece 3.7V Lithium-Ion Quick Select Cordless Screwdriver. Provides detailed information on safety, operation, charging, specifications, and environmental disposal.</p>
	<p><a href="#">Sealey CP108VDD 10.8V Cordless Hammer Drill/Driver User Manual</a></p> <p>Comprehensive user manual for the Sealey CP108VDD 10.8V 2Ah Cordless Hammer Drill/Driver, covering safety, operation, specifications, charging, maintenance, and environmental disposal.</p>





[pdf] Datasheet Safety Datasheet

11 Dan Willis Safety Data Sheet Sealey CP1205KIT Cordless Polisher Kit Ø71mm 12V SV12 Series 2

Batteries v1 SDS DFC1343221 backslash fra1 digitaloceanspaces Workshopping Prototype ||| ||| Safety

Data Sheet Section 1. Product and Company Identification. 1.1 Model Number; CP1205KIT v1 1.2

Description; Cordless Polisher Kit 71mm 12V SV12 Series - 2 Batteries Battery: 12 Volts. 1.5 Ah. 180

grams. CP1200BP 1.3 Manufacturer; Seale

Safety Data Sheet Section 1. Product and Company Identification. 1.1 Model Number;

**CP1205KIT** v1 1.2 Description; Cordless Polisher Kit 71mm 12V SV12 Series - 2

Batteries Battery: 12 Volts. 1.5 Ah. 180 grams. CP1200BP 1.3 Manufacturer; Sealey

Group. Kempson Way, Bury St. Edmunds, Suffolk. IP32...

lang:en score:30 filesize: 308.8 K page\_count: 10 document date: 2023-01-26



[pdf] Accessories Catalog

Sealey Electric Power Tools Catalogue bodyshopsolutionsltd 2024 02 |||

ELECTRIC POWER TOOLS back to Section List Angle Grinders 878-879 Drywall

Sanders 885 Electric Ha ... ad Size: Thread Size: Body Only Weight: 0-2500rpm/0-

7500rpm 71mm 5/16 UNF 0.77kg Model No: CP1205 **CP1205KIT** Type: Body Only

Kit Contents: Combi Drill/Driver CP1201 - Combi Drill/Driver CP1200BP - ...

lang:en score:14 filesize: 17.47 M page\_count: 62 document date: 0000-00-00



[pdf] Datasheet Declaration of Conformity

CP1205KIT Declaration of Conformity 220 4 KB Al tler — Kablosuz Parl tıcı Kit 12V SV12 Seriyası

 71mm 2 Batareyalar Part Number 2023 11 22 10 09 57 273377 datasheet az pdlworld shop netcat files

multifile 773 504 |||

EC DECLARATION OF CONFORMITY Description and

Function:CordlessPolisherKit71mm12VSV12Series-2Batteries

Model/Type**CP1205KIT**v1 Manufacturing Date/Serial Number where applicable:

Declaration of Conformity in accordance with Directive s . References to harmonised

standard s 2014/30/EU EMC Directive...

lang:en score:14 filesize: 220.39 K page\_count: 1 document date: 2023-01-25