

Dyson V11 Torque Drive

Dyson V11 Torque Drive Cordless Vacuum Cleaner User Manual

Model: V11 Torque Drive | **Brand:** Dyson

1. PRODUCT OVERVIEW

The Dyson V11 Torque Drive is a powerful cordless vacuum cleaner designed for deep cleaning across various floor types. It features intelligent optimization of suction and run time, real-time reporting via an LCD screen, and versatile attachments for comprehensive home and car cleaning.



Image 1: Dyson V11 Torque Drive main unit and included accessories, such as the torque drive head, mini-motorized tool, crevice tool, stubborn dirt brush, soft dusting brush, combination tool, wand storage clip, docking station, and charger.

2. SETUP

2.1 Unboxing and Initial Charge

Upon unboxing, ensure all components are present. The vacuum requires an initial charge of approximately 270 minutes to fully power the lithium-ion battery. The convenient docking station stores and charges the machine, ensuring it is always ready for use.






Image 2: The Dyson V11 Torque Drive main unit is shown securely mounted on its wall-mounted docking station, indicating it is charging or stored.

2.2 Assembly

The Dyson V11 Torque Drive can be configured in two primary forms:

- **Stick Vacuum:** Attach the wand to the main unit and then connect the desired cleaner head (e.g., Torque Drive head) to the end of the wand.
- **Handheld Vacuum:** For quick clean-ups or cleaning difficult places, detach the wand and connect accessories directly to the main unit.

3. OPERATING INSTRUCTIONS

3.1 Power Modes and LCD Display

The vacuum features three power modes (Eco, Auto, Boost) controlled via a push button. The integrated LCD screen provides real-time performance information, including selected power mode, remaining run time, filter maintenance reminders, and blockage reports.

3.2 Dynamic Load Sensor (DLS) System

The DLS system automatically adjusts the motor speed between carpets and hard floors, optimizing suction for deep cleaning across different surfaces without manual intervention.

3.3 Included Tools and Their Uses

- **Torque Drive Head:** Automatically adapts suction and power for deep cleaning different floor types.
- **Mini-Motorized Tool:** Ideal for removing pet hair and dirt from upholstery and tight spaces.
- **Crevice Tool:** Designed for cleaning narrow gaps and edges.
- **Stubborn Dirt Brush:** Features stiff bristles for dislodging dried-on and stubborn dirt.
- **Soft Dusting Brush:** Soft bristles for gentle dusting of delicate surfaces.
- **Combination Tool:** A two-in-one tool with a wide nozzle and brush for quick switching between cleaning and dusting tasks.
- **Wand Storage Clip:** Conveniently stores tools on the wand.

Your browser does not support the video tag.

Video 1: This video demonstrates the Dyson V11 Torque Drive in action, showcasing its ability to pick up various types of debris on different surfaces and highlighting the ease of emptying the dustbin.

Your browser does not support the video tag.

Video 2: This video illustrates the powerful suction of the Dyson V11 Torque Drive as it effectively cleans up various messes, demonstrating its efficiency across different cleaning scenarios.

4. MAINTENANCE

4.1 Emptying the Dustbin

The Dyson V11 Torque Drive features a bagless design. To empty, hold the vacuum over a trash receptacle and push the red lever to release the contents. Your hands will not need to touch the dirt.

4.2 Filter Maintenance

The whole-machine filtration system captures 99.97% of microscopic dust particles as small as 0.3 microns. The LCD screen will provide reminders when the HEPA filter needs cleaning. Refer to the on-screen instructions for proper filter maintenance.

4.3 Battery Life

The 7-cell lithium-ion batteries provide up to 60 minutes of fade-free power. Actual runtime may vary based on power mode, floor type, and attachments used. The LCD screen displays the remaining battery life.

5. TROUBLESHOOTING

The LCD screen provides real-time blockage reports. If a blockage is detected, follow the on-screen instructions to clear the obstruction. Regular maintenance, including emptying the bin and cleaning the filter, can prevent common issues.

Your browser does not support the video tag.

Video 3: This video provides a detailed review of the Dyson V11 Absolute, demonstrating its assembly, various attachments, and the functionality of its LCD screen for monitoring performance and battery life.

6. SPECIFICATIONS

Feature	Detail
Brand	Dyson
Model Name	V11 Torque Drive
Filter Type	HEPA Filter
Is Cordless?	Yes
Capacity	0.2 Gallons
Wattage	79 watts
Charging Time	270 minutes
Maximum Suction	185 Inches
Recommended Uses	Carpet, Hard Floor, Upholstery
Form Factor	Stick (with handheld capabilities)
Product Dimensions	50.63" L x 9.84" W x 10.28" H

Battery Life	60 minutes
Noise Level	80 Decibels
Number of Power Levels	3
Item Weight	6.68 pounds

7. WARRANTY AND SUPPORT

The Dyson V11 Torque Drive Cordless Vacuum Cleaner comes with a **2-year warranty** covering all parts and labor from the date of purchase. For any questions or support, please contact the Dyson Helpline with your serial number and purchase details.