AVI-8 AV-4065-02

AVI-8 Hawker Harrier Matador Chronograph User Manual

Model: AV-4065-02
Brand: AVI-8

1. Overview

The AVI-8 Hawker Harrier Matador Chronograph is a sophisticated timepiece designed to pay tribute to the variants of the famed Hawker Harrier "Jump Jet." Inspired by the planes that flew for the Spanish Navy, nicknamed the “Matador,” this watch offers a dynamic experience with its intricate Japanese Quartz Chronograph movement. It features a 45mm stainless steel case, a 22mm genuine leather strap, a mineral lens with anti-reflective coating, and water resistance up to 50m.



Front view of the AVI-8 Hawker Harrier Matador Chronograph, showcasing its intricate dial and genuine leather strap.

2. Product Features

- **Japanese Quartz Chronograph Movement:** Provides precise timekeeping with 1/20 second accuracy and a big date display.
- **Durable Construction:** Features a 45mm stainless steel case for robust wear.
- **Premium Strap:** Equipped with a 22mm genuine leather strap for comfort and style.
- **Enhanced Visibility:** Mineral lens with anti-reflective coating ensures clear readability.
- **Water Resistance:** Rated for 50m (5 ATM), suitable for short periods of recreational swimming, but not diving.



Detailed diagram illustrating the key components and specifications of the Hawker Harrier Matador Chronograph.

3. Setup

3.1. Initial Time and Date Setting

To set the time and date on your AVI-8 Hawker Harrier Matador Chronograph, follow these steps:

1. **Pull the Crown:** Gently pull the crown (the knob on the side of the watch) out to position 2 for date adjustment, or position 3 for time adjustment.
2. **Set the Date:** In position 2, turn the crown clockwise or counter-clockwise to set the correct date.
3. **Set the Time:** In position 3, turn the crown to move the hour and minute hands to the desired time. Ensure you differentiate between AM and PM if your watch has a 24-hour sub-dial.
4. **Push the Crown Back:** Once the time and date are set, push the crown back into position 1 (normal operating position) to start the watch.



Angled view of the watch, showing the crown and pushers.

4. Operating the Chronograph

4.1. Using the Chronograph Function

The chronograph function allows you to measure elapsed time.

1. **Start:** Press the upper pusher (button) to start the chronograph. The chronograph second hand will begin to move.
2. **Stop:** Press the upper pusher again to stop the chronograph. The elapsed time will be indicated by the chronograph hands.
3. **Reset:** With the chronograph stopped, press the lower pusher to reset all chronograph hands to their zero positions.
4. **Split Time (if applicable):** Some chronographs allow for split time measurement. Consult the specific movement manual for advanced functions.

5. Maintenance and Care

5.1. General Care

- **Cleaning:** Wipe the watch regularly with a soft, dry cloth to remove dust and dirt. For the leather strap, avoid excessive moisture.

- **Temperature:** Avoid exposing your watch to extreme temperatures (hot or cold) or sudden temperature changes, as this can affect the movement and battery life.
- **Chemicals:** Keep the watch away from solvents, detergents, perfumes, and cosmetics, which can damage the case, strap, or seals.
- **Magnetic Fields:** Strong magnetic fields can affect the accuracy of quartz watches. Keep your watch away from strong magnets.

5.2. Water Resistance

Your AVI-8 Hawker Harrier Matador Chronograph has a water resistance rating of 50 meters (5 ATM). This means it is suitable for short periods of recreational swimming. However, it is **not** suitable for diving, snorkeling, or prolonged water activities. Always ensure the crown is fully pushed in before any contact with water. Avoid operating the pushers or crown when the watch is wet or submerged.



The reverse side of the AVI-8 Hawker Harrier Matador Chronograph, displaying the engraved case back and the attachment of the genuine leather strap.

6. Troubleshooting

6.1. Common Issues and Solutions

- **Watch Not Running:**
  - Check if the crown is fully pushed in.
  - The battery may need replacement. Consult a professional watchmaker for battery replacement.
- **Inaccurate Time:**
  - Ensure the time was set correctly (refer to Section 3.1).
  - Exposure to strong magnetic fields can affect accuracy. Demagnetization by a professional may

be required.

- **Chronograph Hands Not Resetting to Zero:**
  - This may require a chronograph reset procedure. For specific instructions, refer to the detailed movement manual or contact customer support.

7. Specifications

Feature	Detail
Product Dimensions	4.72 x 4.72 x 4.72 inches
Item Weight	3.53 ounces
Item Model Number	AV-4065-02
Department	Unisex
Batteries	1 AA batteries required.
Manufacturer	AVI-8
ASIN	B07NY3PLD5
Water Resistance	50m (5 ATM)
Case Diameter	45mm
Strap Width	22mm
Lens Material	Mineral with anti-reflective coating

8. Warranty and Support

8.1. International Warranty

Your AVI-8 watch is warranted against any manufacturing defect for a period of twenty-four (24) months from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from improper handling, accidents, unauthorized repairs, or normal wear and tear.

8.2. Customer Support

For warranty claims, technical assistance, or any inquiries regarding your AVI-8 watch, please contact AVI-8 customer support through their official website or the retailer from whom the watch was purchased. Please have your model number (AV-4065-02) and proof of purchase readily available.

© 2024 AVI-8. All rights reserved.