

[Manuals.plus](#) /

› [lezchi](#) /

› User Manual for lezchi Portable Power Bank

lezchi B07P11H8PT

User Manual

LEZCHI PORTABLE POWER BANK (MODEL: B07P11H8PT)

Ultra Slim 10000mAh Portable Charger

1. Introduction

Thank you for choosing the lezchi Portable Power Bank. This ultra-slim 10000mAh portable charger is designed to provide convenient and reliable power for your mobile phones, tablets, digital cameras, game consoles, and other electronic devices on the go. Its compact design, built-in AC plug, and integrated charging cables make it an ideal travel companion.

Please read this manual carefully before using the product to ensure safe and optimal performance.



Figure 1: lezchi Portable Power Bank and included storage bag.

2. Safety Information

Your safety is paramount. The lezchi Portable Power Bank incorporates intelligent power management ICs to provide comprehensive safety protection. Always adhere to the following guidelines:

- Do not expose the power bank to extreme temperatures (above 65°C or 149°F) or direct sunlight.
- Avoid dropping, disassembling, or attempting to repair the device yourself.
- Keep away from water and other liquids.
- Ensure proper ventilation during charging and discharging.

- This device is equipped with power short circuit protection, over current protection, over voltage protection, and over heat protection to ensure safe charging.
- Dispose of the power bank responsibly according to local regulations.

3. Setup and Charging the Power Bank

Before first use, it is recommended to fully charge your lezchi Portable Power Bank.

3.1 Charging via Built-in AC Plug

1. Locate the foldable AC plug on the side of the power bank.
2. Gently unfold the AC plug.
3. Plug the power bank directly into a standard wall outlet (AC 100-240V, 50/60Hz).
4. The LED indicators on the power bank will illuminate to show charging progress. All LEDs will be solid when fully charged.



Foldable AC Plug

Recharging easier for
Power bank itself

Figure 2: Charging the power bank using the foldable AC plug.

3.2 Charging via USB-C Input

1. Connect a USB-C cable (not included) to the USB-C input port on the power bank.
2. Connect the other end of the USB-C cable to a compatible USB wall adapter or computer USB port.
3. The LED indicators will show charging progress.

2 ways to charge the power bank



Figure 3: The power bank can be charged via its built-in AC plug or a USB-C cable.

4. Operating the Power Bank (Charging Your Devices)

The lezchi Portable Power Bank features built-in charging cables and a USB output port for versatile device charging.

4.1 Using Built-in Cables

The power bank includes built-in cables compatible with various devices:

- **USB-C Cable:** For devices with a USB-C port.
- **Lightning Cable:** For Apple devices (iPhone, iPad, etc.) with a Lightning port.
- **Micro USB Cable:** For older Android devices and other electronics with a Micro USB port.

1. Select the appropriate built-in cable for your device.

2. Connect the cable to your device's charging port.
3. The power bank will automatically begin charging your device. The LED indicators will show the remaining battery level of the power bank.

Built-in three kinds of cables

Compatible with different phone



Figure 4: The power bank features built-in cables for various phone types.

4.2 Using USB Output Port

1. Connect your device's original charging cable to the USB output port on the power bank.
2. Connect the other end of your cable to your device.
3. The power bank will automatically begin charging your device.

Note: The power bank can charge multiple devices simultaneously using its built-in cables and USB output port, up to its maximum output capacity.

5. Maintenance

- Clean the power bank with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- If not used for extended periods, charge the power bank at least once every three months to maintain battery health.
- Keep the built-in cables and AC plug clean and free of debris.



Figure 5: The slim design of the power bank makes it easy to carry and maintain.

6. Troubleshooting

Problem	Possible Cause	Solution
Power bank not charging	AC plug not fully inserted; faulty wall outlet; damaged cable (if using USB-C input).	Ensure AC plug is fully inserted or try a different outlet. If using USB-C, try a different cable or adapter.
Device not charging from power bank	Power bank battery is depleted; incorrect cable/port used; device charging port is dirty/damaged.	Recharge the power bank. Ensure the correct built-in cable or your device's original cable is used. Check device's charging port for debris.
Slow charging	Cable quality; device input limit; multiple devices charging simultaneously.	Use high-quality cables. Disconnect other devices if charging speed is critical for one device.
Power bank gets warm during use	Normal operation during charging/discharging.	This is normal. If it becomes excessively hot, disconnect immediately and contact customer service.

7. Specifications

Feature	Detail
Model	B07P11H8PT
Brand	lezchi
Battery Capacity	10000mAh (37Wh)
Battery Type	Li-ion
AC Input	100-240V~, 50/60Hz, 0.3A Max
USB-C Input	5V : 2.1A Max
USB Output	5V : 2.1A Max
Built-in Cable Output (USB-C, Lightning, Micro USB)	5V : 2.1A Max (shared)
Color	White
Special Features	Portable, Built-in AC Plug, Built-in Charging Cables (USB-C, Lightning, Micro USB), Slim Design, Safety Protection

Slim
Easy to carry



Figure 6: The ultra-slim design of the power bank for easy portability.

8. Warranty and Customer Support

Your lezchi Portable Power Bank comes with a user guide and a storage bag. For any questions, concerns, or technical assistance, please contact our customer service team.

- **Customer Service:** 7x24 hrs friendly customer service. Please refer to the contact information provided in your product packaging or on the official lezchi website.
- **Warranty:** Please refer to the warranty information included with your product packaging for details on coverage and terms.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question