Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Cooler Master E600-KGNN-S01

Cooler Master Elite 600 PC Case User Manual

Model: E600-KGNN-S01

1. Introduction

Thank you for choosing the Cooler Master Elite 600 PC Case. This manual provides essential information for the proper installation, operation, and maintenance of your new computer chassis. Please read this manual thoroughly before beginning the assembly process to ensure optimal performance and safety. The Elite 600 is designed for modular builds, offering excellent compatibility and cooling potential for your components.

2. Safety Information

- Always disconnect the power supply from the wall outlet before installing or removing any components.
- Wear an anti-static wrist strap to prevent electrostatic discharge (ESD) damage to sensitive components.
- Handle components carefully. Avoid touching pins or circuit boards directly.
- Keep small parts and tools away from children.
- Ensure proper ventilation around the PC case to prevent overheating.
- Do not attempt to modify the case structure, as this may void your warranty and pose a safety risk.

3. Package Contents

Please check the contents of your Elite 600 package. If any items are missing or damaged, contact your retailer or Cooler Master support.

- Cooler Master Elite 600 PC Case
- Accessory Box (screws, standoffs, cable ties, etc.)
- User Manual (this document)

4. Product Overview

The Cooler Master Elite 600 is a versatile ATX tower case designed for optimal airflow and component compatibility. It features a modular design and ample space for high-performance hardware.



Figure 4.1: Front-angled view of the Cooler Master Elite 600 PC case, showcasing the interior layout with pre-installed RGB fans and ample space for components.



Figure 4.2: Interior front view of the Elite 600 case, highlighting the fan mounts and the spacious design for airflow.



Figure 4.3: Angled exterior view of the Elite 600, showing the tempered glass side panel and the overall sleek design.



Figure 4.4: Side view of the Elite 600, emphasizing the clear tempered glass panel for showcasing internal components.



Figure 4.5: Another angled exterior view, highlighting the mesh panels on the top and front for enhanced airflow.



Figure 4.6: Interior view focusing on the motherboard tray and cable management

cutouts.



Figure 4.7: General exterior view of the Elite 600, showcasing its compact yet functional design.



Figure 4.8: Rear view of the Elite 600, showing the I/O shield cutout, expansion slots, and rear fan mount.

5. Setup and Installation

Follow these steps to install your components into the Cooler Master Elite 600 PC case.

1. **Prepare the Case:**
   - Place the case on a flat, stable surface.
   - Remove the side panels by unscrewing the thumbscrews at the rear and sliding them off.
2. **Install the Motherboard:**
   - Install the I/O shield into the cutout at the rear of the case.
   - Align your ATX motherboard with the standoffs inside the case. Ensure all standoffs match the motherboard's screw holes.

- Secure the motherboard with the provided screws.

3. **Install the Power Supply (PSU):**
   - Mount the PSU in the designated bottom-rear compartment.
   - Secure the PSU with screws from the rear of the case.
   - Route the necessary power cables through the cable management cutouts.
4. **Install Storage Drives:**
   - Locate the 3.5-inch drive bays. Slide your hard drives into the bays and secure them with screws or tool-less mechanisms.
   - For 2.5-inch SSDs, use the dedicated mounting points, typically behind the motherboard tray or in the drive cage.
5. **Install Expansion Cards (GPU, etc.):**
   - Remove the necessary expansion slot covers at the rear of the case.
   - Insert your graphics card or other expansion cards into the PCIe slots on the motherboard.
   - Secure the cards with screws.
6. **Connect Front Panel Cables:**
   - Connect the USB, audio, power switch, reset switch, and LED cables from the front panel to the corresponding headers on your motherboard. Refer to your motherboard manual for header locations.
7. **Cable Management:**
   - Utilize the cable routing holes and tie-down points behind the motherboard tray to organize cables. This improves airflow and aesthetics.
8. **Reattach Side Panels:**
   - Once all components are installed and cables are managed, carefully slide the side panels back into place and secure them with the thumbscrews.

6. Operating

The Cooler Master Elite 600 is designed to provide optimal cooling and protection for your PC components. Once your system is fully assembled and powered on, ensure the following:

- **Airflow:** Ensure that the case's intake and exhaust vents are not obstructed. Proper airflow is crucial for maintaining low component temperatures.
- **Fan Operation:** Verify that all installed fans are spinning correctly. The Elite 600 comes with pre-installed fans to assist with cooling.
- **Cable Management:** Well-managed cables not only improve aesthetics but also contribute to better airflow within the case.

7. Maintenance

Regular maintenance will help prolong the life of your components and ensure optimal performance.

- **Dust Cleaning:** Periodically clean dust filters (if present) and the interior of the case using compressed air. Dust buildup can impede airflow and cause overheating.
- **Fan Cleaning:** Gently clean fan blades to remove dust. Ensure fans are not obstructed.
- **Exterior Cleaning:** Wipe the exterior surfaces with a soft, damp cloth. Avoid harsh chemicals.

8. Troubleshooting

If you encounter issues with your PC build, consider the following common troubleshooting steps related to the case:

- **No Power:** Double-check all power connections from the PSU to the motherboard and components. Ensure the front panel power switch cable is correctly connected to the motherboard header.
- **Overheating:** Verify that all case fans are spinning and oriented correctly for optimal airflow (intake/exhaust). Ensure no cables are obstructing airflow. Clean any dust buildup.
- **Noise:** Check if any cables are touching fan blades. Ensure all screws are tightened to prevent vibrations.
- **Front Panel Ports Not Working:** Ensure all front panel USB and audio cables are securely connected to the correct headers on the motherboard.

9. Specifications

Feature	Specification
Brand	Cooler Master
Model Name	E600-KGNN-S01
Motherboard Compatibility	ATX
Case Type	Full Tower Case
Recommended Use	Gaming
Color	Black
Material	Alloy Steel
Power Supply Mounting	Bottom Mount
Cooling Method	Air
Special Feature	Modular Design and Open Frame (Note: Product title suggests a standard case, this feature might refer to internal modularity)
Compatible Hard Drive Size	3.5 Inches

Feature	Specification
Internal Bays Quantity	4
Compatible Devices	Desktop PC
Number of Items	1
Manufacturer	COOLER MASTER
ASIN	B07P1F5796

10. Warranty and Support

Cooler Master products come with a limited warranty. For detailed warranty information, terms, and conditions, please visit the official Cooler Master website. For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Cooler Master customer service through their official support channels.
Official Website: www.coolermaster.com

© 2023 Cooler Master. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07P1F5796

More documents and user manuals: **https://manuals.plus/**