

Imetec PS1 2000

Imetec Zerocalc PS1 2000 Compact Steam Iron User Manual

Model: PS1 2000

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your Imetec Zerocalc PS1 2000 Compact Steam Iron. Please read these instructions carefully before first use and retain them for future reference. The Imetec Zerocalc PS1 2000 is designed for effective garment care, featuring advanced anti-calc technology, energy-saving functions, and powerful steam output.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury.

- Read all instructions before using the iron.
- Do not leave the iron unattended while it is connected to the power supply or while it is hot.
- Always unplug the iron from the electrical outlet before filling with water, emptying, or when not in use.
- Do not operate the iron with a damaged cord or if the iron has been dropped or damaged. Contact authorized service personnel for repair.
- Keep the iron and its cord out of reach of children.
- Do not immerse the iron or its base in water or other liquids.
- Use the iron only for its intended purpose.
- The iron must be used and rested on a stable, level surface.
- Do not touch hot surfaces. Use handles or knobs.
- Exercise caution when turning the iron upside down, as there may be hot water in the reservoir.

3. PRODUCT OVERVIEW

The Imetec Zerocalc PS1 2000 is a compact steam iron system designed for efficient and effective ironing. It features a separate water tank and a powerful steam generator.



Figure 1: Imetec Zerocalc PS1 2000 Compact Steam Iron, showing the iron unit resting on its base with the water tank.

Key Features:

- **ZeroCalc Technology:** Three levels of protection to extend the iron's lifespan by combating limescale buildup.
- **High Pressure Steam:** Up to 3.8 bar pump pressure for quick and easy ironing.
- **Imetec Eco Energy Saving:** Reduces power consumption by 35% while optimizing steam output.
- **NoStop Continuous Refill:** Allows refilling the 1-liter water tank without interrupting ironing.
- **Fast Heat-up:** Steam is ready in just one minute.
- **Super Steam Function:** Provides an extra burst of steam for stubborn creases.
- **Durable Soleplate:** Multi-hole aluminum soleplate for even heat distribution.
- **Ergonomic Handle:** Comfortable cork handle for extended use.



Figure 2: The '3X ZeroCalc Technology' logo, indicating the advanced anti-limescale system.

4. SETUP

4.1 Unpacking

Carefully remove the iron and all accessories from the packaging. Retain the packaging for storage or transport. Check for any damage. If the product is damaged, do not use it and contact customer support.

4.2 Filling the Water Tank

1. Ensure the iron is unplugged from the power outlet.
2. Locate the water tank cap on the base unit.
3. Open the cap and fill the 1-liter water tank with clean tap water. Do not exceed the maximum fill line.
4. Close the water tank cap securely.



Figure 3: The water tank opening on the base unit, ready for filling.

4.3 Power Connection

Place the iron unit securely on its base. Plug the power cord into a suitable grounded electrical outlet. The iron is now ready for operation.

5. OPERATING INSTRUCTIONS

5.1 Initial Heat-up

Once plugged in, the iron will begin to heat up. The indicator light will illuminate. The iron will be ready for use in approximately one minute when the light indicates readiness.



Figure 4: Close-up of the iron's handle, showing the temperature control dial and power indicators.

5.2 Temperature Selection

Adjust the temperature dial on the iron to the appropriate setting for your fabric type. Refer to garment care labels for guidance. Start with lower temperatures for delicate fabrics and increase for heavier materials.

5.3 Steam Ironing

Once the iron reaches the selected temperature and the steam is ready (indicated by the light), press the steam button on the iron handle to release continuous steam. For an extra burst of steam for stubborn creases, use the Super Steam function.



Figure 5: The 'Super Vapore' (Super Steam) button on the iron's base for powerful steam bursts.

5.4 Dry Ironing

To iron without steam, ensure the water tank is empty or the steam function is turned off. Set the temperature according to the fabric type.

5.5 Continuous Refill (NoStop Technology)

The 1-liter water tank allows for extended ironing sessions. If the water level becomes low during ironing, you can refill the tank without turning off the iron or waiting for it to cool down. Simply open the water tank cap, add water, and close it securely.

6. MAINTENANCE

6.1 Cleaning the Soleplate

To clean the soleplate, ensure the iron is unplugged and completely cool. Wipe the soleplate with a damp cloth and a non-abrasive cleaner if necessary. Do not use abrasive pads or metallic scourers, as these can damage the soleplate.



Figure 6: The multi-hole aluminum soleplate of the iron.

6.2 Descaling (ZeroCalc Technology)

The Imetec Zerocalc PS1 2000 features integrated anti-calc technology. While this significantly reduces limescale buildup, periodic maintenance may still be beneficial, especially in areas with very hard water. Refer to the specific descaling instructions provided in the full product manual or on the manufacturer's website for detailed guidance on activating or maintaining the ZeroCalc system.

6.3 Storage

After use, unplug the iron and allow it to cool completely. Empty any remaining water from the tank. Store the iron in a dry, safe place, preferably in its original packaging, away from direct sunlight and moisture.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outlet fault; iron fault.	Check power connection; test outlet with another appliance; contact service if fault persists.
No steam or insufficient steam.	Water tank empty; iron not hot enough; steam button not pressed.	Fill water tank; wait for iron to reach operating temperature; press steam button.
Water leaks from soleplate.	Temperature too low for steam; overfilling water tank.	Increase temperature setting; do not overfill water tank.
White flakes on garments.	Limescale buildup.	Perform descaling procedure as per manufacturer's instructions.

8. SPECIFICATIONS

Feature	Specification
Brand	Imetec
Model Number	9014 (PS1 2000)
Power	2100 Watts
Steam Pressure	Up to 3.8 bar (pump pressure)
Water Tank Capacity	1 Liter (XL)
Heat-up Time	1 minute
Soleplate Material	Multi-hole Aluminum
Handle Material	Cork
Dimensions (L x W x H)	26 x 26 x 28 cm
Weight	4.28 Kilograms
Color	White/Blue

9. WARRANTY INFORMATION

This product is covered by a manufacturer's warranty. Details regarding the warranty period, terms, and conditions are typically provided in a separate warranty card included with your purchase or can be found on the official Imetec website. Please retain your proof of purchase for warranty claims.

10. CUSTOMER SUPPORT

For technical assistance, spare parts, or further information about your Imetec Zerocalc PS1 2000 steam iron, please visit the official Imetec website or contact their customer service department. Contact details

can usually be found in the product packaging or on the manufacturer's website.