Bajaj Stormix

Bajaj Stormix 750-Watt Mixer Grinder User Manual

Model: Stormix

1. Introduction

Thank you for choosing the Bajaj Stormix 750-Watt Mixer Grinder. This appliance is designed to simplify your kitchen tasks, offering efficient grinding and blending. To ensure safe and optimal performance, please read this manual thoroughly before using the appliance and retain it for future reference.

2. Important Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions carefully before operation.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Do not immerse the motor unit, cord, or plug in water or any other liquid.
- Keep hands and utensils away from moving blades during operation to prevent injury.
- Always ensure the jar lid is securely fastened before operating the mixer grinder.
- Unplug the appliance from the power outlet when not in use, before assembling or disassembling parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- This appliance is for household use only. Do not use outdoors.
- Keep the appliance out of reach of children.
- **Note on First Use:** It is normal to experience a slight burning smell during the first few uses. This is due to the motor varnish heating up and should dissipate with subsequent uses. If the smell persists, contact customer service.
- **Note on Noise:** Due to the powerful 750-watt motor, some operational noise is normal. If the noise level seems abnormal, please contact customer service.

3. Product Components

The Bajaj Stormix Mixer Grinder comes with the following components:



The complete Bajaj Stormix Mixer Grinder unit with its three accompanying jars.

- **Main Motor Unit:** The core unit housing the 750-watt motor and speed control knob. Features a shock-proof ABS body.
- **1.7 Litre Liquidizing Jar:** Ideal for wet grinding, blending, and making smoothies or batters.
- **1.2 Litre Dry Grinding Jar:** Suitable for grinding dry spices, coffee beans, and grains.
- **0.3 Litre Chutney Jar:** Designed for preparing small quantities of chutneys, pastes, and dips.



A detailed view of the compact 0.3 Litre Chutney Jar.

All jars are made of stainless steel and feature V-shaped designs for efficient grinding and unbreakable handles for durability.



Visual representation of key features including the powerful 750W motor, V-shaped jars, and robust handles.

4. Assembly and Setup

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for storage or future transport.
2. **Placement:** Place the main motor unit on a stable, flat, and dry surface, away from heat sources and water. Ensure adequate ventilation around the unit.
3. **Jar Preparation:** Before first use, wash all jars, lids, and blades with warm soapy water, rinse thoroughly, and dry completely.
4. **Attaching a Jar:** Place the desired jar onto the main motor unit. Align the locking tabs on the jar with the slots on the motor unit and gently twist clockwise until it locks securely into place.
5. **Lid Placement:** Secure the lid firmly onto the jar. Ensure the lid is properly seated to prevent spillage during operation.
6. **Power Connection:** Plug the power cord into a suitable 240-volt electrical outlet.



A close-up view of the main unit's speed control knob and the chutney jar, illustrating the compact design.

5. Operating Instructions

The Bajaj Stormix Mixer Grinder features a 750-watt motor with 3 speed settings and a pulse function for precise control.

1. **Loading Ingredients:** Place your ingredients into the appropriate jar. Do not overfill; ensure ingredients are below the maximum fill line.
2. **Secure Lid and Jar:** Firmly place the lid on the jar and ensure the jar is securely locked onto the motor unit.
3. **Select Speed:** Turn the speed control knob to the desired setting (1, 2, or 3). For short bursts, use the 'Inch/Off' position for pulse action.
4. **Operation:** Allow the appliance to run until the desired consistency is achieved. Avoid continuous operation for more than 5 minutes. Allow a cooling period of 2-3 minutes between cycles.
5. **Switch Off:** Once done, turn the speed control knob to the 'Off' position and unplug the appliance.
6. **Remove Jar:** Carefully unlock and remove the jar from the motor unit.

Usage Guidelines for Jars:

- **Liquidizing Jar (1.7L):** Use for blending liquids, making purees, milkshakes, and wet grinding batters. Add sufficient liquid for smooth operation.
- **Dry Grinding Jar (1.2L):** Ideal for grinding dry spices, nuts, and grains. Ensure ingredients are completely dry for best results.
- **Chutney Jar (0.3L):** Perfect for small quantities of chutneys, ginger-garlic paste, or other fine grinding tasks.

6. Care and Maintenance

Regular cleaning and maintenance will prolong the life of your mixer grinder.

- **Before Cleaning:** Always unplug the appliance from the power outlet.
- **Motor Unit:** Wipe the main motor unit with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
- **Jars and Lids:** Wash jars and lids with warm soapy water immediately after use. Use a brush to clean the blades carefully. Rinse thoroughly and dry completely before storing.
- **Blades:** Handle blades with extreme care as they are sharp.
- **Storage:** Store the mixer grinder and its accessories in a clean, dry place when not in use.

7. Troubleshooting

- **Appliance Not Starting:**
  - Check if the power cord is securely plugged into the outlet.
  - Ensure the jar is correctly locked onto the motor unit.
  - Verify that the speed control knob is not in the 'Off' position.
  - The unit has a motor overload protector. If the motor stops due to overload, switch off the appliance, remove some ingredients, and wait a few minutes before restarting.
- **Burning Smell During Operation:**
  - A slight burning smell is normal during the first few uses as the motor varnish cures. If it persists or is strong, switch off and contact customer service.
- **Excessive Noise:**
  - Some noise is expected from a powerful motor. Ensure the jar is properly seated and the lid is secure. If the noise is unusually loud or accompanied by vibrations, discontinue use and contact customer service.
- **Leakage from Jar:**
  - Ensure the lid is properly closed and the gasket is correctly fitted. Do not overfill the jar.

8. Technical Specifications

Feature	Specification
Brand	Bajaj
Model Number	Stormix
Power	750 Watts

Voltage	240 Volts
Number of Jars	3
Jar Capacities	1.7L (Liquidizing), 1.2L (Dry Grinding), 0.3L (Chutney)
Blade Material	Stainless Steel
Container Material	Stainless Steel
Body Material	Shock-proof ABS
Number of Speeds	3 + Pulse
Dimensions (LxWxH)	43.5 x 21.5 x 26.5 Centimeters
Item Weight	3 kg 900 g

9. Warranty and Customer Support

Your Bajaj Stormix Mixer Grinder is covered by a limited warranty:

- **Motor Warranty:** 5 Years
- **Product Warranty:** 2 Years

For any product-related queries, service requests, or to report abnormal noise levels or persistent burning smells, please contact Bajaj customer care:
Customer Care Number: 18001025963
Please retain your purchase receipt for warranty claims.

© 2023 Bajaj. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question