

JVC LT-32VHQ52I

JVC 32-inch HD-Ready Smart TV LT-32VHQ52I User Manual

Model: LT-32VHQ52I

1. INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your JVC 32-inch HD-Ready Smart TV, model LT-32VHQ52I. Please read this manual thoroughly before using your television and retain it for future reference. This television features HD-Ready resolution, Smart TV functionality with direct access buttons for Netflix and Prime Video, and integrated DVB-T2/C/S2 tuners for various broadcast standards.

2. SAFETY INFORMATION

Always observe the following safety precautions to prevent electric shock, fire, or injury:

- Do not expose the TV to rain or moisture.
- Do not open the TV casing; refer all servicing to qualified personnel.
- Ensure proper ventilation around the TV. Do not block ventilation openings.
- Place the TV on a stable, level surface to prevent it from falling.
- Unplug the TV from the power outlet during lightning storms or when unused for long periods.
- Keep the power cord away from heat sources and sharp edges.
- Do not place objects containing liquids on the TV.

3. PACKAGE CONTENTS

Verify that all items are present in the box:

- JVC 32-inch HD-Ready Smart TV (LT-32VHQ52I)
- Remote Control (RM-C3331)
- Power Cable
- User Manual
- TV Stand and Screws



Image: The JVC RM-C3331 remote control, featuring dedicated buttons for Netflix and YouTube.

4. SETUP

4.1 Unpacking and Stand Installation

1. Carefully remove the TV from its packaging.
2. Place the TV face down on a soft, clean surface to prevent screen damage.
3. Attach the TV stand to the bottom of the TV using the provided screws. Ensure it is securely fastened.



Image: Front view of the JVC 32-inch Smart TV with its stand attached.

4.2 Connecting Power

Connect the power cable to the TV's power input and then to a wall outlet. Ensure the voltage matches your region's requirements.

4.3 Antenna/Cable/Satellite Connection

Connect your antenna, cable, or satellite dish to the appropriate input port on the back of the TV. The TV supports DVB-T2 (terrestrial), DVB-C (cable), and DVB-S2 (satellite) tuners.



Image: A detailed view of the back panel connectivity ports, including HDMI, USB, LAN, and antenna inputs.

4.4 Initial Setup Wizard

Upon first power-on, the TV will guide you through an initial setup process. This includes language selection, country, time zone, and channel scanning. Follow the on-screen prompts using your remote control.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off

- Press the **Power** button on the remote control to turn the TV on or off.
- The TV does not feature a physical power button on the unit itself; all power functions are controlled via the remote.

5.2 Channel Selection and Volume Control

- Use the **CH +/-** buttons to change channels.
- Use the **VOL +/-** buttons to adjust the volume.
- Press the **Mute** button to temporarily silence the audio.

5.3 Input Source Selection

Press the **Source** button on the remote control to cycle through available input sources (e.g., HDMI 1, HDMI 2, AV, DTV).

6. SMART TV FEATURES

6.1 Connecting to the Internet

1. Navigate to the **Settings** menu using the remote control.
2. Select **Network** and then **Wi-Fi**.
3. Choose your Wi-Fi network from the list and enter the password.
4. Alternatively, connect an Ethernet cable to the LAN port on the back of the TV for a wired connection.

6.2 Using Streaming Services

Your JVC Smart TV includes direct access buttons on the remote control for popular streaming services:

- Press the **Netflix** button to launch the Netflix application.
- Press the **Prime Video** button to launch the Amazon Prime Video application.
- Other pre-installed applications can be accessed via the Smart TV home screen.

7. CONNECTIVITY

The TV offers various connection options:

- **HDMI Ports (x2):** For connecting high-definition devices such as Blu-ray players, game consoles, or set-top boxes.
- **USB Ports:** For connecting USB storage devices to play media files (photos, videos, music).
- **LAN Port:** For a wired internet connection.
- **Antenna/Satellite Inputs:** For connecting terrestrial, cable, or satellite signals.
- **Common Interface (CI+) Slot:** For inserting a CI+ module and smart card to access encrypted pay-TV services.
- **Optical Audio Out:** For connecting to an external audio system.
- **AV Input:** For connecting older devices using composite video and stereo audio cables.





8. MAINTENANCE

8.1 Cleaning the TV

- Always unplug the TV before cleaning.
- Use a soft, dry cloth to wipe the screen and cabinet.
- For stubborn marks, lightly dampen the cloth with water or a mild, non-abrasive screen cleaner. Do not spray cleaner directly onto the screen.
- Avoid using abrasive cleaners, waxes, or solvents.

8.2 Remote Control Care

- Replace batteries when the remote control's range decreases.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the remote control will not be used for an extended period.

9. TROUBLESHOOTING

Before contacting support, try the following solutions for common issues:

Problem	Possible Solution
No power	Check if the power cable is securely connected and the wall outlet is working. Press the power button on the remote.
No picture, but sound is present	Ensure the correct input source is selected. Check external device connections.
No sound, but picture is present	Check volume level and mute status. Verify audio cable connections for external devices.
Remote control not working	Replace batteries. Ensure no obstructions between the remote and the TV's IR sensor.
Cannot connect to Wi-Fi	Check Wi-Fi password. Restart your router. Ensure the TV is within range of the Wi-Fi signal.

10. SPECIFICATIONS

Feature	Detail
Model Name	LT-32VHQ52I
Screen Size	32 Inches
Resolution	720p (HD-Ready)
Display Technology	LED-LCD
Refresh Rate	240 Hz
Aspect Ratio	16:9

Feature	Detail
Tuner Type	DVB-T2/C/S2 MPEG 4 - HEVC - H265
Smart TV Features	Internet, Netflix, Amazon Video
HDMI Ports	2
USB Ports	Yes
Connectivity Technology	Wireless (Wi-Fi), HDMI
Common Interface (CI+)	Yes
Energy Efficiency	A+
Dimensions (Package)	90 x 58 x 14 cm
Weight (Package)	7.06 kg
Included Components	Product and manual

11. WARRANTY INFORMATION

This JVC television comes with a limited warranty. The specific terms and duration of the warranty may vary by region and retailer. Please refer to the warranty card included with your product or contact your point of purchase for detailed information. Keep your proof of purchase for warranty claims.

12. SUPPORT

For technical assistance, service, or further inquiries, please visit the official JVC support website or contact their customer service department. Contact information can typically be found on the JVC brand website or on your warranty documentation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question