

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Flash Furniture](#) /

› [Flash Furniture Hercules Series Folding Chair \(Model 2-LE-L-1-BLACK-GG\) - Instruction Manual](#)

Flash Furniture 2-LE-L-1-BLACK-GG

Flash Furniture Hercules Series Folding Chair

MODEL: 2-LE-L-1-BLACK-GG

Introduction

This manual provides essential information for the safe and effective use of your Flash Furniture Hercules Series Folding Chair. Designed for durability and versatility, this commercial-grade resin chair is suitable for various indoor and outdoor settings. Please read these instructions carefully before use.

Safety Information

WARNING:

- This chair has a maximum weight capacity of 800 pounds. Ensure the total weight on the chair does not exceed this limit.
- Use caution when using the chair outdoors, as environmental factors such as uneven surfaces or strong winds may affect stability.
- Always ensure the chair is fully unfolded and locked into position before sitting.
- Keep hands and fingers clear of folding mechanisms during setup and storage to prevent pinching.

Setup

Your Flash Furniture Hercules Series Folding Chair requires **no assembly** and is ready for immediate use. To set up the chair:

1. Hold the chair by the top of the backrest.
2. Gently pull the front and back legs apart until the seat drops into place and the chair is fully

extended.

3. Ensure all four legs are firmly on the ground and the seat is securely locked before use.



The Hercules Series Folding Chair shown in both its unfolded and compactly folded states.

Operating Instructions

The Hercules Series Folding Chair is designed for ease of use and portability.

Folding the Chair:

1. Ensure no one is sitting on the chair.
2. Lift the seat upwards from the front edge. The legs will begin to collapse inward.
3. Continue to bring the front and back sections together until the chair is fully flat.

Unfolding the Chair:

1. Hold the folded chair by the backrest.
2. Gently pull the front and back legs apart until the seat drops into its horizontal position.
3. Verify that the chair is stable and fully open before use.



The chair is ready to use right out of the box, requiring no assembly.

Your browser does not support the video tag.

Official Flash Furniture video demonstrating the chair's features and ease of folding/unfolding.

Maintenance

To ensure the longevity and appearance of your folding chair, follow these maintenance guidelines:

- **Cleaning:** The chair features a washable vinyl seat and polypropylene resin frame. Wipe clean with a damp cloth and mild soap. Avoid abrasive cleaners.
- **Seat Replacement:** The vinyl seat is replaceable if damaged, prolonging the life of the chair. Contact Flash Furniture support for replacement parts.
- **Outdoor Use:** While suitable for outdoor use, prolonged exposure to extreme weather conditions may affect the chair's lifespan. Store indoors or under cover when not in use for extended periods.



A close-up view of the durable and easy-to-clean black vinyl padded seat.

Storage

The folding design allows for convenient and space-saving storage:

- Fold the chairs flat as described in the Operating Instructions.
- Chairs can be stacked vertically to minimize floor space.
- For large quantities, consider using a folding chair dolly for easy transport and storage (dolly sold separately).



INDOOR OR OUTDOOR USE

UV Stabilized Resin with Waterproof Vinyl Seat

Multiple chairs stacked on a dolly, illustrating efficient storage and transport.

Troubleshooting

If you encounter any issues with your folding chair, consider the following:

- **Chair does not fold/unfold smoothly:** Check for any obstructions in the folding mechanism. Ensure the seat is fully lifted before attempting to fold.
- **Instability:** Verify that the chair is on a flat, even surface and fully extended with all locking mechanisms engaged.
- **Damaged Seat:** The vinyl seat is designed to be replaceable. Contact Flash Furniture customer service for assistance with obtaining a replacement.

Specifications

Attribute	Detail
Brand	Flash Furniture
Model Number	2-LE-L-1-BLACK-GG
Color	Black
Product Dimensions (Unfolded)	18"D x 17.5"W x 30.75"H
Seat Size	15.5"W x 13.75"D x 18.5"H
Back Size	17.5"W x 15"H
Folded Size	17.5"W x 2.25"D x 35"H
Maximum Weight Capacity	800 Pounds
Material	Polypropylene Resin, Vinyl (Seat)
Special Features	Lightweight, UV Stabilized, Removable Padded Seat
Assembly Required	No
Indoor/Outdoor Use	Yes

SPACE SAVING

Lightweight Foldable Design



Visual representation of the chair's key dimensions.

Warranty and Support

For warranty information, replacement parts, or further assistance, please contact Flash Furniture customer service. Refer to the product packaging or the official Flash Furniture website for the most current contact details.

Online Support: Visit the official [Flash Furniture Store](#) for product information and support resources.