

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Sew Mighty](#) /

› [Sew Mighty Handheld Sewing Machine Instruction Manual SMHH](#)

Sew Mighty SMHH

Sew Mighty Handheld Sewing Machine Instruction Manual

Model: SMHH

INTRODUCTION

This manual provides instructions for the proper use and maintenance of your Sew Mighty Handheld Sewing Machine, Model SMHH. This compact and lightweight device is designed for quick repairs, light crafting, and on-the-go stitching needs. Please read these instructions carefully before operating the machine to ensure safe and efficient use.

PACKAGE CONTENTS

Upon unpacking, please verify that all the following items are included:

- Sew Mighty Portable Sewing Machine
- 3 Threaded Bobbins (various colors)
- 1 Replacement Needle
- 1 Needle Threader
- 1 Spindle
- 1 Pink 60-inch Tape Measure
- Instruction Manual (this document)

Kit Includes

1. Pink 60" Soft Tape Measure
2. Prewound bobbins: blue, black & red
3. 1" Thread Spindle
4. Needle Threader
5. Extra Needle



Image: The Sew Mighty handheld sewing machine kit, showing the machine, three bobbins, a needle threader, an extra needle, a spindle, and a pink tape measure.

SETUP

1. Power Source Installation

The Sew Mighty handheld sewing machine can be powered by 4 AA batteries or an optional 6V AC power adapter (not included).

- **Battery Installation:** Locate the battery compartment on the underside of the machine. Open the cover and insert 4 AA batteries, ensuring correct polarity (+/-). Close the cover securely.
- **AC Adapter (Optional):** If using an AC adapter, plug it into the designated port on the side of the machine and then into a standard wall outlet.



Image: Close-up view of the Sew Mighty handheld sewing machine's battery compartments, showing where 4 AA batteries are inserted.

2. Bobbin and Threading

The machine comes with pre-threaded bobbins. If you need to replace a bobbin or re-thread:

1. Lift the presser foot.
2. Place the bobbin onto the bobbin pin located on the side of the machine.
3. Guide the thread through the tension disc.
4. Thread the needle from front to back using the provided needle threader if necessary.
5. Ensure the thread is securely pulled through the needle eye.

OPERATING INSTRUCTIONS

1. Preparing to Sew

1. Ensure the machine is properly threaded and powered.
2. Lift the presser foot using the lever.
3. Place the fabric under the presser foot. The machine can handle a maximum seam thickness of 1.8mm.
4. Lower the presser foot onto the fabric.

2. Starting and Stopping

- To start sewing, gently press the power button/switch. The machine will begin stitching.

- Guide the fabric smoothly with one hand while the machine stitches. Do not force the fabric.
- To stop sewing, release the power button/switch.

3. Securing Stitches

The Sew Mighty handheld machine produces a single chain stitch. To prevent unraveling, it is essential to secure the stitch at the end of your seam.

1. After completing your seam, lift the presser foot and gently pull the fabric away from the machine, leaving a tail of thread.
2. Cut the thread, leaving a tail of approximately 4-6 inches.
3. Manually tie a knot at the end of the stitch line to secure it. You may need to tie a double knot for added security.



Image: The Sew Mighty handheld sewing machine, ready for use, highlighting its compact design.

MAINTENANCE

- **Cleaning:** Regularly clean lint and dust from the needle area and feed dogs using a small brush or compressed air. Ensure the machine is off and batteries are removed before cleaning.
- **Needle Replacement:** If the needle becomes bent, dull, or breaks, replace it with a new one. Loosen the needle clamp screw, remove the old needle, insert the new needle with the flat side facing away from you, and tighten the screw.
- **Storage:** Store the machine in a dry, clean place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Machine does not turn on.	Dead batteries; incorrect battery installation; power adapter issue.	Replace batteries; check battery polarity; ensure power adapter is securely connected and functional.
Skipped stitches or loose stitches.	Incorrect threading; dull or bent needle; fabric too thick.	Re-thread the machine carefully; replace the needle; ensure fabric thickness is within 1.8mm limit.
Thread breaks frequently.	Incorrect tension; poor quality thread; needle bent or damaged.	Adjust tension disc; use good quality thread; replace needle.

Problem	Possible Cause	Solution
Fabric does not feed smoothly.	Presser foot not lowered; lint accumulation in feed dogs.	Ensure presser foot is down; clean feed dogs.

SPECIFICATIONS

Brand:

Sew Mighty

Model Number:

SMHH

Power Source:

4 x AA Batteries (not included) or 6V AC Adapter (not included)

Maximum Seam Thickness:

1.8 mm

Product Dimensions (L x W x H):

8.25" x 1.4" x 2.63"

Color:

Black (with pink accents)

ASIN:

B07P6Y2B8M

UPC:

855170001933




Image: Diagram showing the length (8.25 inches), width (1.4 inches), and height (2.63 inches) of the Sew Mighty handheld sewing machine.

WARRANTY AND SUPPORT

For information regarding warranty coverage, returns, or technical support, please refer to the retailer's policy where the product was purchased or contact Sew Mighty customer service directly. Keep your purchase receipt as proof of purchase.

Related Documents - SMHH

 <p>sewMighty® Multi-Function Sewing Machine</p> <p>CE</p> <p>OPERATION MANUAL</p>	<p>Sew Mighty Mighty Mini Sewing Machine: Operation Manual & Guide</p> <p>Detailed operation manual for the Sew Mighty Mighty Mini Sewing Machine. Learn how to set up, thread, operate, and maintain your multi-function sewing machine. Includes safety precautions, parts identification, stitch pattern selection, and troubleshooting tips for home sewing and fabric repair.</p>
 <p>sewMighty® www.sewmighty.com</p> <p>Mighty Mini Sewing Machine</p>  <p>OPERATION MANUAL <small>(Please read manual carefully before using the SewMighty™)</small></p>	<p>SewMighty Mighty Mini Sewing Machine Operation Manual - Guide and Troubleshooting</p> <p>Comprehensive operation manual for the SewMighty Mighty Mini Sewing Machine. Learn how to thread, sew, adjust tension, replace needles, wind bobbins, and troubleshoot common issues. Includes safety precautions and creative ideas.</p>
 <p>sewMighty® Multi-Function Sewing Machine</p> <p>CE</p> <p>OPERATION MANUAL</p>	<p>Sew Mighty Mighty Mini Sewing Machine: Operation Manual & Guide</p> <p>Detailed operation manual for the Sew Mighty Mighty Mini Sewing Machine. Learn how to set up, thread, operate, and maintain your multi-function sewing machine. Includes safety precautions, parts identification, stitch pattern selection, and troubleshooting tips for home sewing and fabric repair.</p>
 <p>MANUAL INSTRUCTIONS</p>	<p>Singer Stitch Sew Quick Manual Instructions - Operation and Maintenance Guide</p> <p>Comprehensive user manual for the Singer Stitch Sew Quick handheld sewing machine. Provides detailed instructions on operation, threading, needle and bobbin replacement, tension adjustment, and safety precautions.</p>
 <p>EMERIO SEW-122595.2</p>  <p>Handheld Sewing Machine (EM) Handsewing Machine (ES) Máquina de coser portátil (ES) Handheld sewing machine (EN) Handsewing machine (EN) Máquina de coser de mano (ES) Máquina de coser portátil (ES)</p> <p>CE</p>	<p>Emerio SEW-122595.2 Handheld Sewing Machine User Manual</p> <p>Comprehensive user manual for the Emerio SEW-122595.2 Handheld Sewing Machine. Includes setup, operation, safety, and maintenance instructions for easy sewing and repairs.</p>

Sew Together Bag Supply List

©2013 Sew Demented. All rights reserved.

Notes: This list is for the Sew Together Bag project. It includes fabric, interfacing, notions, and tools.

Fabric and other materials:

- 1 yard of fabric
- 1 yard of interfacing
- 1 yard of fabric (optional)

Notions:

- 1 yard of fabric
- 1 yard of interfacing
- 1 yard of fabric (optional)

Tools:

- 1 yard of fabric
- 1 yard of interfacing
- 1 yard of fabric (optional)

Notes:

- 1 yard of fabric
- 1 yard of interfacing
- 1 yard of fabric (optional)

[Sew Together Bag Supply List - Crafting & Sewing Essentials](#)

Comprehensive supply list for the Sew Together Bag project, including fabric, interfacing, notions, and tools. Designed by Sew Demented.