Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tefal FV9835

Tefal Ultimate Pure Steam Iron FV9835 User Manual

Model: FV9835

For detailed information, please refer to the sections below.

1. Introduction

This manual provides essential information for the safe and efficient use of your Tefal Ultimate Pure Steam Iron, model FV9835. Please read all instructions carefully before first use and retain for future reference.
The Tefal Ultimate Pure Steam Iron FV9835 is designed for efficient ironing, featuring a Durilium Autoclean soleplate and powerful steam capabilities.

2. Safety Instructions

Important Safety Precautions:

- Always plug the iron into a grounded outlet.
- Do not leave the iron unattended while it is connected to the mains.
- Keep the iron and its cord out of reach of children.
- Do not immerse the iron in water or any other liquid.
- Unplug the iron before filling with water, cleaning, or after each use.
- Use the iron only for its intended purpose.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.

3. Setup

Before first use, remove any labels or protective covers from the soleplate.

3.1 Filling the Water Tank

1. Ensure the iron is unplugged.
2. Open the water tank filler cap.
3. Fill the water tank with clean tap water up to the 'MAX' level indicator. Do not overfill.
4. Close the filler cap securely.



Figure 3.1: Filling the water tank. The image displays the iron with its water tank cap open, ready for water to be poured in.

4. Operating Instructions

4.1 Powering On and Temperature Setting

1. Plug the iron into a suitable electrical outlet.
2. Turn the temperature dial to the desired setting according to the fabric type. The indicator light will illuminate.
3. Wait for the indicator light to turn off, indicating the iron has reached the set temperature.

4.2 Steam Ironing

- Ensure the water tank is filled.
- Select the appropriate steam setting using the steam control knob.
- For a burst of steam, press the steam shot button.



Figure 4.1: Steam ironing in progress. The iron is shown actively releasing steam, smoothing out wrinkles on a piece of clothing.

4.3 Dry Ironing

For dry ironing, ensure the steam control is set to the 'no steam' position.

4.4 Vertical Steaming

The iron can be used for vertical steaming of hanging garments. Hold the iron vertically and press the steam shot button.

5. Maintenance

5.1 Cleaning the Soleplate

The Durilium Autoclean soleplate is designed for easy cleaning. If necessary, wipe the soleplate with a damp cloth after the iron has cooled down.

5.2 Descaling (Micro-Calc Filter)

The Tefal Ultimate Pure FV9835 features a Micro-Calc Filter to prevent limescale build-up. Regularly remove and clean the filter as per the instructions below:

1. Ensure the iron is unplugged and completely cool.
2. Locate the Micro-Calc Filter cartridge, usually at the rear of the iron.
3. Remove the filter by pulling it out.
4. Rinse the filter under running water to remove any calc deposits.
5. Reinsert the clean filter back into the iron until it clicks into place.



Figure 5.1: Removing and cleaning the Micro-Calc Filter. The image shows the iron with the filter cartridge detached, ready for cleaning.

5.3 Storage

After use, unplug the iron and allow it to cool completely. Empty any remaining water from the tank. Store the iron upright in a safe, dry place.



Figure 5.2: Proper storage of the iron. The iron is shown standing upright on its heel, ready for storage.

6. Troubleshooting

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outlet faulty; temperature dial set to minimum.	Check power connection; try another outlet; turn temperature dial to desired setting.
No steam or insufficient steam.	Water tank empty; temperature too low; steam control set to 'no steam'; Micro-Calc Filter clogged.	Fill water tank; set higher temperature; adjust steam control; clean Micro-Calc Filter.
Water leaking from soleplate.	Temperature too low for steam; overfilled water tank.	Allow iron to heat up fully before using steam; do not overfill water tank.

7. Specifications

Model: FV9835

Brand: Tefal

Power: 3000 Watts

Voltage: 2.3E+2 Volts

Soleplate Material: Durilium Autoclean

Weight: 2.14 Kilograms

Dimensions (L x W x H): 50 x 50 x 28 cm

8. Warranty and Support

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Tefal website. Keep your proof of purchase for warranty claims.
Online Support: www.tefal.com

9. Product Overview



Figure 9.1: Front view of the Tefal Ultimate Pure Steam Iron FV9835. This image shows the overall design and color of the iron.



Figure 9.2: Side view of the iron, illustrating the transparent water tank and ergonomic handle.



Figure 9.3: Rear view of the iron, demonstrating its stable heel rest for upright storage.



Figure 9.4: The iron in action, showing powerful steam output for effective wrinkle removal.



Figure 9.5: Detailed view of the removable Micro-Calc Filter, essential for maintaining steam performance.

© 2024 Tefal. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07P6YDT61

More documents and user manuals: **https://manuals.plus/**