

Preethi Mystic

Preethi Mystic 750W Mixer-Grinder User Manual

Model: Mystic | Brand: Preethi

1. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions carefully before using the appliance.
- Always ensure the appliance is unplugged from the power outlet before assembly, disassembly, or cleaning.
- Do not immerse the motor unit in water or any other liquid. Clean with a damp cloth only.
- Keep hands and utensils out of the jar while operating to prevent injury and damage to the appliance.
- Ensure the lid is securely locked before starting the mixer-grinder.
- Avoid contact with moving parts. Blades are sharp; handle with extreme care.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or is dropped or damaged in any manner.
- This appliance is for household use only.

2. PRODUCT OVERVIEW

The Preethi Mystic 750W Mixer-Grinder is designed for efficient and hands-free grinding. It features a powerful Vega W5 motor, a secure lid-lock system, and a triple safety mechanism for enhanced user safety.



Image: The Preethi Mystic 750W Mixer-Grinder, showcasing the main unit and three stainless steel jars. Key features such as the 5-year motor warranty, powerful 750W motor, secure lid-lock, diamond facet design, and triple safety design are highlighted.

Components:

- **Main Motor Unit:** The base unit housing the 750W motor and speed control knob.
- **1.5 Liter Jar:** For larger quantities and wet grinding.
- **1 Liter Jar:** For medium quantities and general grinding.
- **0.5 Liter Jar:** For smaller quantities, chutneys, and dry grinding.
- **Spatula:** For mixing and removing ingredients.



Image: The main motor unit of the Preethi Mystic Mixer-Grinder, featuring the speed control knob and power indicator.



Image: The 1.5 Liter stainless steel jar with its transparent lid and handle.



Image: The 1 Liter stainless steel jar with its transparent lid and handle.



Image: The 0.5 Liter stainless steel jar with its transparent lid and handle.

3. SETUP

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for future storage or transport.
2. **Clean Jars:** Before first use, wash the jars, lids, and blades with warm soapy water. Rinse thoroughly and dry.
3. **Position the Unit:** Place the main motor unit on a clean, dry, stable, and flat surface, away from the edge of the countertop. Ensure there is adequate ventilation around the unit.
4. **Check Power:** Ensure the power supply matches the appliance's requirements (230 Volts AC).

4. OPERATING INSTRUCTIONS

General Operation:

1. **Prepare Ingredients:** Cut ingredients into smaller pieces if necessary to facilitate grinding.
2. **Load Jar:** Place the desired ingredients into the appropriate jar. Do not overfill the jar beyond the maximum fill line.

3. **Secure Lid:** Place the lid firmly onto the jar and ensure it is locked into position. The Preethi Mystic features a secure lid-lock system for hands-free operation and to prevent spills.
4. **Attach Jar to Motor Unit:** Place the jar onto the main motor unit. Twist the jar clockwise until it locks securely into place. The triple safety mechanism ensures the mixer-grinder will not operate unless the jar and lid are properly secured.
5. **Plug In:** Connect the power cord to a suitable electrical outlet.
6. **Select Speed:** Turn the knob to the desired speed setting (1, 2, or 3). For short bursts, use the 'Pulse' setting.
7. **Grind:** Allow the mixer-grinder to operate until the desired consistency is achieved. The powerful Vega W5 750W motor is designed for superior grinding performance, capable of grinding tough ingredients like turmeric in just 2 minutes.
8. **Monitor:** The 3D Air Cooling Technology helps in faster cooling and extends motor life during operation.
9. **Switch Off:** Once grinding is complete, turn the knob to '0' and unplug the appliance.
10. **Remove Jar:** Twist the jar counter-clockwise to unlock and lift it from the motor unit. Carefully remove the lid and pour out the contents.

Grinding Guidelines:

KNOW YOUR MIXER GRINDER

LESS THAN 750W

MORE THAN 750W



Dips & Chutneys

CHOOSE
< 750
WATTS FOR
REGULAR
GRINDING



CHOOSE
> 750
WATTS FOR
TOUGH
GRINDING



Dry Masala



Purées & Soups



Smoothies
& Milkshakes




Ginger, Coconut
& Turmeric Paste



Rice & Lentils
Dosa/Idli Batter



BURNING SMELL DURING FIRST
few runs due to evaporating varnish



80-90dB OPERATING NOISE
levels similar to that of a hair dryer

DECIBEL LEVEL COMPARISON CHART



Image: An infographic titled 'Know Your Mixer Grinder' providing guidance on selecting wattage for different grinding tasks (e.g., less than 750W for dips/chutneys, more than 750W for tough grinding like dry masala or ginger/turmeric paste). It also explains the burning smell during initial use and typical operating noise levels.

- For regular grinding tasks like dips, chutneys, purees, soups, smoothies, and milkshakes, the 750W motor is highly effective.
- For tough grinding tasks such as dry masala, ginger, coconut, turmeric paste, rice, and lentil batters, the 750W motor provides ample power.
- A burning smell during the first few runs is normal due to the evaporating varnish on the motor windings. This will dissipate with continued use.

5. MAINTENANCE AND CLEANING

1. **Unplug:** Always ensure the mixer-grinder is unplugged before cleaning.
2. **Clean Jars and Blades:** Immediately after use, rinse the jars, lids, and sharp rust-proof stainless steel blades under running water. Use a brush and mild dish soap to remove any food residue. Be extremely careful when handling blades.
3. **Dishwasher Safety:** The jars, lids, and blades are *not* dishwasher safe. Hand wash only.
4. **Clean Motor Unit:** Wipe the main motor unit with a soft, damp cloth. Do not use abrasive cleaners or immerse the motor unit in water.
5. **Dry Thoroughly:** Ensure all parts are completely dry before reassembling or storing to prevent rust and mildew.
6. **Storage:** Store the mixer-grinder and its accessories in a clean, dry place.

6. TROUBLESHOOTING

- **Appliance Not Starting:**
 - Check if the power cord is securely plugged into the outlet.
 - Ensure the jar is correctly placed and locked onto the motor unit.
 - Verify that the lid is securely locked onto the jar. The triple safety mechanism prevents operation if not properly assembled.
- **Burning Smell During Operation:**
 - A slight burning smell during the first few uses is normal due to motor varnish. This will subside.
 - If the smell persists or is strong, switch off the appliance immediately and allow it to cool down. Do not overload the mixer-grinder.
- **Excessive Noise:**
 - Mixer-grinders typically produce noise during operation. The Preethi Mystic operates at 80-90dB, similar to a hair dryer.
 - Ensure the unit is placed on a stable, flat surface. The wider base provides greater stability.
 - Check if the jar and lid are properly secured.
- **Jar Leakage:**
 - Ensure the lid is properly seated and locked.
 - Do not overfill the jar beyond the maximum fill line.
 - Check the rubber gasket/seal for proper placement and any damage. Replace if necessary.

- **Motor Overheating:**

- If the motor stops due to overheating, switch it off and unplug. Allow it to cool for at least 20-30 minutes before attempting to use it again.
- Reduce the load or add more liquid if grinding thick mixtures.

7. SPECIFICATIONS

| | |
|---------------------------------------|---|
| Brand | Preethi |
| Model Name | Mystic |
| Wattage | 750 watts |
| Voltage | 230 Volts (AC) |
| Number of Jars | 3 (1.5L, 1L, 0.5L) |
| Material | Stainless Steel (Jars & Blades) |
| Controls Type | Knob Control (Pulse, 0, 1, 2, 3) |
| Special Features | Safety Lock, Hands-Free Grinding, 3D Air Cooling Technology |
| Product Dimensions (D x W x H) | 62.5D x 74.5W x 29H centimetres |
| Item Weight | 12000 Grams |
| Dishwasher Safe | No |

8. WARRANTY AND SUPPORT

Warranty:

This Preethi Mystic Mixer-Grinder comes with a **2-year warranty on the product** from the date of purchase. Please retain your purchase receipt as proof of warranty.

The motor is covered by a **5-year motor warranty**, as indicated on the product packaging and overview.

The warranty covers manufacturing defects under normal household use. It does not cover damage resulting from misuse, neglect, accident, alteration, or unauthorized repair.

Customer Support:

For any service, repair, or warranty claims, please contact Preethi customer support. Refer to the contact information provided in your product packaging or visit the official Preethi website for assistance.