Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Jobar JB8099

Jobar JB8099 Digital Body Weight Bathroom Scale with Extendable Display User Manual

Model: JB8099

1. Introduction

Thank you for purchasing the Jobar International Digital Body Weight Bathroom Scale with Extendable Display. This scale is designed to provide accurate body weight measurements with the convenience of an adjustable display for easy viewing. Please read this manual thoroughly before use to ensure proper operation and maintenance.

2. Important Safety Information

- Always place the scale on a hard, flat, and stable surface. Avoid carpets or uneven flooring, as this can affect accuracy.
- Do not use the scale on wet or slippery surfaces. Ensure the scale surface is dry before stepping on it.
- Do not jump on the scale. Step on and off gently.
- The maximum weight capacity for this scale is 550 lbs (approximately 250 kg). Do not exceed this limit.
- Keep the scale away from extreme temperatures and direct sunlight.
- This scale is for personal use only and not intended for medical diagnosis or treatment.
- Keep batteries out of reach of children.

3. Package Contents

Ensure all items are present before assembly:

- Digital Body Weight Bathroom Scale Platform
- Extendable Display Pole with Digital Display
- Base for Display Pole
- Connection Cable
- User Manual (this document)

4. Setup and Assembly

1. **Install Batteries:** Locate the battery compartment on the underside of the digital display unit. Insert 2 AAA batteries (not included), ensuring correct polarity (+/-). Close the battery compartment securely.
2. **Assemble Display Pole:**
    - Attach the digital display unit to the top of the extendable pole.
    - Secure the base for the display pole to the bottom of the extendable pole.
    - Carefully route the connection cable from the digital display through the pole and connect it to the port on the scale platform. Ensure the cable is not pinched or strained.
3. **Position the Scale:** Place the scale platform on a firm, flat, and level surface. Ensure the display pole is stable and upright.
4. **Adjust Display Height:** The telescoping pole allows adjustment of the display height from 23" to 46". Loosen the locking mechanisms on the pole, adjust to your desired height, and then securely tighten the locks.





Image 1: Fully assembled Jobar Digital Body Weight Bathroom Scale. This image shows the scale platform and the extendable display pole with the digital screen.






Image 2: Diagram illustrating the dimensions of the Jobar Digital Body Weight Bathroom Scale, including the 13" x 15" platform and the adjustable height of the display pole.

5. Operating Instructions

1. **Power On:** Gently tap the scale platform with your foot or press the power button on the display unit. The display will light up and show "0.0 lb" (or "0.0 kg" depending on the last setting).
2. **Select Measurement Unit:** If you wish to change the unit of measurement (pounds or kilograms), press the unit button (often located near the power button or on the back of the display). The display will toggle between "lb" and "kg".
3. **Weighing:** Once "0.0" is displayed, step onto the center of the scale platform with bare feet. Stand still and distribute your weight evenly.
4. **Read Measurement:** Your weight will be displayed on the digital screen. The reading will stabilize and then flash a few times before locking.
5. **Power Off:** The scale will automatically turn off after a few seconds of inactivity to conserve battery life. You can also press and hold the power button to manually turn it off.



Image 3: A close-up view of the digital display, showing a clear weight reading in pounds. The power button is visible below the screen.

6. Care and Maintenance

- **Cleaning:** Wipe the scale surface with a soft, damp cloth. Do not use abrasive cleaners or immerse the scale in water.
- **Storage:** Store the scale in a cool, dry place. Avoid placing heavy objects on the scale when not in use.
- **Battery Replacement:** Replace batteries when the low battery indicator appears on the display. Always use 2 new AAA batteries.
- **Cable Care:** Ensure the connection cable between the platform and the display is not twisted, pulled, or damaged. Handle the display pole gently when adjusting its height to prevent cable issues.

7. Troubleshooting

Problem	Possible Cause	Solution
Inaccurate Readings	Scale is on an uneven surface (e.g., carpet). Scale has been moved recently. Initial calibration required.	Place the scale on a hard, flat floor (tile or wood). Allow the scale to settle for a few minutes after moving it. Step on the scale briefly to turn it on, then step off and wait for "0.0" before weighing yourself.

Problem	Possible Cause	Solution
Display Not Working / Blank Screen	Low or dead batteries. Batteries inserted incorrectly. Loose connection cable.	Replace with 2 new AAA batteries. Check battery polarity (+/-). Ensure the connection cable is securely plugged into both the display and the scale platform.
"Err" Message on Display	Weight exceeds maximum capacity (550 lbs). Scale malfunction.	Ensure the weight is within the scale's capacity. Step off the scale, wait for it to reset to "0.0", and try again. If the error persists, contact customer support.
Display numbers are partial or incorrect	Low batteries. Faulty display unit or connection.	Replace batteries. If the issue persists, ensure the cable is not damaged and is properly connected.

8. Specifications

- **Model:** JB8099
- **Brand:** Jobar International
- **Weight Capacity:** Up to 550 lbs (250 kg)
- **Display Type:** LCD with backlight
- **Platform Material:** Tempered Glass
- **Platform Dimensions:** 13" x 15"
- **Display Height Adjustment:** 23" to 46"
- **Power Source:** 2 x AAA Batteries (not included)
- **Measurement Units:** Pounds (lb), Kilograms (kg)
- **Item Weight:** Approximately 7.98 lbs

9. Warranty and Customer Support

For warranty information or customer support, please refer to the product packaging or contact Jobar International directly. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07P75ML7L

More documents and user manuals: **https://manuals.plus/**