

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Siku](#) /

› [Siku 3560 Wacker Neuson EW65 Mobile Excavator User Manual](#)

Siku 3560

Siku 3560 Wacker Neuson EW65 Mobile Excavator User Manual

Model: 3560 | Brand: Siku

INTRODUCTION

This manual provides essential information for the proper use, setup, operation, and maintenance of your Siku 3560 Wacker Neuson EW65 Mobile Excavator model. Please read this manual thoroughly before use to ensure safe and optimal performance.

Important Safety Information:

Choking hazard. Small parts. Not suitable for children under 36 months.

WHAT'S IN THE BOX

Upon opening the packaging, please verify that all components are present and undamaged.

- 1 x Wacker Neuson EW65 mobile excavator model



Image: The Siku 3560 Wacker Neuson EW65 Mobile Excavator model displayed within its retail box, showing the product clearly visible through a transparent window.

SETUP

The Siku 3560 Wacker Neuson EW65 Mobile Excavator is a ready-to-use model and requires minimal setup.

1. **Unboxing:** Carefully remove the excavator model from its packaging. Ensure no small parts are left behind in the box.
2. **Inspection:** Inspect the model for any visible damage or loose parts. If any issues are found, refer to the troubleshooting section or contact support.
3. **Placement:** Place the model on a flat, stable surface for display or play.



Image: A detailed view of the Siku 3560 Wacker Neuson EW65 Mobile Excavator, showcasing its yellow excavator arm, grey cabin,

and black wheels.

OPERATING INSTRUCTIONS

The Siku 3560 Wacker Neuson EW65 Mobile Excavator is designed for interactive play and display. Its features allow for realistic movements.

- **Rotating Machine:** The upper part of the excavator, including the cabin and arm, can be rotated manually 360 degrees on its chassis.
- **Movable Pusher Blade:** The front pusher blade can be manually raised and lowered. This feature is typically used for leveling ground or stabilizing the excavator during operation.
- **Excavator Arm and Bucket:** The multi-jointed excavator arm can be manually extended, retracted, and articulated at its various pivot points. The bucket at the end of the arm can also be tilted to simulate digging and dumping actions.
- **Rubberised Tires:** The model features rubberised tires, allowing for smooth movement across various surfaces. The excavator is designed to be pushed or pulled manually.



Image: The Siku 3560 Wacker Neuson EW65 Mobile Excavator viewed from the rear-side, showing the full extension of its yellow arm and the detailed bucket.




Image: A close-up of the Siku 3560 Wacker Neuson EW65 Mobile Excavator's arm, highlighting the articulation points and hydraulic cylinders.



Image: An overhead view of the Siku 3560 Wacker Neuson EW65 Mobile Excavator, focusing on the detailed cabin and the chassis with its wheels and front blade.

MAINTENANCE

To ensure the longevity and appearance of your Siku 3560 Wacker Neuson EW65 Mobile Excavator, follow these

simple maintenance guidelines:

- **Cleaning:** Wipe the model regularly with a soft, dry cloth to remove dust and dirt. For stubborn marks, a slightly damp cloth can be used, but avoid excessive moisture.
- **Storage:** Store the model in a cool, dry place away from direct sunlight and extreme temperatures to prevent material degradation.
- **Handling:** Handle the model with care, especially the movable parts, to prevent accidental damage. Avoid dropping or applying excessive force to the components.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Stiff or difficult-to-move parts (arm, bucket, blade)	Accumulation of dust or debris in joints; infrequent use.	Gently clean the joints with a soft brush or dry cloth. Avoid using lubricants.
Loose or detached small parts	Rough handling; manufacturing defect.	If parts are designed to be detachable, reattach them carefully. For broken or permanently detached parts, contact Siku customer support.
Scratches or paint chips	Normal wear and tear from play; abrasive contact.	These are typically cosmetic and do not affect functionality. No specific solution is provided by the manufacturer for touch-ups.

SPECIFICATIONS

- **Model Number:** 3560
- **Product Type:** Mobile Excavator Model
- **Scale:** 1:50
- **Materials:** Metal with plastic parts
- **Item Weight:** 4.9 ounces (approx. 139 grams)
- **Manufacturer:** SIKU
- **Recommended Age:** 36 months - 3 years (Note: Contains small parts, choking hazard)
- **Key Features:** Rotating machine, movable pusher blade, movable excavator arm with bucket, rubberised tires.

WARRANTY AND SUPPORT

For information regarding warranty coverage, product support, or to inquire about replacement parts, please contact Siku customer service directly. Refer to the official Siku website or product packaging for the most current contact details.

Manufacturer: SIKU

Model: 3560

Release Date: September 30, 2019

