



[Manuals.plus](#) /

> [OOTORI](#) /

> OOTORI Full Body Electric Massage Chair User Manual (Model B07P85DTM8)

## OOTORI B07P85DTM8

# OOTORI Full Body Electric Massage Chair User Manual

Model: B07P85DTM8

## 1. INTRODUCTION

---

Thank you for choosing the OOTORI Full Body Electric Massage Chair. This manual provides essential information for the safe and effective use, setup, operation, and maintenance of your massage chair. Please read this manual thoroughly before use and retain it for future reference.

This massage chair is designed to provide a comprehensive massage experience, featuring zero gravity positioning, shiatsu massage techniques, heat therapy, and foot rollers to help relieve muscle tension and promote relaxation.

## 2. SAFETY INFORMATION

---

### Important Safety Instructions:

- Always unplug the chair from the electrical outlet immediately after use and before cleaning.
- Do not use the chair in a wet or damp environment.
- Keep children away from the chair, especially during operation.
- Consult a physician before using the chair if you have medical conditions such as heart disease, pregnancy, osteoporosis, or are undergoing medical treatment.
- Do not use the chair for more than 30 minutes at a time to prevent overheating or over-stimulation.
- Never insert any objects into openings or drop them into the chair.
- Do not attempt to repair or disassemble the chair yourself. Contact qualified service personnel.
- Ensure the power cord is not damaged or pinched.

## 3. SETUP AND ASSEMBLY

---

The OOTORI massage chair requires some assembly. Please follow these general steps. Refer to the separate assembly manual for detailed, step-by-step instructions and diagrams.

1. **Unpack Components:** Carefully remove all parts from the packaging. Ensure all components are present according

to the packing list.

2. **Attach Armrests:** Securely attach the left and right armrests to the main body of the chair using the provided hardware.
3. **Connect Legrest:** Attach the legrest assembly to the main chair frame.
4. **Connect Cables:** Connect any internal cables between the chair components as instructed in the assembly manual.
5. **Position Chair:** Place the chair on a flat, stable surface, ensuring adequate space around it for recline and operation.
6. **Power Connection:** Plug the power cord into a grounded electrical outlet.



Image: The OOTORI Full Body Electric Massage Chair, ready for use in a living space.

## 4. OPERATING INSTRUCTIONS

---

Familiarize yourself with the remote control and its functions before operating the chair.

### 4.1 Power On/Off

Press the 'Power' button on the remote control to turn the chair on or off.

## 4.2 Zero Gravity Function

The zero gravity position elevates your legs above your heart, reducing pressure on your spine and enhancing the massage experience. Press and hold the dedicated 'Zero Gravity' button on the remote to automatically recline the chair into this position.




Image: Illustration of the Zero Gravity position, showing how the heart is lower than the legs for a weightless sensation.

## 4.3 Massage Modes and Programs

The chair offers various massage techniques and pre-programmed automatic sessions:

- **Massage Techniques:** Kneading, Knocking, Tapping, Shiatsu, Air Pressure, Heating.
- **Pre-set Auto Programs:** Choose from 5 different automatic massage programs, each designed with a unique combination of techniques and intensities for a varied experience.

QUASI-REAL MASSAGE

# SIMULATOR MASTER

SIMULATED MASTERING TECHNIQUES SUCH AS  
KNEADING AND MASSAGE




Image: Visual representation of simulated massage techniques including kneading, general massage, and positive reversal.

## 4.4 Targeted Massage Areas

The chair features a curved rail massage system and manipulators designed to target specific body areas:

- **Neck and Shoulder Massage:** Rollers and airbags target the upper back and neck.
- **Waist Massage:** Focuses on the lumbar region.
- **Buttock Massage:** Provides relief to the gluteal area.
- **Arm Massage:** Airbags gently compress the arms.
- **Leg Massage:** Airbags and rollers work on calves and feet.

# Curved rail massage




Image: Illustration of the curved rail massage system, highlighting its reach from neck to buttocks.



Image: Cutaway view of the massage chair indicating shoulder, manipulator, arm, and leg massage zones.

#### **4.5 Customization**

You can customize the massage experience by adjusting the type, intensity, speed, and specific location of the massage rollers using the remote control.

#### **4.6 Heat Function**

Activate the lower-back heat function for soothing warmth during your massage session. This feature can be turned on or off via the remote control.

#### **4.7 Bluetooth Audio**

The chair includes integrated Bluetooth speakers. Pair your mobile device to enjoy music during your massage. Refer to your device's Bluetooth pairing instructions.

**BLUETOOTH SURROUND SOUND**

Enjoy high-quality music while massaging, both physically and mentally.

**WIRELESS BLUETOOTH**

Can be connected to the phone to play  
Follow the music to enjoy the massage

**HIFI HIGH FIDELITY**

High fidelity music playback  
Quietly enjoy the massage

Image: Illustration of the Bluetooth surround sound system, demonstrating wireless connectivity for music playback.

## 5. MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your massage chair.

### 5.1 Cleaning

- Always unplug the chair before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- For fabric areas, use a mild upholstery cleaner if necessary, testing on an inconspicuous area first.
- Ensure no liquid enters the internal components.

### 5.2 Storage

When not in use for extended periods, store the chair in a cool, dry place, away from direct sunlight and extreme temperatures. Cover the chair to protect it from dust.

## 6. TROUBLESHOOTING

---

If you encounter any issues with your massage chair, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair does not power on.	Power cord unplugged, power outlet malfunction, main power switch off.	Check power cord connection. Test outlet with another device. Ensure main power switch (if present) is on.
Massage function not working.	Program not selected, safety feature activated, remote control issue.	Select a massage program. Ensure no obstructions. Check remote control batteries.
Unusual noise during operation.	Normal operational sounds, loose component, foreign object.	Some mechanical sounds are normal. Check for loose parts or objects. If noise is excessive or unusual, discontinue use and contact support.
Remote control unresponsive.	Low batteries, remote out of range, signal obstruction.	Replace batteries. Ensure remote is pointed at the chair's receiver. Remove any obstructions.

If the problem persists after attempting these solutions, please contact OOTORI customer support.

## 7. SPECIFICATIONS

---

- **Brand:** OOTORI
- **Model:** B07P85DTM8
- **Color:** Grey
- **Special Feature:** Automatic programs, Zero Gravity, Heat, Foot Rollers
- **Unit Count:** 1.0 Count
- **Pattern:** Solid
- **Room Type:** Indoor
- **Age Range (Description):** Adult
- **Arm Style:** With arms
- **Form Factor:** Ergonomic
- **UPC:** 759675637249
- **Manufacturer:** Ruilaigesi
- **Date First Available:** January 24, 2019

## 8. WARRANTY AND SUPPORT

---

For warranty information, product support, or service inquiries, please refer to the warranty card included with your purchase or visit the official OOTORI website. Keep your purchase receipt as proof of purchase for warranty claims.

**Contact Information:** Please refer to the contact details provided in your product packaging or on the official OOTORI brand store page for customer service assistance.

**Online Store:** [OOTORI Store on Amazon](#)

