

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Casio](#) /
- › [Casio Enticer LTP-2089L-7AVDF Women's Analog Watch User Manual](#)

Casio LTP-2089L-7AVDF

Casio Enticer LTP-2089L-7AVDF Women's Analog Watch User Manual

Model: LTP-2089L-7AVDF

[Overview](#) [Setup](#) [Operation](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. PRODUCT OVERVIEW

The Casio Enticer LTP-2089L-7AVDF is an elegant analog watch designed for women, featuring a white dial and a genuine leather band. This timepiece combines classic aesthetics with practical functionality, including multiple sub-dials for date, day, and 24-hour indication. It is built with an ion-plated case and mineral glass for durability, offering 50-meter water resistance suitable for daily use.




Figure 1.1: Casio Enticer LTP-2089L-7AVDF watch. This image displays the watch's overall design, including the white dial, sub-dials, and beige leather strap.

2. INITIAL SETUP

2.1 Unpacking and Inspection

Carefully remove the watch from its packaging. Inspect the watch for any visible damage. Ensure the crown is pushed in completely to start the watch if it is not already running.

2.2 Setting the Time

1. Pull the crown out to the second click position. The second hand will stop.
2. Rotate the crown to set the hour and minute hands. When setting the minute hand, advance it four or five minutes past the desired time, then turn it back to the exact time.
3. Push the crown back in to the normal position. The second hand will resume movement.

2.3 Setting the Date and Day

1. Pull the crown out to the first click position.
2. Rotate the crown to adjust the date and day indicators. Turn the crown clockwise to adjust the date and counter-clockwise to adjust the day.
3. Set the date and day for the previous day. For example, if today is the 10th, set it to the 9th.
4. Pull the crown out to the second click position.
5. Advance the time by rotating the crown until the date and day change to the current day. Continue to set the correct time, ensuring the AM/PM is correctly set (the date changes at midnight).
6. Push the crown back in to the normal position.

2.4 Adjusting the Leather Band

The genuine leather band features a buckle closure. Adjust the buckle to a comfortable fit on your wrist, ensuring it is neither too tight nor too loose. The band should allow for slight movement without rotating freely.

3. OPERATING THE WATCH

3.1 Reading the Time

The watch displays time using three analog hands: hour, minute, and second. The main dial indicates the current time.

3.2 Reading the Date and Day

The watch features three sub-dials:

- **Date Indicator:** Displays the current day of the month.
- **Day Indicator:** A retrograde dial that indicates the day of the week.
- **24-Hour Indicator:** Shows the current time in a 24-hour format, useful for distinguishing AM/PM.

3.3 Water Resistance

This watch is rated for 50-meter (5 ATM) water resistance. This means it is suitable for everyday use and can withstand splashes, rain, and brief immersion in water. It is **not** suitable for swimming, diving, or showering with hot water, as steam can penetrate the seals.

4. CARE AND MAINTENANCE

4.1 Cleaning Your Watch

Wipe the watch case and mineral glass regularly with a soft, dry cloth to remove dirt and moisture. For the leather band, wipe it with a slightly damp cloth and allow it to air dry completely. Avoid using chemical cleaners or abrasive materials.

4.2 Battery Replacement

The watch is powered by an SR920SW battery with an approximate life of 3 years. When the watch stops or the second hand moves erratically, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and water resistance.

4.3 Water Resistance Precautions

- Ensure the crown is always pushed in completely to maintain water resistance.
- Do not operate the crown or pushers while the watch is wet or submerged in water.
- Avoid exposing the watch to extreme temperature changes, which can affect the water resistance seals.

4.4 Leather Band Care

Leather bands can deteriorate over time due to sweat, moisture, and direct sunlight. To prolong its life:

- Avoid prolonged exposure to direct sunlight or high temperatures.
- Remove the watch before showering or swimming.
- If the band gets wet, wipe it dry immediately and allow it to air dry naturally.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch not running	Battery depleted; Crown pulled out	Replace battery (professional service recommended); Push crown fully in
Incorrect time/date	Time/date not set correctly; Crown accidentally pulled out	Refer to Section 2.2 and 2.3 for setting instructions; Push crown fully in
Condensation inside watch	Exposure to extreme temperature changes; Water resistance compromised	Consult a professional watch technician immediately to prevent damage

6. SPECIFICATIONS

- **Model Number:** LTP-2089L-7AVDF
- **Case Material:** Ion plated metal
- **Band Material:** Genuine Leather
- **Glass:** Mineral Glass
- **Water Resistance:** 50 meters (5 ATM)
- **Movement:** Quartz
- **Accuracy:** ±20 seconds per month
- **Battery Type:** SR920SW
- **Approx. Battery Life:** 3 years
- **Case Dimensions (H×W×D):** 37 × 33.4 × 9.2 mm
- **Total Weight:** 38 g
- **Display Type:** Analog (3 hands: hour, minute, second)
- **Dials:** 3 dials (24-hour, date, retrograde day)



Figure 6.1: Watch dimensions. The image illustrates the watch case height of 37 mm, shown in comparison to a standard credit card (85.6mm x 53.98mm) for scale.

7. WARRANTY AND SUPPORT

7.1 Manufacturer's Warranty

This Casio watch comes with a 2-year manufacturer warranty from the date of purchase. An additional 6 months warranty is provided for products registered online.

How to Avail Warranty:

1. Register your product on <https://register.casio.in/>.
2. To claim your warranty, produce the original bill copy/invoice at an authorized Casio service center. The warranty card and stamp are not mandatory for online purchases.

7.2 Customer Support

For any service-related inquiries or feedback, please contact Casio India Customer Support:

- **Helpline Number:** 011-66999200
- **Email:** casiocare@casio.co.in