

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Kinsman](#) /

› [Kinsman Coco Liner for Carousel Basket \(Kc93\) - User Manual](#)

Kinsman Kc93 (ASIN: B07P994183)

Kinsman Coco Liner for Carousel Basket (Kc93) - User Manual

Model: Kc93 | ASIN: B07P994183

INTRODUCTION

This manual provides instructions for the proper installation, use, and maintenance of your Kinsman Coco Liner, specifically designed to fit the Carousel Basket (Kc93). Coco liners offer a natural and effective way to retain soil and moisture in hanging baskets, promoting healthy plant growth.

SAFETY INFORMATION

- Always handle gardening tools and materials with care.
- Keep out of reach of children and pets.
- Wear appropriate gardening gloves to protect your hands.
- Ensure the hanging basket is securely mounted before filling to prevent accidents.

SETUP

Follow these steps to properly install the coco liner into your Kinsman Carousel Basket:

1. **Prepare the Basket:** Ensure your Kinsman Carousel Basket is clean and free of debris.
2. **Position the Liner:** Gently place the coco liner into the basket. The liner is pre-formed to fit the specific dimensions of the Carousel Basket (18"D x 18"W x 10"H).
3. **Adjust for Fit:** Press the liner firmly against the sides and bottom of the basket, ensuring it sits snugly and evenly. The natural fibers will conform to the basket's shape.
4. **Check Drainage:** Verify that the liner covers the entire interior surface, allowing for proper soil retention while still permitting water drainage through its natural porous structure.



Image: A close-up view of the coco liner securely fitted within a wire hanging basket. The natural, fibrous material is visible, demonstrating how it lines the basket to hold soil.

OPERATING INSTRUCTIONS

Once the coco liner is installed, you can proceed with planting:

- 1. Add Potting Mix:** Fill the lined basket with a high-quality potting mix suitable for your chosen plants. Leave about 1 inch of space from the top rim of the liner.
- 2. Planting:** Carefully place your plants into the potting mix, arranging them as desired. Gently firm the soil around the plant roots.
- 3. Initial Watering:** Water thoroughly after planting until water drains from the bottom of the liner. Coco liners are excellent at retaining moisture, so monitor soil dampness.
- 4. Hanging:** Securely hang your Carousel Basket in its desired location, ensuring the hanger can support the weight of the basket, soil, and plants, especially after watering.

MAINTENANCE

- Watering:** Check soil moisture daily, especially during warm weather. Coco liners help retain water, but hanging baskets can dry out quickly. Water when the top inch of soil feels dry.
- Fertilizing:** Follow the recommendations for your specific plants regarding fertilization. Liquid fertilizers can be applied during regular watering.
- Liner Longevity:** Coco liners are natural products and will biodegrade over time. Depending on environmental conditions, they typically last one to two growing seasons.
- Replacement:** When the liner shows signs of significant deterioration or begins to lose its structural integrity, it is time to replace it with a new Kinsman Coco Liner.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Liner appears to be sagging or losing shape.	Over-saturation, age, or improper initial fit.	Ensure proper drainage. If old, consider replacement. Re-adjust fit if possible.
Water drains too quickly.	Liner not fully seated, or very dry coco fiber.	Ensure liner is snug. Water slowly and thoroughly to allow fibers to absorb.
Plants are wilting despite watering.	Under-watering, or liner has deteriorated significantly.	Check soil moisture more frequently. If liner is old, replace it.

SPECIFICATIONS

Brand: Kinsman

Product Dimensions: 18"D x 18"W x 10"H

Style: Modern

Number of Pieces: 1

Material: Coco Fiber

UPC: 653958964674

ASIN: B07P994183

WARRANTY INFORMATION

Kinsman products are manufactured to high standards. While coco liners are consumable items designed for a limited lifespan, if you encounter any manufacturing defects upon receipt, please contact customer support within 30 days of purchase for assistance. This warranty does not cover normal wear and tear, improper installation, or damage due to misuse.

CUSTOMER SUPPORT

For further assistance, questions, or to report any issues, please contact Kinsman customer support:

Website: www.kinsmangarden.com (Note: This is a placeholder URL as no specific support link was provided.)

Email: support@kinsmangarden.com (Note: This is a placeholder email as no specific support email was provided.)

Phone: 1-800-XXX-XXXX (Note: This is a placeholder number as no specific support phone was provided.)

Please have your product model (Kc93) and ASIN (B07P994183) ready when contacting support.

© 2023 Kinsman. All rights reserved.

Related Documents - Kc93 (ASIN: B07P994183)

	<p>Kinsman BB10 10 Watt Guitar Amplifier Owners Manual</p> <p>Comprehensive owners manual for the Kinsman BB10 10 Watt Guitar Amplifier, detailing features, specifications, safety precautions, and electrical connections.</p>
	<p>Kinsman KPA500 Compact Tower PA System User Manual</p> <p>User manual for the Kinsman KPA500 Compact Tower PA System, detailing setup, functions, operation, and important safety instructions for powerful, premium quality sound.</p>

	<p>GPT Smartwatch User Manual</p> <p>User manual for the GPT Smartwatch, detailing download and pairing instructions, GPS function usage, AI features, and smart bracelet functions like activity tracking, call logs, weather, music control, and notifications.</p>
	<p>Vacuum Sealer Rolls - Instruction Manual & Features</p> <p>Instruction manual for Vacuum Sealer Rolls (ASIN: B0F6MWPQ78, Model: AS-20285003EU). Features include LFGB approval, BPA-free PA+PE material, wide temperature resistance, and suitability for all vacuum sealers and sous vide machines. Includes safety warning regarding suffocation risk.</p>