JVC LT-75N7125

JVC 75 Inch 4K UHD Smart TV User Manual

Model: LT-75N7125

1. Introduction

This user manual provides comprehensive instructions for the setup, operation, maintenance, and troubleshooting of your new **JVC 75 Inch 4K UHD Smart TV**, Model **LT-75N7125**. Designed for an immersive viewing experience, this television features an edgeless display, 4K UHD HDR resolution, and integrated smart functionalities including official Hey Google, Netflix, and YouTube access. It also comes with built-in Bluetooth and WiFi connectivity, and an Android 6.0 operating system.
Please read this manual thoroughly before operating your television to ensure proper use and to maximize its performance and longevity. Keep this manual for future reference.

2. Safety Information

Always observe the following safety precautions to prevent electric shock, fire, or damage to the television.

- **Power Supply:** Ensure the power supply voltage matches the rating label on the TV. Do not overload power outlets.
- **Ventilation:** Do not block ventilation openings. Allow adequate space around the TV for proper airflow.
- **Liquid Exposure:** Do not expose the TV to rain or moisture. Do not place objects filled with liquids, such as vases, on the TV.
- **Cleaning:** Unplug the TV before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or aerosol cleaners.
- **Placement:** Place the TV on a stable, level surface. Avoid placing it in direct sunlight or near heat sources.
- **Lightning:** During lightning storms or when unused for long periods, unplug the TV from the power outlet.
- **Servicing:** Do not attempt to service the TV yourself. Refer all servicing to qualified service personnel.

3. Package Contents

Carefully unpack your JVC 75 Inch 4K UHD Smart TV and ensure all items are present. The package should contain:

- JVC 75 Inch 4K UHD Smart TV (Model: LT-75N7125)
- Remote Control
- Power Cable
- User Manual (this document)

- TV Stands (if applicable, for tabletop placement)
- Screws for TV Stands (if applicable)

If any items are missing or damaged, please contact your retailer or JVC customer support immediately.

4. Setup

4.1 Physical Installation

Before connecting any cables, decide on the placement of your TV. You can either use the included stands for tabletop placement or mount it on a wall (wall mount kit sold separately).

1. **Tabletop Placement:** Attach the TV stands to the designated slots at the bottom of the TV using the provided screws. Ensure they are securely fastened.
2. **Wall Mounting:** Refer to the instructions provided with your wall mount kit. Ensure the wall mount is compatible with the VESA mounting pattern of your TV.

4.2 Connecting Peripherals

Your JVC Smart TV offers various connectivity options:

- **HDMI:** Connect external devices such as Blu-ray players, gaming consoles, or set-top boxes using HDMI cables. Your TV supports multiple HDMI inputs.
- **USB:** Plug in USB drives for media playback.
- **Antenna/Cable:** Connect your antenna or cable TV source to the DVB-T2 input for terrestrial or cable broadcasts.
- **Audio Out:** Connect external sound systems or headphones.

4.3 Initial Power-On and Network Setup

1. Connect the power cable to the TV and then to a power outlet.
2. Press the power button on the TV or the remote control to turn it on.
3. Follow the on-screen instructions for initial setup, including language selection, time zone, and network configuration.
4. **WiFi Connection:** Select your home WiFi network from the list and enter the password.
5. **Bluetooth Pairing:** If prompted, you can pair Bluetooth devices like headphones or game controllers.
6. **Google Account:** Sign in with your Google account to access the full range of Android TV features, including app downloads from the Google Play Store.



This image displays the JVC 75 Inch 4K UHD Smart TV from the front, showcasing its edgeless design. The screen is active, displaying a high-resolution image of a scenic ocean view with a long bridge connecting landmasses, highlighting the television's impressive display capabilities.

5. Operating

5.1 Remote Control Functions

Familiarize yourself with the remote control for easy navigation:

- **Power Button:** Turns the TV on or off.
- **Navigation Pad (Up/Down/Left/Right/OK):** Used to navigate menus and select options.
- **Back/Home Buttons:** Return to the previous screen or the Android TV home screen.
- **Volume Up/Down:** Adjusts the sound level.
- **Channel Up/Down:** Changes TV channels.
- **Netflix/YouTube Buttons:** Direct access to these streaming applications.
- **Google Assistant Button:** Activates "Hey Google" voice commands for search, control, and information.

5.2 Smart TV Features

Your JVC Smart TV runs on Android 6.0, providing access to a wide range of applications and features:

- **Google Play Store:** Download and install additional apps, games, and content.
- **Built-in Chromecast:** Cast content from your smartphone, tablet, or computer directly to the TV.
- **Media Playback:** Play videos, music, and view photos from connected USB devices.
- **Browser:** Access the internet directly from your TV.

6. Maintenance

6.1 Cleaning the TV

- Always unplug the TV from the power outlet before cleaning.
- Use a soft, dry, lint-free cloth to wipe the screen and cabinet.
- For stubborn marks on the screen, lightly dampen the cloth with water or a specialized screen cleaner (ensure it's safe for LED screens) and wipe gently. Do not spray liquid directly onto the screen.
- Avoid using abrasive cleaners, waxes, or solvents as they can damage the finish.

6.2 General Care

- Do not place heavy objects on top of the TV.
- Avoid exposing the TV to extreme temperatures or humidity.
- If moving the TV, ensure it is properly supported and handled to prevent damage to the screen or internal components.

7. Troubleshooting

If you encounter issues with your TV, refer to the following common problems and solutions before contacting customer support.

Problem	Possible Cause	Solution
No Power	Power cable not connected; Power outlet not working.	Ensure power cable is securely plugged in. Test the outlet with another device.
No Picture / No Sound	Incorrect input source; Loose cable connections.	Press the "Input" or "Source" button on the remote to select the correct input. Check all cable connections (HDMI, antenna).
Poor Picture Quality	Weak signal; Picture settings incorrect.	Check antenna/cable connection. Adjust picture settings (brightness, contrast, sharpness) in the TV menu.
Cannot Connect to WiFi	Incorrect password; Router issues; TV too far from router.	Double-check WiFi password. Restart your router and modem. Move the TV closer to the router or use a WiFi extender.
Remote Control Not Working	Dead batteries; Obstruction between remote and TV.	Replace batteries. Remove any obstructions. Ensure you are pointing the remote directly at the TV's IR sensor.

If the problem persists after trying these solutions, please contact JVC customer support.

8. Specifications

Feature	Detail
Brand	JVC
Model Number	LT-75N7125
Screen Size	75 Inches (Note: Product specifications also list 65 Inches)
Display Technology	LED
Resolution	4K UHD (3840 x 2160)

Feature	Detail
Refresh Rate	120 Hz
Operating System	Android 6.0
Special Features	Browser, Hey Google, Netflix, YouTube, Built-in Bluetooth & WiFi, Chromecast Built-in
Connectivity Technology	HDMI, USB, WiFi, Bluetooth
Tuner	DVB-T2 Receiver Included
Aspect Ratio	16:9
Product Dimensions (L x W x H)	168D x 8W x 97H centimeters
Weight	25 kg
Included Components	Remote Control

9. Warranty and Support

Your JVC 75 Inch 4K UHD Smart TV comes with a **1 Year Full Warranty** from the date of purchase. This warranty covers manufacturing defects and ensures your product functions as intended under normal use.

For warranty claims, technical support, or any inquiries not covered in this manual, please contact JVC customer service. Keep your purchase receipt as proof of purchase for warranty validation.

For the most up-to-date support information, visit the official JVC website or refer to the contact details provided with your product packaging.

© 2024 JVC. All rights reserved.
JVC is a registered trademark.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question