

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Let's Play](#) /

› [Let's Play Bigfun BF-5301C 49-Key Electronic Piano Keyboard User Manual](#)

## Let's Play BF-5301C

# Let's Play Bigfun BF-5301C 49-Key Electronic Piano Keyboard User Manual

## 1. INTRODUCTION

Thank you for choosing the Let's Play Bigfun BF-5301C 49-Key Electronic Piano Keyboard. This instrument is designed to provide an engaging musical experience with features such as 16 tones, 8 rhythms, 6 demos, 5 percussions, and recording capabilities. It supports mobile/tablet connectivity and includes a rechargeable Li-ion battery for portable use. This manual provides essential information for setup, operation, and maintenance to ensure optimal performance and enjoyment.

## 2. SAFETY INFORMATION

- Keep the keyboard away from water and moisture to prevent electric shock or damage.
- Do not expose the unit to direct sunlight or extreme temperatures.
- Avoid dropping the keyboard or subjecting it to strong impacts.
- Use only the provided USB cable and compatible power adapters (e.g., mobile phone charger) for charging.
- This product is recommended for ages 3 years and up. Adult supervision is advised for younger children.
- If keys appear locked or jammed upon unpacking, gently pull each key out slowly to release them. This is a protective measure for safe transportation.

## 3. PACKAGE CONTENTS

Please check that all items are present in the package:

- Let's Play Bigfun BF-5301C 49-Key Electronic Piano Keyboard
- Microphone
- USB Charging Cable
- User Manual (this document)

## 4. PRODUCT OVERVIEW

Familiarize yourself with the main components and controls of your electronic piano keyboard.



Figure 4.1: The Bigfun BF-5301C keyboard, microphone, and USB cable.



Figure 4.2: Detailed view of the keyboard's control panel, highlighting various functions such as Tones, Rhythms, Demos, Record, Play, and Fill-in.

## 5. SETUP

## 5.1 Powering the Keyboard

The keyboard is equipped with a rechargeable Li-ion battery. To power the device:

- Connect the provided USB cable to the keyboard's USB port.
- Connect the other end of the USB cable to a compatible USB power source, such as an Android mobile phone charger, a computer's USB port, or a power bank.
- The keyboard will power on or begin charging.

## 5.2 Connecting the Microphone

To use the microphone:

- Locate the microphone input jack on the keyboard.
- Insert the microphone's plug firmly into the jack.

## 5.3 Initial Key Check

Upon first use, if any keys feel stiff or locked, gently pull each key upwards slowly. This is a factory setting to prevent damage during transit and will not harm the instrument.

# 6. OPERATING INSTRUCTIONS

---

## 6.1 Basic Functions

- **Power On/Off:** Press the 'Power' button to turn the keyboard on or off.
- **Volume Control:** Use the 'Volume' buttons to adjust the overall sound level.
- **Tempo Control:** Use the 'Tempo' buttons to adjust the speed of rhythms and demo songs.

## 6.2 Tones and Rhythms

- **Selecting Tones:** Press the 'Tone Select' button and then use the numbered keys or dedicated tone buttons (if available) to choose from 16 different instrument sounds.
- **Selecting Rhythms:** Press the 'Rhythm Select' button and then use the numbered keys or dedicated rhythm buttons to choose from 8 different rhythm patterns.
- **Percussions:** Press the 'Percussion' buttons to play 5 different percussion sounds.

## 6.3 Demo Songs

- **Playing Demos:** Press the 'Demo' button to cycle through the 6 pre-recorded demo songs.
- **Stop Demo:** Press the 'Stop' button to halt the demo playback.

## 6.4 Recording and Playback

- **Record:** Press the 'Record' button to begin recording your performance. Play notes on the keyboard.
- **Play:** After recording, press the 'Play' button to listen to your recorded sequence.
- **Program:** Use the 'Program' function to create custom rhythm sequences. Refer to the on-device labels for specific programming steps.

## 6.5 Special Functions

- **Fill-in:** While a rhythm is playing, press the 'Fill-in' button to add a short drum fill.
- **One Key for One Note:** This mode allows simplified play, where pressing any key will play the next note in a melody.

- **AUX-IN Function:** Connect your mobile phone, tablet, or MP3 player to the keyboard's AUX-IN port using an audio cable (not included) to play music or stories through the keyboard's speaker.
- **Microphone Use:** Once connected, the microphone allows you to sing along while playing the keyboard.

## 7. MAINTENANCE

---

- **Cleaning:** Wipe the keyboard surface with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the keyboard regularly.

## 8. TROUBLESHOOTING

---

- **No Sound:**
  - Ensure the keyboard is powered on.
  - Check the volume level and increase if necessary.
  - Verify that the microphone or AUX-IN cable is properly connected if using those features.
- **Keys Not Responding:**
  - If keys feel locked or jammed, gently pull them out as described in Section 5.3.
  - Ensure the keyboard is powered on.
- **Keyboard Not Charging:**
  - Check if the USB cable is securely connected to both the keyboard and the power source.
  - Try a different USB power source or cable to rule out a faulty component.
- **Distorted Sound:**
  - Reduce the volume level.
  - If using AUX-IN, check the volume level on the connected external device.

## 9. SPECIFICATIONS

---

Feature	Specification
Model Number	BF-5301C
Number of Keys	49
Tones	16 Selectable
Rhythms	8 Selectable
Demos	6 Pre-recorded
Percussions	5

Connectivity	AUX-IN, USB
Power Source	Rechargeable Li-ion Battery (included), USB DC Power
Headphones Jack	3.5mm Jack
Material	Plastic
Recommended Age	3 months and up (Manufacturer Recommended)

## 10. WARRANTY AND SUPPORT

---

For warranty information or technical support, please refer to the retailer where the product was purchased or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.