Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- **→ GE APPLIANCES** /
- > GE APPLIANCES GTW465ASNWW Top Load Washer Instruction Manual

GE APPLIANCES GTW465ASNWW

GE APPLIANCES GTW465ASNWW Top Load Washer Instruction Manual

Model: GTW465ASNWW | Brand: GE APPLIANCES

INTRODUCTION

This manual provides essential information for the safe and efficient operation of your GE 4.5 cuft DOE Top Load Washer, model GTW465ASNWW. Please read all instructions carefully before use.

KEY FEATURES

- GE 4.5 cuft DOE Top Load Washer White
- Model Number: GTW465ASNWW
- Item Package Dimension: 45.0" L x 40.0" W x 70.0" H
- Item Package Weight: 200.0 lb

SETUP AND INSTALLATION

Proper installation is crucial for the performance and safety of your washing machine. Ensure the unit is placed on a level surface and connected to appropriate water and power sources.

Dimensions: 1"D \times 1"W \times 1"H (Product Dimensions) - Note: Package dimensions are 45.0" L \times 40.0" W \times 70.0" H.

Weight: 147 pounds (Item Weight) - Note: Package weight is 200.0 lb.

For detailed installation instructions, including water hook-up, leveling, and electrical requirements, please refer to the comprehensive installation guide provided with your appliance.

OPERATING INSTRUCTIONS

Your GE Top Load Washer features intuitive knob controls for easy cycle selection and customization. Below are key aspects of its operation:

Control Panel Overview

The control panel features rotary knobs for Water Level, Temperature, Colors/Whites cycles, Options, and Auto Soak. Indicator lights show the current cycle status (Sensing/Fill, Soak, Wash, Rinse, Spin).



Figure 1: Detailed view of the washer's control panel, showing settings for water level, temperature, wash cycles, and options.

Loading the Washer

Load items loosely around the agitator for best cleaning results. Avoid overfilling the tub to ensure proper water circulation and agitation.



Figure 2: The spacious stainless steel drum with the agitator, designed for efficient washing.

Cycle Selection

Turn the central 'Colors' or 'Whites' knob to select from 14 standard cycles including DeepClean, Normal, Light, Delicates, Casuals, Speed Wash, Drain & Spin, Active Wear, Towels/Sheets, Jeans, and Bulky Items. Choose the cycle that best suits your laundry type.

Water Level and Temperature

- Water Level: Select Low, Medium, High, or Max. The Precise Fill option automatically adjusts water levels based on load size.
- Temperature: Choose from Tap Cold, Cold, Cool, Colors, Warm, or Hot. All cold rinses are available.

Options and Auto Soak

- **Options:** Includes 2nd Rinse, Extra Spin, 2nd Rinse + Extra Spin, Deep Rinse (select when adding fabric softener), and +2nd Rinse.
- Auto Soak: Set for 15 Min, 30 Min, 1 Hr, or 2 Hr to pre-soak heavily soiled items.

Start/Pause

Press the 'Start/Pause' button to begin or temporarily stop a cycle. Hold for 3 seconds to stop the cycle completely. The 'Lid Locked' indicator will illuminate when the lid is securely locked during operation.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your washing machine.

Cleaning the Washer

- Exterior: Wipe down the exterior surfaces with a soft, damp cloth. Avoid abrasive cleaners.
- Interior: Periodically run a 'Deep Clean' cycle with a washer cleaner or bleach (following product instructions) to prevent odor and residue buildup in the stainless steel basket.
- Dispenser: Clean the fabric softener and bleach dispensers regularly to prevent clogging.

TROUBLESHOOTING

If you encounter issues with your washer, consider the following common solutions:

- Washer not starting: Ensure the power cord is securely plugged in and the lid is fully closed and locked. Check if the 'Start/Pause' button was pressed.
- Excessive vibration/noise: Verify the washer is level and all four leveling legs are making firm contact with the floor. Redistribute the laundry load evenly around the agitator.
- Clothes not clean/too wet: Ensure you are using the correct amount of detergent for your load size and water hardness. Select an appropriate wash cycle and consider using the 'Deep Rinse' or 'Extra Spin' options for heavily soiled or bulky items. Avoid overloading the washer.
- Water level too low: If using Precise Fill, the washer senses the load size. For maximum water, select the 'Max' water level setting.

For more detailed troubleshooting steps or persistent issues, please refer to the complete user manual or contact customer support.

SPECIFICATIONS

Attribute	Value
Brand Name	GE APPLIANCES
Model Info	GTW465ASNWW
Item Weight	147 pounds
Product Dimensions	1 x 1 x 1 inches
Efficiency	High Efficiency
Capacity	4.5 Cubic Feet
Max Spin Speed	700 RPM
Installation Type	Freestanding

Color	White
Control Console	Knob
Standard Cycles	14
Access Location	Top Load
Voltage	120 Volts
Material Type	Stainless Steel
Date First Available	April 9, 2019

WARRANTY AND SUPPORT

This product comes with a manufacturer's warranty covering parts and labor. Please refer to the official documentation included with your appliance for specific warranty terms and conditions, as well as details on how to register your product.

For customer support, technical assistance, or service requests, please consult the contact information provided in your product's user manual or visit the official GE Appliances website.

© 2023 GE APPLIANCES. All rights reserved.

Related Documents - GTW465ASNWW



GE Appliances Fall Savings Event Rebate Offer - Up to \$500 Savings

Get up to \$500 back on qualifying GE Appliances, Café, and GE Profile kitchen and laundry products during the Fall Savings Event. Learn how to submit your rebate online or by mail.



GE Appliances Fall Savings Event: Up to \$500 Rebate

Details of the GE Appliances Fall Savings Event offering up to \$500 rebate on qualifying Café, GE Profile, and GE Appliances kitchen and laundry products. Includes offer dates, submission instructions, and eligible models.



GE GDF530PGM/PSM/PMM Dishwasher: Dimensions, Installation & Features

Detailed information on the GE GDF530PGM/PSM/PMM Dishwasher, including installation dimensions, electrical specifications, features, benefits, and model variations.



GE Appliances: Comprehensive Catalog of 2000 Home Appliances

Explore the 2000 GE Appliances product catalog, featuring innovative refrigerators, advanced cooking ranges, efficient dishwashers, high-performance washers and dryers, and more. Discover quality and design from America's #1 preferred appliance brand.



GE GTX52GASPWB 6.2 cu. ft. Gas Dryer: Installation, Dimensions, and Features

Comprehensive guide for the GE GTX52GASPWB 6.2 cu. ft. capacity gas dryer. Details dimensions, installation requirements, venting specifications, safety precautions, and key features like 5-year warranty and long vent capability.



<u>UVM9125STSS/DYBB/DYWW 1.2 Cu. Ft. Over-the-Range Low Profile Sensor Microwave Oven Installation and Features</u>

Installation dimensions, ventilation options, and key features of the GE UVM9125STSS/DYBB/DYWW 1.2 Cu. Ft. Over-the-Range Low Profile Sensor Microwave Oven. Includes details on ducting, electrical requirements, and product benefits like sensor cooking and LED lighting.