

Timex TW2R98000

Timex Fairfield Supernova Chronograph 41mm Watch TW2R98000 User Manual

Model: TW2R98000

INTRODUCTION

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Timex Fairfield Supernova Chronograph 41mm Watch, model TW2R98000. Please read this guide thoroughly to ensure proper use and care of your timepiece.

SETUP AND INITIAL ADJUSTMENT

Setting Time and Date

- Pull the Crown:** Gently pull the crown (located on the right side of the watch case) out to position 2.
- Set the Date:** Turn the crown clockwise or counter-clockwise to adjust the date.
- Pull the Crown Further:** Pull the crown out to position 3. The second hand will stop.
- Set the Time:** Turn the crown to set the hour and minute hands. To ensure accurate AM/PM setting, advance the hands past 12 o'clock; if the date changes, you are in the AM hours.
- Push the Crown In:** Once the time is set, push the crown back into position 1 to start the watch.

Adjusting the Mesh Bracelet

The stainless steel mesh bracelet features a fold-over clasp that can be adjusted for a comfortable fit. Consult a professional jeweler or refer to Timex's official website for detailed instructions on adjusting mesh bracelets, as improper adjustment can damage the clasp or bracelet.



Image: The watch's gray stainless steel mesh bracelet with its fold-over clasp. This image illustrates the type of bracelet that may require adjustment for proper fit.

OPERATING YOUR WATCH

Chronograph Functions

Your watch is equipped with a chronograph function for measuring elapsed time.

- **Start/Stop:** Press the top pusher (A) to start the chronograph. Press it again to stop.
- **Reset:** While the chronograph is stopped, press the bottom pusher (B) to reset all chronograph hands to zero.



Image: Side view of the watch, highlighting the crown and the two pushers (A and B) used for setting time and operating the chronograph functions.

INDIGLO® Night-Light with Night-Mode

The INDIGLO® Night-Light illuminates the entire watch dial for easy reading in low-light conditions.

- **Activate:** Press and hold the crown to activate the INDIGLO® Night-Light.
- **Night-Mode:** For continuous illumination for several seconds, press and hold the crown for three seconds. The light will remain on for a short period after releasing the crown.



Image: The Timex Fairfield Supernova Chronograph watch with its INDIGLO® Night-Light feature activated, illuminating the dial in a distinct blue glow for visibility in darkness.

MAINTENANCE AND CARE

Water Resistance

Your watch is water-resistant to 30 meters (3 ATM). This means it is suitable for splashes or brief immersion in water, but not for swimming, showering, or diving. Do not operate the crown or pushers when the watch is wet.

Cleaning

Wipe the watch case and crystal with a soft, damp cloth. For the mesh bracelet, a soft brush and mild soap solution can be used, followed by thorough rinsing and drying. Avoid harsh chemicals or abrasive materials.

Battery Replacement

The watch is powered by a quartz movement and requires a battery. The product specifications mention "1 AA batteries required. (included)". This is highly unusual for a wrist watch, which typically uses a small

button cell battery. If your watch requires a battery replacement, it is recommended to take it to an authorized Timex service center or a professional watch repairer to ensure the correct battery type is installed and water resistance is maintained.

TROUBLESHOOTING

- **Watch Not Running:**

Check if the crown is fully pushed in. If the watch still does not run, the battery may need replacement. Refer to the "Battery Replacement" section.

- **Incorrect Time/Date:**

Ensure the crown is fully pushed in after setting. If the time or date consistently falls behind or advances, the battery may be low, or the movement may require servicing.

- **Chronograph Hands Not Resetting to Zero:**

If the chronograph hands do not return to their zero position after pressing the reset pusher, a calibration may be needed. Consult a professional watch repairer or Timex support for assistance.

- **INDIGLO® Night-Light Not Working:**

Ensure the crown is pressed firmly. If it still does not illuminate, the battery may be low or depleted.

SPECIFICATIONS

Model Number	TW2R98000
Case Diameter	41 mm
Case Material	Gray low lead brass with stainless steel back
Movement	Quartz
Water Resistance	30 meters (3 ATM)
Functions	Hours, Minutes, Small Seconds, Chronograph, Date
Special Features	INDIGLO® Night-Light with Night-Mode
Strap Material	Gray stainless steel mesh bracelet
Battery Type	1 AA battery (as per product specifications; typically a button cell for wristwatches)



Image: Front view of the Timex Fairfield Supernova Chronograph 41mm watch, showcasing its gray dial, blue chronograph subdials, date window, and gray stainless steel mesh bracelet.

WARRANTY AND SUPPORT

Your Timex watch is covered by a limited warranty. For specific warranty terms, registration, and service inquiries, please visit the official Timex website or contact Timex customer support directly. Keep your proof of purchase for warranty claims.

Timex Official Website: www.timex.com

© 2023 Timex. All rights reserved. Information subject to change without notice.

Related Documents - TW2R98000

	<p><u>Timex Kids Digital Watch User Guide - Operation and Features</u></p> <p>Comprehensive user guide for the Timex Kids digital watch (model 791-095007). Covers features, basic operations, setting time and date, chronograph, alarm, timer, INDIGLO night light, water resistance, strap adjustments, battery information, and warranty details.</p>
	<p><u>Timex T100 User Guide: Operation, Features, and Maintenance</u></p> <p>Official user guide for the Timex T100 watch, detailing how to set time, date, use the chronograph, timer, alarms, Indiglo night-light, and information on water resistance and warranty.</p>
	<p><u>Timex W-191-AS Watch User Manual and Instructions</u></p> <p>Detailed instructions and user guide for the Timex W-191-AS digital watch, covering all features including time/date setting, chronograph, timer, interval timer, alarms, and INDIGLO night-light functionality. Includes warranty information.</p>
	<p><u>Timex W-209 Watch User Manual: Features, Operation, and Warranty</u></p> <p>Comprehensive guide to operating your Timex W-209 watch, covering time setting, chronograph, timer, alarms, occasions, INDIGLO night-light, water resistance, battery, and international warranty information.</p>
	<p><u>Timex Kids Digital Watch User Guide</u></p> <p>Comprehensive user guide for the Timex Kids Digital Watch (W33 791095007), covering operations, features, water resistance, and maintenance in multiple languages.</p>



[Timex Watch User Manual: Features, Operation, and Care](#)

Comprehensive user manual for Timex watches, detailing features like analog and digital time, multiple time zones, alarms, chronographs, timers, water resistance, and bracelet adjustment.