

[Manuals.plus](#) /

› [PlayBetter](#) /

› Swing Caddie SC300i Golf Launch Monitor User Manual

PlayBetter SC300i

Swing Caddie SC300i Golf Launch Monitor User Manual

Model: SC300i | Brand: PlayBetter

INTRODUCTION

The Swing Caddie SC300i Golf Launch Monitor is a portable device designed to provide golfers with precise, real-time data on their swing and ball flight. This bundle includes the SC300i Launch Monitor, a remote control, a USB charging cable, and a PlayBetter 5000mAh Portable Charger. It measures key metrics such as Carry/Total Distance, Smash Factor, Launch Angle, Swing Speed, Apex (Max Height), and Ball Speed, helping golfers to analyze and improve their game.




Image: The Swing Caddie SC300i Launch Monitor with its display showing various golf metrics, accompanied by a PlayBetter portable charger and mobile phone screens displaying the companion app.

SETUP GUIDE

Proper placement of the SC300i is crucial for accurate readings. Follow these guidelines for optimal performance:

1. **Power On:** Press the power button on the device to turn it on. The display will illuminate.
2. **Indoor Use:** For indoor practice with a net or screen, place the golf ball 6.5 feet away from the net/screen. Position the SC300i unit 5 feet directly behind the golf ball. This results in a total distance of 11.5 feet from the net/screen to the unit.
3. **Outdoor Use:** For outdoor practice, simply place the SC300i unit 5 feet directly behind the golf ball.
4. **Orientation:** Ensure the front of the SC300i unit (where the radar sensor is located) is facing directly towards the target area.
5. **Remote Control:** The included remote control allows for convenient adjustment of settings without needing to bend over.



Image: Rear view of the Swing Caddie SC300i, showing the integrated kickstand for stable placement during use.



Image: The remote control for the Swing Caddie SC300i, featuring buttons for mode selection, volume, loft adjustment, and club type selection.

OPERATING INSTRUCTIONS

The SC300i provides instant feedback on various golf metrics. Here's how to operate it and interpret the data:

Key Data Parameters:

- **Carry Distance:** The distance the ball travels through the air before landing.
- **Total Distance:** The total distance the ball travels, including roll.
- **Smash Factor:** A ratio of ball speed to clubhead speed, indicating efficiency of impact.
- **Launch Angle:** The initial angle of ascent of the golf ball immediately after impact.
- **Swing Speed:** The speed of the clubhead at impact.
- **Apex (Max Height):** The maximum height the ball reaches during its flight.

- **Ball Speed:** The speed of the golf ball immediately after impact.

Modes of Operation:

Use the remote control or the buttons on the device to switch between modes:

- **Practice Mode:** Displays all key data parameters after each shot.
- **Target Mode:** Allows you to set a target distance and practice hitting to that specific yardage.

Voice Output:

The SC300i features voice output that verbally announces your carry distance after each shot, providing immediate audible feedback.

MySwingCaddie App Integration:

Connect the SC300i to the MySwingCaddie App via Bluetooth for enhanced data analysis and tracking. The app stores all your swing data and videos, allowing you to review and compare session data and shot videos. You can also overlay lines on your swing video to analyze your motion.



Image: Close-up of the Swing Caddie SC300i's display, showing metrics like Carry, Swing Speed, Ball Speed, Launch Angle, Apex,

and Smash Factor.




Image: The Swing Caddie SC300i alongside a mobile phone displaying the MySwingCaddie app interface, showing shot data and video analysis capabilities.

MAINTENANCE

To ensure the longevity and optimal performance of your Swing Caddie SC300i, follow these maintenance tips:

- **Cleaning:** Wipe the device with a soft, dry cloth to remove dust and debris. Avoid using harsh chemicals or

abrasive materials.

- **Storage:** Store the unit in a cool, dry place when not in use. Protect it from extreme temperatures and direct sunlight.
- **Screen Protection:** Consider applying a screen protector to prevent scratches and damage to the display.
- **Charging:** Use the provided USB charging cable and the PlayBetter Portable Charger to keep your device powered. Avoid overcharging.



Image: A PlayBetter portable charger connected via USB-C to a mobile phone, illustrating the charging capability for the Swing Caddie SC300i and other electronics.

TROUBLESHOOTING

If you encounter issues with your Swing Caddie SC300i, try the following solutions:

- **No Reading/Inaccurate Readings:**

- Ensure the unit is placed at the correct distance (5 feet behind the ball for outdoor, 5 feet behind the ball and 6.5 feet from net for indoor).
- Verify the unit is properly aligned with the target.
- Check for any obstructions between the unit and the ball.
- Ensure the battery is sufficiently charged.
- Try turning the unit off and on again.

- **Remote Control Not Responding:**

- Check the remote control's battery.
- Ensure there are no obstructions between the remote and the unit.

- **Bluetooth Connectivity Issues:**

- Ensure Bluetooth is enabled on your mobile device.
- Restart both the SC300i and your mobile device.
- Forget the device in your mobile device's Bluetooth settings and re-pair.

SPECIFICATIONS

Feature	Detail
Item Package Dimensions L x W x H	9.65 x 8.5 x 3.62 inches
Package Weight	0.99 Kilograms
Item Dimensions LxWxH	1 x 6.5 x 4.5 inches
Brand Name	PlayBetter
Color	+Portable Charger
Manufacturer	Voice Caddie
Style	SC300i
Size	SC300i
Sport Type	Golf
ASIN	B08ZSBSWCL
Date First Available	January 1, 2021

WARRANTY AND SUPPORT

Specific warranty details and comprehensive support information for the Swing Caddie SC300i are typically provided in the full product manual included with your purchase or available on the official PlayBetter or Voice Caddie website. For technical assistance, product registration, or warranty claims, please refer to the manufacturer's official support channels.

Visit the [PlayBetter Store](#) for more information.