

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Link2Home](#) /
- › [Link2Home 25 ft. Cord Reel Extension Cord with 4 Power Outlets \(Model EM-EL-250E\) - Instruction Manual](#)

Link2Home EM-EL-250E

Link2Home 25 ft. Cord Reel Extension Cord

MODEL: EM-EL-250E

1. Introduction

This manual provides essential information for the safe and efficient use of your Link2Home 25 ft. Cord Reel Extension Cord. Please read all instructions carefully before operation and retain this manual for future reference.



Figure 1: Link2Home 25 ft. Cord Reel Extension Cord. This image shows the overall design of the cord reel, highlighting its compact, square shape and the four orange outlets on the front panel.

2. Safety Information

Always follow basic safety precautions to reduce the risk of fire, electric shock, and personal injury.

- **Do not overload:** Ensure the total current draw of connected devices does not exceed the cord reel's maximum rating.
- **Grounding:** This cord reel is equipped with a grounding plug. Only plug it into a properly installed and grounded outlet.
- **Indoor use only:** This product is designed for indoor use. Avoid exposure to moisture or wet conditions.
- **Uncoil completely:** For optimal performance and to prevent overheating, always uncoil the extension cord completely before use.
- **Keep away from children:** Store the cord reel out of reach of children.
- **Inspect before use:** Check the cord and outlets for any damage before each use. Do not use if damaged.

3. Product Features

- **4 Grounded Outlets:** Provides power for multiple devices.
- **25 ft. 16 AWG SJT Cable:** Durable and flexible cable for various applications.
- **Built-in Circuit Breaker:** Automatically cuts power when overloaded to protect connected devices.
- **ON/OFF Power Switch:** Conveniently control power to all outlets.
- **Easy Rewind Handle:** Integrated handle for smooth and tangle-free cord retraction.
- **Compact Design:** Unique four-handle design for easy transport and storage.

Link2Home



High-
Quality
Cable

SJT

- Thermoplastic insulation
- Hard Service Cord

Figure 2: Front panel detail showing the four grounded outlets, the ON/OFF power switch, and the safety/overload reset button.



Easy Rewind with Built-in Handle

Figure 3: Rear view of the cord reel, illustrating the integrated handle designed for easy and smooth cord rewinding.

4. Setup

1. **Unpack:** Carefully remove the cord reel from its packaging.
2. **Inspect:** Examine the cord reel for any signs of damage. Do not use if any damage is observed.
3. **Placement:** Position the cord reel on a stable, dry surface, away from heat sources or flammable materials.
4. **Plug In:** Insert the cord reel's main plug into a standard 120V grounded wall outlet.

5. Operation

1. **Extend the Cord:** Pull the desired length of the extension cord from the reel. Ensure the cord is fully uncoiled to prevent overheating, especially when drawing high power.
2. **Activate Power:** Press the ON/OFF power switch on the front panel to the 'ON' position. The indicator light will illuminate, showing power is active.
3. **Connect Devices:** Plug your appliances or tools into the four grounded outlets.
4. **Rewind the Cord:** When finished, unplug all devices and turn off the power switch. Use the integrated handle on the side of the reel to manually wind the cord back into the housing. This ensures tangle-free storage.

Video 1: This video demonstrates the key features and practical use of the Link2Home Cord Reel, including extending and retracting the cord, and connecting various devices.

Link2Home



24/7

CUSTOMER SERVICE



3-YEAR

LIMITED WARRANTY

Have questions about shipping or usage?

WE ARE HERE TO HELP!



Figure 4: The cord reel providing power to a vacuum cleaner, demonstrating its utility for household tasks.

6. Maintenance

- **Cleaning:** Disconnect the cord reel from the power source before cleaning. Wipe the exterior with a dry, soft cloth. Do not use liquid cleaners or immerse in water.
- **Storage:** Always rewind the cord completely before storing. Store in a cool, dry place away from direct sunlight and moisture.
- **Inspection:** Periodically inspect the cord and plug for cuts, fraying, or other damage. If damaged, discontinue use and replace the product.

7. Troubleshooting

If the cord reel stops providing power:

1. **Check Overload Protector:** The cord reel has a built-in circuit breaker (overload protector). If too many devices are connected or a device draws excessive power, the circuit breaker will trip, cutting off power.
2. **Reset:** Disconnect some devices to reduce the load. Press the red 'OVERLOAD' reset button on the front panel to restore power.
3. **Inspect Devices:** If the breaker trips repeatedly, check your connected devices for faults.

8. Specifications

Feature	Specification
Product Dimensions	5.2 x 7.1 x 7.1 inches
Item Weight	3 pounds
Item Model Number	EM-EL-250E
Brand	Link2Home
Color	Orange
Total Power Outlets	4
Voltage	120 Volts
Cable Type	16 AWG SJT
Cable Length	25 ft.
Special Feature	Compact
Manufacturer	Hongyi
Date First Available	March 1, 2019

9. Warranty and Support

This Link2Home Cord Reel is covered by a **3-Year Limited Warranty**. For warranty claims or technical assistance, please contact Link2Home customer service.

Customer Service: 24/7 support is available for any questions regarding shipping or usage. Please refer to the product packaging or the official Link2Home website for contact details.