

Canmore TW353

CANMORE TW353 Golf GPS Watch User Manual

Model: TW353

1. INTRODUCTION

The CANMORE TW353 Golf GPS Watch is designed to provide golfers with essential course information directly on their wrist. This lightweight and easy-to-use device comes preloaded with over 41,000 golf courses worldwide, offering features such as distance to green, hazard distances, shot distance measurement, and a digital scorecard. Its high-contrast display ensures readability even in bright sunlight.



Figure 1.1: The CANMORE TW353 Golf GPS Watch, featuring a black and gray design with a clear digital display.

2. SETUP

2.1 Initial Charging

Before first use, fully charge your CANMORE TW353 Golf GPS Watch using the included charging cable. Connect the cable to the watch and a standard USB power source. A full charge typically takes a few hours.

2.2 Course Data Updates

The watch comes preloaded with over 41,000 golf courses. To ensure you have the most current course data, it is recommended to update the watch regularly. Course data is updated biweekly and can be downloaded from the official CANMORE website. Connect your watch to a computer running Windows, Mac, or Linux to perform the

update.

2.3 GPS Connection

When starting Golf Mode, the watch will automatically search for nearby courses and connect to GPS satellites. The initial GPS connection may take 3-5 minutes. Subsequent connections typically take 30-90 seconds. For best results, activate Golf Mode as soon as you arrive at the golf course to allow sufficient time for satellite acquisition.

3. OPERATING INSTRUCTIONS

3.1 Golf Mode Activation

Upon entering Golf Mode, the watch will automatically detect the top 10 nearest courses. Select your desired course to begin playing. The watch will automatically advance holes as you progress through your round.

3.2 Display Information

The TW353 features a high-contrast monochrome display with backlights, ensuring readability in various lighting conditions, including direct sunlight.

- **Distance to Green:** Displays distances to the front, middle, and back of the green.
- **Hazard Distance:** Provides distances to various course hazards.
- **Shot Distance:** Measure the distance of your shots.
- **Scorecard:** Keep track of your score directly on the watch.



Figure 3.1: The watch display showing distances to the front, middle, and back of the green, along with the current hole and par.

Reach the Pin



Figure 3.2: The watch display showing distances to various course hazards, such as bunkers and water.



Figure 3.3: The watch display showing a measured shot distance.

4. MAINTENANCE

4.1 Cleaning

To clean your watch, wipe it with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the watch's finish or screen. The watch is sweatproof, but it is not designed for prolonged submersion in water.

4.2 Storage

Store the watch in a cool, dry place when not in use. Avoid extreme temperatures, which can affect battery life and performance.

5. TROUBLESHOOTING

Problem	Possible Cause	Solution
Slow GPS acquisition	Initial connection, poor satellite signal, outdated course data.	Ensure you are in an open area with a clear view of the sky. Allow 3-5 minutes for initial connection. Update course data regularly.
Watch freezes or loses connectivity	Software glitch, low battery, temporary signal loss.	Restart the watch. Ensure the battery is sufficiently charged. If issues persist, perform a firmware update via the CANMORE website.
Course not loading or incorrect yardage	Outdated course data, weak satellite connection.	Verify that your course data is up to date. Ensure a strong GPS signal. Try restarting Golf Mode.
Battery drains quickly	Frequent GPS usage, old battery.	Ensure the watch is fully charged before use. GPS mode consumes more power; standby mode offers longer battery life.

6. SPECIFICATIONS

Feature	Detail
Product Dimensions	5.08 x 4.06 x 1.52 cm
Weight	42.52 g
Item Model Number	TW-353B-CA
Batteries	1 Lithium Polymer battery (included)
Display Size	7 Inches (diagonal, referring to screen area for display)
Voice Command	Buttons
Manufacturer	CANMORE
Model Name	TW353
Special Feature	Bluetooth, Waterproof (sweatproof)
Connectivity Technology	Bluetooth, USB
Map Type	Worldwide (41,000+ preloaded courses)
Included Components	Canmore TW-353 golf watch, charging cable, user manual, quick start guide
Mounting Type	Wrist Mount
Operating System Compatibility	Windows, Mac, Linux (for updates)
Battery Life (GPS Mode)	Up to 11 hours

Feature	Detail
Battery Life (Standby Mode)	Up to 60 days

7. WARRANTY INFORMATION



The CANMORE TW353 Golf GPS Watch comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product functions as intended under normal use. Please retain your proof of purchase for warranty claims.





8. CUSTOMER SUPPORT

CANMORE offers 24/7 customer service to assist with any inquiries or issues you may encounter. Additionally, a life-long subscription for new course and course change updates is provided. For support or to download the latest course data, please visit the official CANMORE website or contact their customer service team.


Note: For the most up-to-date contact information and support resources, please refer to the CANMORE official website or the quick start guide included with your product.

Related Documents - TW353

	<p>The Grizzly Paw Menu - Craft Beer, Cocktails, Burgers & More in Canmore, Alberta</p> <p>Explore the full menu from The Grizzly Paw Brewing Company in Canmore, Alberta, featuring a wide selection of craft beers, signature cocktails, delicious burgers, pub bites, and more.</p>
	<p>The Grizzly Paw Menu - Craft Beer, Cocktails, Burgers & More in Canmore, Alberta</p> <p>Explore The Grizzly Paw's extensive menu featuring award-winning craft beers, signature cocktails, delicious burgers, sandwiches, appetizers, and house-made sodas. Located in Canmore, Alberta.</p>

	<p>Administrative Assistant Job Opportunity - RGO Flooring. Canmore AB</p> <p>RGO is hiring an Administrative Assistant for their Flooring Division in Canmore, Alberta. Discover the responsibilities, qualifications, and benefits of this full-time role. Apply now to join a leading interior solutions company.</p>
	<p>U.S. Paralympics Nordic Skiing World Cup Team Selection Criteria 2025-26</p> <p>Official selection criteria for the U.S. Paralympics Nordic Skiing World Cup Team for the 2025-26 season, detailing general requirements, specific event qualifications for World Cup events in Canmore, Finsterau, and Jakuszyce, and funding information.</p>
	<p>The Grizzly Paw Brewing Company Taproom Menu - Food & Drinks</p> <p>Explore the full food and drink menu from The Grizzly Paw Brewing Company's taproom, featuring seasonal brews, craft cocktails, pizzas, handhelds, small bites, and non-alcoholic options.</p>
	<p>BENKÉ Designer Heating Rails & Towel Rails - Product Catalog</p> <p>Explore the BENKÉ range of designer heating rails and towel rails, including models like Dorado, Sail, Square, Allegro, Boston, Capri, and more. View specifications, sizes, BTU outputs, codes, and prices for various finishes and dimensions. Also includes heating valves, elements, and pipe sleeves.</p>

Documents - Canmore – TW353



Troubleshooting

If any errors or malfunction occur, use factory reset at **SETTINGS** → **Factory Reset**. If that does not work, try hardware reset by pressing **3** + **2** together, and then press **1**. Release all three buttons at the same time.

Charge the Watch

Battery/ Charging Information
 Battery Specifications: 3.7V / 400mAh
 Charging Specifications: 5V / 500mA

Charge the charging contact as it frequently to ensure the charging efficiency.

- Attach the magnetic charger on the charging contacts located on the side of the watch. Be sure the pins are aligned. Keep the watch on a stable surface while charging.
- Insert the USB end of the charging cord into a computer USB port or CEFC certified 5V output USB charger (ensuring 5V will avoid the overcharge).

CAUTION
 Avoid touching the magnetic end of the charging cable with metal objects to prevent short-circuit and damage to the cable. For safety reasons, after the watch is fully charged, disconnect the charging cable from USB power source.

[\[pdf\]](#) Troubleshooting Guide Specifications Guide Warranty Accessories

Troubleshooting TW353 CANMORE Golf GPS Watch for Men and Women High Contrast LCD Display

Free Update Over 40 000 Preloaded Courses Worldwide Lightweight Essential Accessory Golfers Black Orange TW 353O CA Guide B07Z3BQ5CC B08GLNNJ1F B09CKFK2X3 B07PCMQQ7L B07SZBLZ87 B08GLNL5WB B07PBQTLTX 71A9X lxxML m media amazon images I |||

Troubleshooting If any errors or malfunction occur, use factory 11 08 SUN OCT 11 reset at **SETTINGS** **Factory Reset** . If that does not work, try hardware reset by pressing together, and then press . Release all three buttons at the same time.

Charge the Watch Battery/ Charging Informatio...

lang:en score:20 filesize: 158.07 K page_count: 1 document date: 2021-09-14

CANMORE

FR

AVERTISSEMENTS IMPORTANTS ET INFORMATIONS DE SÉCURITÉ

Avant de commencer, veuillez lire attentivement les autres instructions de sécurité connexes (reportez-vous au manuel imprimé dans l'emballage du produit).

⚠ AVERTISSEMENT

Le non-respect des consignes de sécurité pourrait entraîner un accident ou une collision entraînant la mort ou des blesses graves.

Autres avertissements relatifs à la batterie

- Il n'est autorisé ni d'entretenir ni d'insérer de nouvelles piles ni de remplacer les piles existantes.
- Si une pile est surchauffée, il vous est recommandé de ne pas utiliser le produit jusqu'à ce qu'il se soit refroidi.

Autres avertissements relatifs à l'appareil

- Touchez l'appareil avec précaution pour éviter tout dommage au produit.
- Ne portez pas de bijoux ou de vêtements qui pourraient s'accrocher au produit.
- Ne portez pas de bijoux ou de vêtements qui pourraient s'accrocher au produit.

Autres avertissements relatifs à l'utilisation

- Ne portez pas de bijoux ou de vêtements qui pourraient s'accrocher au produit.
- Ne portez pas de bijoux ou de vêtements qui pourraient s'accrocher au produit.

⚠ PRÉCAUTION

Le non-respect des consignes de sécurité pourrait entraîner des blessures mineures ou modérées.

Condition d'utilisation


- Ne portez pas de bijoux ou de vêtements qui pourraient s'accrocher au produit.
- Ne portez pas de bijoux ou de vêtements qui pourraient s'accrocher au produit.

Autres avertissements

- Ne portez pas de bijoux ou de vêtements qui pourraient s'accrocher au produit.
- Ne portez pas de bijoux ou de vêtements qui pourraient s'accrocher au produit.

TW-356 Golf Watch

User Guide




⚠ WARNING

Use only USB chargers with 5V output that comply with the CE/FCC standard. Using non-standard USB chargers will void the warranty.

82-356U-01010

TW-353 Golf Watch

User Guide



⚠ WARNING

Use only USB chargers with 5V output that comply with the CE/FCC standard. Using non-standard USB chargers will void the warranty.

82-353U-01010

	CANMORE TW-353	CANMORE TW-353	CANMORE TW-353	CANMORE TW-353	CANMORE TW-353
Produced in China	✓	✓	✓	✓	✓
Lightweight	✓	✓	✓	✓	✓
Waterproof	✓	✓	✓	✓	✓
GPS	✓	✓	✓	✓	✓
Bluetooth	✓	✓	✓	✓	✓
Heart Rate Monitor	✓	✓	✓	✓	✓
Battery Life	12 Days (GPS Off)	12 Days (GPS Off)	12 Days (GPS Off)	12 Days (GPS Off)	12 Days (GPS Off)

[\[pdf\]](#) Instructions Accessories

Frannie Informazioni sulla sicurezza CANMORE TW353 Orologio GPS da Golf per Uomo e Donna Display LCD ad Alto Contrasto Oltre 41 000 Campi Precaricati in Tutto il Mondo Accessorio Essenziale Leggero Nero Turchese Amazon it Sport tempo libero 81AsxpwEW7L m media amazon images I |||

AVERTISSEMENTS IMPORTANTS ET INFORMATIONS DE SCURIT Avant de commencer, veuillez lire attentivement les autres instructions de scurit connexes reportez-vous au manuel imprim dans l emballage du produit . Le non-respect des consignes de scurit pourrait entrainer un accident ou une collision entranant...

lang:fr score:19 filesize: 467.5 K page_count: 4 document date: 2024-06-20

[\[pdf\]](#) User Manual Instructions Guide Warranty Accessories

CANMORE TW353 Golf GPS Watch for Men and Women High Contrast LCD Display Free Update Over 41 000 Preloaded Courses Worldwide Lightweight Essential Accessory Golfers Black Gray Installation Manual B07Z3BQ5CC B08GLNNJ1F B09CKFK2X3 B08GLNL5WB B07SZBLZ87 B07PBQTLTX A1 fzm6pIL m media amazon images I |||

TW-356 Golf Watch User Guide WARNING Use only USB chargers with 5V output that comply with the CE/FCC standard. Using non-standard USB chargers will void the warranty. 82-356U-01010 GPS Locating Tips : Receive a GPS signal in an open space, and refer to the following instructions. GPS receiv...

lang:en score:17 filesize: 1.9 M page_count: 12 document date: 2023-05-31

[\[pdf\]](#) User Manual Instructions Guide Warranty Accessories

TW353 User Manual 2 CANMORE Golf GPS Watch for Men and Women High Contrast LCD Display Free Update Over 40 000 Preloaded Courses Worldwide Lightweight Essential Accessory Golfers Turquoise Gray Black Orange B07Z3BQ5CC B08GLNNJ1F B09CKFK2X3 B07PCMQQ7L B07SZBLZ87 B08GLNL5WB B07PBQTLTX TW 3530 CA A1wtVYRhBL m media amazon images I |||

TW-353 Golf Watch User Guide WARNING Use only USB chargers with 5V output that comply with the CE/FCC standard. Using non-standard USB chargers will void the warranty. 82-353U-01010 GPS Locating Tips : Receive a GPS signal in an open space, and refer to the following instructions. GPS receiv...


lang:en score:16 filesize: 1.96 M page_count: 12 document date: 2021-08-20

[\[pdf\]](#) Accessories

Comparson ý i3 2 Comparison chart CANMORE TW353 Golf GPS Watch for Men and Women High Contrast LCD Display Free Update Over 40 000 Preloaded Courses Worldwide Lightweight Essential Accessory Golfers Orange Amazon ca Electronics 61UMJ4PXHuL m media amazon images I |||

...


lang:en score:11 filesize: 112.39 K page_count: 1 document date: 2021-09-13

	
LCD	Sharp transfective panel Black & White LCD
LCD Size	23.04 x 23.04 (H x W in mm)
Resolution	128 x 128 Pixels
Waterproof	IPX7
Backlight	Single level
Operating temperature	0°-40°C
Voltage	DC 5V
Battery	Chargeable 400mAh lithium battery
Battery life	Golf Mode = up to 10 hours / Time Mode = up to 60 day
Interface	USB
Charger	USB interface, 300mA, 3 hours completed
Size	55.5 x 40.0 x 12.0 (L x W x H in mm)
Weight	42g

[pdf] Specifications Accessories

Specification Sheet TW353 CANMORE Golf GPS Watch for Men and Women High Contrast LCD Display Free Update Over 40 000 Preloaded Courses Worldwide Lightweight Essential Accessory Golfers Black Orange TW 353O CA B07Z3BQ5CC B08GLNNJ1F B09CKFK2X3 B07PCMQQ7L B07SZBLZ87 B08GLNL5WB B07PBQTLTX 61fbjsUmRzL m media amazon images I |||

LCD LCD Size Resolution Waterproof Backlight Operating temperature Voltage Battery Battery life Interface Charger Size Weight Sharp transfective panel Black White LCD 23.04 x 23.04 H x W in mm 128 x 128 Pixels IPX7 Single level 0- 40C DC 5V Chargeable 400mAh lithium battery Golf Mode = up to...
lang:en score:11 filesize: 124.51 K page_count: 1 document date: 2021-09-13



Troubleshooting

If any errors or malfunctions occur, use factory reset. If that does not work try hardware reset. Press ③+④ together, and then press ①. Release three buttons at same time.

Charge the Watch

Battery/ Charging Information
Battery Specifications: 3.7V / 400mAh
Charging Specifications: 5V / 500mA
Clean the charging contact pin frequently to ensure the charging efficiency.

- Attach the magnetic charge on the charging contacts located at the bottom of the watch. Be sure the pins are aligned. Keep the watch on a stable surface while charging.
- Insert the USB end of the charging cord into a computer USB port or CE/FCC certified 5V output USB charger (exceeding 5V will void the warranty).

CAUTION

Avoid touching the magnetic coil of the charging cable with metal objects to prevent short circuit, and damage to the cable. For safety reasons, after the watch is fully charged, disconnect the charging cable from USB power source.

[pdf] Troubleshooting Guide Specifications Warranty Accessories

Troubleshooting TW410HR CANMORE TW353 Golf GPS Watch for Men and Women High Contrast LCD Display Free Update Over 40 000 Preloaded Courses Worldwide Lightweight Essential Accessory Golfers Black Orange TW 353O CA Safety Information B07Z3BQ5CC B08GLNNJ1F B09CKFK2X3 B07PCMQQ7L B07SZBLZ87 B08GLNL5WB B07PBQTLTX 71 FbmVW6RL m media amazon images I |||
Troubleshooting If any errors or malfunctions occur, use factory reset. If that does not work try hardware reset. Press together, and then press . Release three buttons at same time. Charge the Watch Battery/ Charging Information Battery Specifications: 3.7V / 400mAh Charging Specificat...
lang:en score:10 filesize: 148.61 K page_count: 1 document date: 2021-09-14