

White Shark GCP-29 ICE Wizard

White Shark GCP-29 ICE Wizard Laptop Cooling Pad User Manual

1. INTRODUCTION

The White Shark GCP-29 ICE Wizard is a high-performance laptop cooling pad designed to enhance the thermal management of your laptop. It features five built-in fans and an ergonomic design to provide optimal airflow and a comfortable user experience. This manual provides essential information for the proper setup, operation, and maintenance of your cooling pad.

2. SAFETY INFORMATION

- Do not expose the cooling pad to water or excessive moisture.
- Avoid placing heavy objects on the cooling pad.
- Keep the cooling pad away from heat sources and direct sunlight.
- Do not attempt to disassemble or modify the device. Refer all servicing to qualified personnel.
- Ensure proper ventilation around the cooling pad during operation.

3. PACKAGE CONTENTS

Please check the package contents upon unboxing to ensure all items are present:

- White Shark GCP-29 ICE Wizard Laptop Cooling Pad
- USB Power Cable



Image: The White Shark GCP-29 ICE Wizard cooling pad as packaged in its retail box.

4. PRODUCT OVERVIEW

The GCP-29 ICE Wizard cooling pad features a robust design with a metal mesh surface for efficient heat dissipation. It includes five integrated fans with red LED illumination, providing effective cooling for laptops up to 17.3 inches.



Image: Top view of the cooling pad, showcasing the five illuminated red LED fans and the metal mesh surface.



Image: An angled view of the cooling pad from above, highlighting its geometric shape and fan placement.



Image: A detailed close-up of the cooling pad's surface, showing the metal mesh and the 'GAMING ONLY' inscription.

5. SETUP INSTRUCTIONS

1. **Unpack the Cooling Pad:** Carefully remove the cooling pad and USB cable from its packaging.
2. **Position the Cooling Pad:** Place the cooling pad on a flat, stable surface.
3. **Adjust Height (Optional):** The cooling pad features two adjustable height settings for ergonomic comfort. Locate the foldable stands on the underside of the pad and extend them to your desired height.



Image: The underside of the cooling pad, illustrating the adjustable stand mechanism for ergonomic positioning.

4. **Connect Power:** Connect one end of the provided USB cable to the USB port on the cooling pad and the other end to an available USB port on your laptop or a compatible USB power adapter. The cooling pad is plug-and-play and does not require external power or software installation.
5. **Place Your Laptop:** Carefully place your laptop on top of the cooling pad, ensuring it is centered and stable. The cooling pad is compatible with laptops up to 17.3 inches.

6. OPERATING INSTRUCTIONS

Once connected, the cooling pad's fans and red LED lights will activate automatically. The GCP-29 ICE Wizard features integrated controls for fan speed adjustment.

- **Fan Speed Control:** Locate the two rotary knobs on the side of the cooling pad. These controls allow you to adjust the speed of the fans. Turn the knobs to increase or decrease the fan speed according to your cooling needs.
- **LED Lights:** The red LED lights indicate that the fans are operational. Their intensity may vary with fan speed.



Image: A side view of the cooling pad, detailing the two USB ports and the rotary fan speed control knobs.

7. MAINTENANCE

- **Cleaning:** Regularly clean the metal mesh surface and fan blades to prevent dust accumulation, which can impede airflow. Use a soft, dry cloth or a can of compressed air.
- **Storage:** When not in use, store the cooling pad in a cool, dry place away from direct sunlight.
- **Avoid Liquids:** Do not use liquid cleaners directly on the cooling pad. If necessary, dampen a cloth slightly with water and wipe gently, then dry thoroughly.

8. TROUBLESHOOTING

- **Fans not spinning / LEDs not lighting up:**
 - Ensure the USB cable is securely connected to both the cooling pad and a functioning USB port on your laptop.
 - Try connecting the cooling pad to a different USB port or a different USB power source.
 - Check if the fan speed control knobs are turned up.
- **Insufficient cooling:**
 - Ensure the cooling pad's fans are free from dust and obstructions.
 - Verify that your laptop's vents are not blocked.
 - Increase the fan speed using the control knobs.
- **Unusual noise from fans:**
 - Check for any foreign objects obstructing the fan blades.
 - Ensure the cooling pad is on a flat, stable surface.

9. SPECIFICATIONS

Feature	Specification
Model	GCP-29 ICE Wizard
Brand	White Shark
Overall Dimensions	427 x 305 x 24 mm (16.81"L x 12.01"W x 0.94"H)
Material	ABS + PC Plastic with Metal Mesh
Number of Fans	5 (4 large, 1 small)
Large Fan Dimensions	140 mm
Small Fan Dimensions	70 mm
Fan Speed	2400 RPM \pm 10%
Noise Level	30 dB
Air Flow	100 CFM
Operating Voltage	DC 5V 380mA
Weight	800 g (1.76 lbs)
Compatibility	Laptops up to 17.3 inches
Power Source	USB Powered

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided with your purchase or contact your retailer. Keep your proof of purchase for warranty claims.

