

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- › [DICKIE TOYS](#) /
- › [DICKIE TOYS Parking Garage Playset \(Model 203749008\) Instruction Manual](#)

DICKIE TOYS 203749008

DICKIE TOYS Parking Garage Playset

Model: 203749008

INTRODUCTION

The DICKIE TOYS Parking Garage Playset offers an authentic multi-story car park experience for your toy car collection. Designed with four spacious levels, it provides ample parking for numerous toy cars, which can then descend quickly via the spiral ramp. This playset includes four high-quality die-cast cars with free-wheel action and a die-cast helicopter. Integrated light and sound effects enhance the play experience. A printed play base and required batteries are included.

PACKAGE CONTENTS

- 1 Car Park Playset with 4 Levels
- 4 Die-Cast Cars
- 1 Die-Cast Helicopter
- 1 Play Base
- 3 LR44 Batteries (included)



Image: The playset box illustrating the included components.

SAFETY INFORMATION

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

Always supervise young children during play. Ensure all parts are securely assembled before use. Keep batteries out of reach of small children.

ASSEMBLY INSTRUCTIONS

The DICKIE TOYS Parking Garage Playset requires adult assembly. Please follow the included graphical instructions carefully. Ensure all connections are firm to prevent parts from detaching during play.

1. Unpack all components from the box and verify against the package contents list.
2. Connect the main base sections to form the foundation of the playset.
3. Attach the vertical support pillars for the parking levels.
4. Secure each of the four parking levels onto the support pillars.
5. Assemble and attach the spiral ramp sections, ensuring they connect smoothly between levels.
6. Install the elevator mechanism into the main tower structure.

7. Attach any additional accessories such as the helipad, gas pumps, and seaport elements.
8. Insert the 3 LR44 batteries into the designated compartment for light and sound features.
9. Apply any decorative stickers as indicated in the assembly guide for enhanced realism.



Image: A complete view of the assembled parking garage playset.

OPERATING INSTRUCTIONS

1. Using the Elevator

Place a die-cast car onto the elevator platform at the ground level. Use the manual crank or lever (depending on model variation) to raise the elevator to any of the four parking levels. Once at the desired level, the car can be driven off the platform.



Image: A hand demonstrating the operation of the playset's elevator.

2. The Spiral Ramp

Cars can descend from any parking level via the continuous spiral ramp. Place a car at the top of the ramp and watch it roll down to the ground floor. Some sections of the ramp may feature movable barriers to

control car flow or create stopping points.



Image: A detailed view of the playset's spiral ramp.



Image: A die-cast car completing its descent down the spiral ramp.

3. Light and Sound Effects

The playset features light and sound effects for an immersive experience. These are activated by specific actions or buttons on the playset. Ensure batteries are correctly installed for these features to function.

4. The Helipad and Helicopter

The included die-cast helicopter can land on the designated helipad at the top of the playset. The helipad may also function as an activation point for certain playset features.

5. The Seaport Area

The playset includes a seaport area with a movable dock. This allows for imaginative play scenarios involving boats and cars interacting at the waterfront. The dock can be opened or closed to facilitate different play patterns.

CARE AND MAINTENANCE

- **Cleaning:** Wipe the playset with a damp cloth. Do not immerse in water. Avoid harsh chemicals.
- **Storage:** Store the playset in a dry, cool place away from direct sunlight to prevent material degradation.
- **Battery Replacement:** When light and sound effects diminish, replace the 3 LR44 batteries. Ensure correct polarity.

TROUBLESHOOTING

- **Lights/Sounds Not Working:** Check battery installation and ensure batteries are not depleted. Replace if necessary.
- **Cars Not Rolling Smoothly:** Ensure ramps and tracks are free from obstructions and properly connected. Clean any dust or debris.
- **Parts Detaching:** Re-secure any loose parts by firmly pressing them into place according to assembly instructions.

SPECIFICATIONS

- **Brand:** DICKIE TOYS
- **Model Number:** 203749008
- **ASIN:** B07PFFC9JX
- **Item Weight:** 5.94 pounds
- **Recommended Age:** 36 months - 15 years
- **Batteries:** 3 LR44 batteries (included)
- **Release Date:** March 4, 2020

WARRANTY AND SUPPORT




For warranty information or customer support, please refer to the contact details provided on the product packaging or visit the official DICKIE TOYS website. Keep your proof of purchase for any warranty claims.

Related Documents - 203749008



[Dickie Toys Parking Deck Playset - Interactive Toy Garage](#)

Explore the Dickie Toys Parking Deck playset, a multi-level toy garage with ramps and car accessories. Perfect for imaginative play and car enthusiasts.

 <p>RC TURBO RACER MCQUEEN</p> <p>D: Bedienungsanleitung EN: User Manual FR: Manuel d'utilisation NL: Bedienungshandleiding DE: Bedienungsanleitung ES: Manual de instrucciones IT: Istruzioni per l'uso PT: Manual de instruções HU: Használati útmutató RO: Manual de utilizare SK: Používateľská príručka SL: Uporabniški priročnik SV: Användarhandbok GR: Ηλεκτρονική Εγγραφή ES: Manual de instrucciones FR: Manuel d'utilisation NL: Bedienungshandleiding DE: Bedienungsanleitung ES: Manual de instrucciones IT: Istruzioni per l'uso PT: Manual de instruções HU: Használati útmutató RO: Manual de utilizare SK: Používateľská príručka SL: Uporabniški priročnik SV: Användarhandbok</p> <p>CE</p>	<p>RC Turbo Racer McQueen - Instruction Manual and Operation Guide</p> <p>Official instruction manual for the Dickie Toys RC Turbo Racer McQueen. Learn how to install batteries, operate the remote control, drive the car, use the turbo function, and troubleshoot common issues.</p>
	<p>Dickie Toys Walkie Talkie User Manual - Operating Instructions and Safety Guide</p> <p>User manual for Dickie Toys Walkie Talkie (models 20 111 8195, 8197, 8198, 8199). Features operating instructions, safety warnings, battery guidelines, disposal information, and compliance details.</p>
	<p>Dickie Toys RC Mining Excavator - Operating Instructions and Safety Guide</p> <p>Detailed operating instructions and safety precautions for the Dickie Toys RC Mining Excavator (Model 20 372 9018), including battery installation, operational features, safety warnings, and compliance information.</p>
 <p>A4 SIZE</p>	<p>Dickie Toys RC Sea Hawk 20 110 6012 - Operating Instructions and Safety Guide</p> <p>Detailed instructions for the Dickie Toys RC Sea Hawk (Model 20 110 6012), covering charging, remote control pairing, operation, safety precautions, and battery disposal.</p>
	<p>Dickie Toys Happy Fendt Hay Baler - Product Information</p> <p>Detailed product information for the Dickie Toys Happy Fendt Hay Baler, including features, safety instructions, and battery usage guidelines.</p>