Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YING RAY 2019030708

YING RAY Universal Air Conditioner Remote Control Instruction Manual

Model: 2019030708

Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your YING RAY Universal Air Conditioner Remote Control. This remote is designed to be compatible with a wide range of air conditioner brands and models, including Airwell, Emailair, Electra, and Elco units. Please read this manual carefully before use to ensure proper functionality and to maximize the lifespan of your remote control.

Product Overview

The YING RAY Universal Air Conditioner Remote Control is a replacement remote designed for ease of use and broad compatibility. It features a clear display and intuitive button layout for controlling various functions of your air conditioner.





Image: Front view of the YING RAY Universal Air Conditioner Remote Control, showing its overall design and button layout.

Setup and Code Setting

1. Battery Installation

Open the battery compartment cover on the back of the remote control. Insert two new AAA batteries, ensuring the positive (+) and negative (-) terminals match the markings inside the compartment. Close the battery cover securely.

2. Code Setting for Compatibility

This universal remote requires a one-time code setting to match your specific air conditioner unit. Follow these steps:

1. Ensure your air conditioner is powered on.
2. Press and hold the **SET** and **MODE** buttons simultaneously on the remote control.
3. Continue holding until a 2-digit remote code flashes on the remote's display.
4. While the code is flashing, use the **+** and **-** buttons (usually for temperature or hour adjustment) to cycle through the available codes. Point the remote at your air conditioner during this process.
5. Stop pressing the **+** or **-** button when your air conditioner responds (e.g., turns on, off, or changes mode).
6. Immediately press the **SET** button to confirm and save the code. The flashing code will disappear.
7. Test all functions of the remote control to ensure full compatibility. If some functions do not work, repeat the code setting process to find a more suitable code.



Image: Visual guide for code setting, illustrating the process of pressing SET + MODE and using +/- buttons to find the correct code. Also displays various compatible original remote models.

Operating Instructions

Once the remote is successfully paired with your air conditioner, you can use the following buttons to control its functions:



Image: Detailed close-up of the remote control's buttons, showing their labels and functions.

- **Power Button (Orange, with universal power symbol):** Turns the air conditioner ON or OFF.
- **MODE:** Cycles through operating modes such as Cool, Heat, Fan, Dry, Auto.
- **TEMP + / -:** Adjusts the desired temperature up or down. The display shows temperature in Celsius.
- **FAN (Fan symbol):** Adjusts fan speed (Auto, Low, Medium, High).
- **SWING (Swing symbol):** Controls the louver swing function.
- **TIMER:** Sets the timer for automatic ON/OFF operations.
- **SET:** Confirms settings, especially for timer or code setting.
- **CLEAR:** Clears current timer or other temporary settings.
- **HOUR + / -:** Used for adjusting time settings, typically for the timer function.

- **ROOM:** May display or set the room temperature.
- **I FEEL:** Activates a function where the remote senses the temperature at its location and adjusts the AC accordingly.
- **SLEEP:** Activates sleep mode, which typically adjusts temperature and fan speed for comfortable sleep.

Maintenance

Cleaning the Remote Control

To clean the remote control, gently wipe its surface with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, followed by a dry cloth. Do not use harsh chemicals, abrasive cleaners, or immerse the remote in water.

Battery Replacement

When the remote control's display becomes dim or its response time slows, it is time to replace the batteries. Always replace both batteries with new AAA batteries simultaneously. Do not mix old and new batteries or different types of batteries.

Troubleshooting

- **Remote not responding:**
  - Check if batteries are inserted correctly and have sufficient power. Replace if necessary.
  - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
  - Verify that the remote is pointed directly at the air conditioner.
- **Air conditioner not responding to commands:**
  - Re-perform the code setting procedure (refer to "Setup and Code Setting" section) to ensure the correct code is selected for your air conditioner model.
  - Try different codes if the first attempt does not yield full functionality.
- **Display is dim or blank:**
  - Replace the batteries with new ones.

Specifications

- **Brand:** YING RAY
- **Model Number:** 2019030708
- **Special Feature:** Universal compatibility
- **Compatible Devices:** Air Conditioner
- **Connectivity Technology:** Infrared
- **Controller Type:** Button Control
- **Maximum Range:** 10 Meters
- **Display:** Celsius

Product Features and Quality

The YING RAY remote control is manufactured with attention to quality, featuring a durable design and a clear display. The LCD surface is made from a thick, high-quality lens material, ensuring durability and clear visibility.



Image: Illustrates the difference between a thick, high-quality LCD lens material (labeled 'GOOD') and a thin, lower-quality PVC material (labeled 'BAD').

Additionally, the remote control's LCD screen comes with a protective film to prevent scratches during shipping and initial handling. This film should be removed before regular use for optimal display clarity.



Image: Shows the protective film applied to the LCD screen of the remote control, indicated by red lines.

Support Information

For any questions, assistance with code setting, or if you are looking for compatibility with other remote control models, please contact YING RAY customer support. You can leave a message on Amazon or reach out through the seller's contact information provided with your purchase.
We specialize in remote controls for various devices and are committed to providing support for our products.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07PFNVLX4

More documents and user manuals: **https://manuals.plus/**